aiwa SERVICE

# AV-D77 U,EZ

# SERVICE MANUAL

STEREO
AV RECEIVER

aiwa

S/M Code No. 09-004-429-6T2

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | AC OUTLET | | 8A-AR3-631-010 | | PWB,COMB AC OUTLET (6M) | UBM | AV-D77 |
| | X | AC OUTLET | | 8A-AR3-631-110 | -- | PWB,COMB AC OUTLET (6M) | UBM | AV-D77 |
| | O | AC OUTLET | C 0011 | 87-A11-155-080 | | CAP,TC U 0.01-16 Z F | UBM | AV-D77 |
| | O | AC OUTLET | C 0011 | 87-A11-155-080 | 0E | CAP,TC U 0.01-16 Z F | UBM | AV-D77 |
| | O | AC OUTLET | C 0102 | 87-A10-922-090 | | CAP,CER 0.01-250 M F KH | UBM | AV-D77 |
| ! | O | AC OUTLET | C 0102 | 87-A10-922-090 | 1A | CAP,CER 0.01-250 M F KH | UBM | AV-D77 |
| | X | AC OUTLET | CN 0104 | 87-099-448-010 | | CONN,2P V VT | UBM | AV-D77 |
| | X | AC OUTLET | CN 0104 | 87-099-448-010 | 0E | CONN,2P V VT | UBM | AV-D77 |
| | O | AC OUTLET | CNA0101 | 88-805-036-010 | | CONN ASSY,3P | UBM | AV-D77 |
| | O | AC OUTLET | CNA0101 | 88-805-036-010 | 0E | CONN ASSY,3P | UBM | AV-D77 |
| | S | AC OUTLET | D 0006 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | AC OUTLET | D 0006 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | O | AC OUTLET | FC 0103 | 87-A90-160-080 | | FUSE CLAMP,FC 51F | UBM | AV-D77 |
| | O | AC OUTLET | FC 0103 | 87-A90-160-080 | 0E | FUSE CLAMP,FC 51F | UBM | AV-D77 |
| | O | AC OUTLET | FC 0104 | 87-A90-160-080 | | FUSE CLAMP,FC 51F | UBM | AV-D77 |
| | O | AC OUTLET | FC 0104 | 87-A90-160-080 | 0E | FUSE CLAMP,FC 51F | UBM | AV-D77 |
| | O | AC OUTLET | J 0101 | 87-A61-192-010 | | OUTLET,AC CCT 1304-0202 | UBM | AV-D77 |
| ! | O | AC OUTLET | J 0101 | 87-A61-192-010 | 1C | OUTLET,AC CCT 1304-0202 | UBM | AV-D77 |
| | S | AC OUTLET | Q 0006 | 87-026-610-080 | | TR,KTC3198GR | UBM | AV-D77 |
| | S | AC OUTLET | Q 0006 | 87-026-610-080 | 0E | TR,KTC3198GR | UBM | AV-D77 |
| | X | AC OUTLET | R 0006 | 88-121-100-080 | | RES,10-1/8W J | UBM | AV-D77 |
| | X | AC OUTLET | R 0006 | 88-121-100-080 | 0E | RES,10-1/8W J | UBM | AV-D77 |
| | X | AC OUTLET | R 0007 | 88-121-103-080 | | RES,10K-1/8W J | UBM | AV-D77 |
| | X | AC OUTLET | R 0007 | 88-121-103-080 | 0E | RES,10K-1/8W J | UBM | AV-D77 |
| | O | AC OUTLET | RY 0006 | 87-A90-977-010 | | RELAY,AC12V DG12D1-O(M) | UBM | AV-D77 |
| ! | O | AC OUTLET | RY 0006 | 87-A90-977-010 | 1C | RELAY,AC12V DG12D1-O(M) | UBM | AV-D77 |
| | O | AC-3,CON | CN 0504 | 87-099-574-010 | | CONN,20P TUC-P20P-B1 | UBM | AV-D77 |
| | O | AC-3,CON | CN 0504 | 87-099-574-010 | 0E | CONN,20P TUC-P20P-B1 | EZBM | AV-D77 |
| | O | AC-3,CON | CN 0504 | 87-099-574-010 | 0E | CONN,20P TUC-P20P-B1 | UBM | AV-D77 |
| | O | AC-3,CON | CN 0505 | 87-A60-189-010 | | CONN,16P V TUC-P16P-B1 | UBM | AV-D77 |
| ! | O | AC-3,CON | CN 0505 | 87-A60-189-010 | 0E | CONN,16P V TUC-P16P-B1 | EZBM | AV-D77 |
| ! | O | AC-3,CON | CN 0505 | 87-A60-189-010 | 0E | CONN,16P V TUC-P16P-B1 | UBM | AV-D77 |
| | X | AC-3,CON | JR 0188 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0188 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AC-3,CON | JR 0188 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0315 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0315 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AC-3,CON | JR 0315 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0520 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0520 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AC-3,CON | JR 0520 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0606 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0606 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AC-3,CON | JR 0606 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0939 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0939 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AC-3,CON | JR 0939 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0950 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AC-3,CON | JR 0950 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AC-3,CON | JR 0950 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | ACCESSORY | | 87-043-115-010 | | FEEDER-ANT,FM | UBM | AV-D77 |
| | O | ACCESSORY | | 87-043-115-010 | 1A | FEEDER-ANT,FM | UBM | AV-D77 |
| | O | ACCESSORY | | 87-A90-118-010 | 0E | ANT,WIRE FM(Z) | EZBM | AV-D77 |
| | O | ACCESSORY | | 8A-AR1-701-010 | | RC UNIT,RC-AAR01 BLK | UBM | AV-D77 |
| | O | ACCESSORY | | 8A-AR1-701-010 | 2M | RC UNIT,RC-AAR01 BLK | UBM | AV-D77 |
| | O | ACCESSORY | | 8A-AR2-701-110 | 1H | RC UNIT,RC-AAR02 BLK | EZBM | AV-D77 |
| | O | ACCESSORY | ANT | 87-006-225-010 | | ANT,LOOP ANT NC2 | UBM | AV-D77 |
| | O | ACCESSORY | ANT | 87-006-225-010 | 1D | ANT,LOOP ANT NC2 | EZBM | AV-D77 |
| | O | ACCESSORY | ANT | 87-006-225-010 | 1D | ANT,LOOP ANT NC2 | UBM | AV-D77 |
| | O | APPEARANCE | | 87-CE3-023-010 | | BADGE,AIWA 30N SILV | UBM | AV-D77 |
| ! | O | APPEARANCE | | 87-CE3-023-010 | 0E | BADGE,AIWA 30N SILV | EZBM | AV-D77 |
| ! | O | APPEARANCE | | 87-CE3-023-010 | 0E | BADGE,AIWA 30N SILV | UBM | AV-D77 |
| | O | APPEARANCE | | 8A-AR1-005-010 | | PANEL,FR U | UBM | AV-D77 |
| | O | APPEARANCE | | 8A-AR1-005-010 | 1D | PANEL,FR U | UBM | AV-D77 |
| | O | APPEARANCE | | 8A-AR1-006-010 | 1D | PANEL,FR EZ | EZBM | AV-D77 |
| | O | APPEARANCE | | 8A-AR2-013-110 | 1E | PANEL,REAR EZBM | EZBM | AV-D77 |
| | O | APPEARANCE | | 8A-AR2-015-010 | | PANEL,REAR UBM | UBM | AV-D77 |
| | O | APPEARANCE | | 8A-AR2-015-010 | 1E | PANEL,REAR UBM | UBM | AV-D77 |
| | O | APPEARANCE | | 8Z-AR1-020-110 | | RING,FOOT SIL | UBM | AV-D77 |
| | O | APPEARANCE | | 8Z-AR1-020-110 | 1A | RING,FOOT SIL | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | APPEARANCE | | 8Z-AR1-020-110 | 1A | RING,FOOT SIL | UBM | AV-D77 |
| | O | APPEARANCE | | 8Z-AR1-021-110 | | FOOT,REAR | UBM | AV-D77 |
| | O | APPEARANCE | | 8Z-AR1-021-110 | 1A | FOOT,REAR | EZBM | AV-D77 |
| | O | APPEARANCE | | 8Z-AR1-021-110 | 1A | FOOT,REAR | UBM | AV-D77 |
| | O | APPEARANCE | * | 8A-AR2-001-110 | | CABI,FR U | UBM | AV-D77 |
| | O | APPEARANCE | * | 8A-AR2-001-110 | 2A | CABI,FR U | EZBM | AV-D77 |
| | O | APPEARANCE | * | 8A-AR2-001-110 | 2A | CABI,FR U | UBM | AV-D77 |
| | O | APPEARANCE | * | 8A-AR3-025-010 | | CABI,STEEL | UBM | AV-D77 |
| | O | APPEARANCE | * | 8A-AR3-025-010 | 2M | CABI,STEEL | EZBM | AV-D77 |
| | O | APPEARANCE | * | 8A-AR3-025-010 | 2M | CABI,STEEL | UBM | AV-D77 |
| | O | ATT SW | C 0548 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | ATT SW | C 0548 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | ATT SW | C 0548 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | ATT SW | C 0723 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | ATT SW | C 0723 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |
| | O | ATT SW | C 0723 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | ATT SW | C 0726 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | ATT SW | C 0726 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | ATT SW | C 0726 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | ATT SW | CN 0601 | 87-A60-627-010 | | CONN,10P V 2MM JMT | UBM | AV-D77 |
| | O | ATT SW | CN 0601 | 87-A60-627-010 | 0E | CONN,10P V 2MM JMT | EZBM | AV-D77 |
| | O | ATT SW | CN 0601 | 87-A60-627-010 | 0E | CONN,10P V 2MM JMT | UBM | AV-D77 |
| | X | ATT SW | JR 0567 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | ATT SW | JR 0567 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | ATT SW | JR 0567 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | ATT SW | JR 0590 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | ATT SW | JR 0590 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | ATT SW | JR 0590 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | S | ATT SW | Q 0721 | 87-A30-257-080 | | C-TR,2SD1306E | UBM | AV-D77 |
| | S | ATT SW | Q 0721 | 87-A30-257-080 | 0E | C-TR,2SD1306E | EZBM | AV-D77 |
| | S | ATT SW | Q 0721 | 87-A30-257-080 | 0E | C-TR,2SD1306E | UBM | AV-D77 |
| | X | ATT SW | R 0730 | 88-118-222-080 | | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | ATT SW | R 0730 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | EZBM | AV-D77 |
| | X | ATT SW | R 0730 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | ATT SW | R 0732 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | ATT SW | R 0732 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | ATT SW | R 0732 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | O | AV SEL | C 0560 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0560 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | AV SEL | C 0560 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0901 | 87-010-406-080 | | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0901 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | EZBM | AV-D77 |
| | O | AV SEL | C 0901 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0902 | 87-010-406-080 | | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0902 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | EZBM | AV-D77 |
| | O | AV SEL | C 0902 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0903 | 87-010-406-080 | | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0903 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | EZBM | AV-D77 |
| | O | AV SEL | C 0903 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0904 | 87-010-406-080 | | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0904 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | EZBM | AV-D77 |
| | O | AV SEL | C 0904 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0905 | 87-010-406-080 | | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0905 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | EZBM | AV-D77 |
| | O | AV SEL | C 0905 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0906 | 87-010-260-080 | | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0906 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | EZBM | AV-D77 |
| | O | AV SEL | C 0906 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | AV SEL | C 0907 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0907 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | AV SEL | C 0907 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0908 | 87-010-387-080 | | CAP,E 470-25 M SME | UBM | AV-D77 |
| | O | AV SEL | C 0908 | 87-010-387-080 | 1A | CAP,E 470-25 M SME | EZBM | AV-D77 |
| | O | AV SEL | C 0908 | 87-010-387-080 | 1A | CAP,E 470-25 M SME | UBM | AV-D77 |
| | O | AV SEL | C 0909 | 87-010-371-080 | | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | AV SEL | C 0909 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | EZBM | AV-D77 |
| | O | AV SEL | C 0909 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | AV SEL | C 0910 | 87-010-371-080 | | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | AV SEL | C 0910 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | EZBM | AV-D77 |
| | O | AV SEL | C 0910 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | AV SEL | C 0911 | 87-010-371-080 | | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | AV SEL | C 0911 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | EZBM | AV-D77 |
| | O | AV SEL | C 0911 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | AV SEL | C 0912 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0912 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | AV SEL | C 0912 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0913 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0913 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | AV SEL | C 0913 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0914 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0914 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | AV SEL | C 0914 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0915 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0915 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | AV SEL | C 0915 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | C 0951 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | AV SEL | C 0952 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | AV SEL | C 0953 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | AV SEL | C 0954 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | AV SEL | CN 0510 | 87-A60-063-010 | | CONN,04P V 9604S-04C | UBM | AV-D77 |
| | O | AV SEL | CN 0510 | 87-A60-063-010 | 0E | CONN,04P V 9604S-04C | UBM | AV-D77 |
| | S | AV SEL | D 0901 | 87-070-136-080 | | ZENER,MTZJ5.1B | UBM | AV-D77 |
| | S | AV SEL | D 0901 | 87-070-136-080 | 0E | ZENER,MTZJ5.1B | EZBM | AV-D77 |
| | S | AV SEL | D 0901 | 87-070-136-080 | 0E | ZENER,MTZJ5.1B | UBM | AV-D77 |
| | S | AV SEL | D 0902 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | AV SEL | D 0902 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | AV SEL | D 0902 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | AV SEL | D 0903 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | AV SEL | D 0903 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | AV SEL | D 0903 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | AV SEL | IC 0901 | 87-A20-820-010 | | IC,BA7625 | UBM | AV-D77 |
| | S | AV SEL | IC 0901 | 87-A20-820-010 | 1C | IC,BA7625 | EZBM | AV-D77 |
| | S | AV SEL | IC 0901 | 87-A20-820-010 | 1C | IC,BA7625 | UBM | AV-D77 |
| | S | AV SEL | IC 0902 | 87-017-917-080 | 1A | C-IC,BU4066BCF | EZBM | AV-D77 |
| | S | AV SEL | IC 0902 | 87-017-917-080 | 1A | C-IC,BU4066BCF | UBM | AV-D77 |
| O | S | AV SEL | IC 0902 | 87-017-917-080 | | C-IC,BU4066BCF | UBM | AV-D77 |
| | O | AV SEL | J 0901 | 87-A60-949-010 | | JACK,PIN 3P R/W/Y V GLD | UBM | AV-D77 |
| | O | AV SEL | J 0901 | 87-A60-949-010 | 1B | JACK,PIN 3P R/W/Y V GLD | EZBM | AV-D77 |
| | O | AV SEL | J 0901 | 87-A60-949-010 | 1B | JACK,PIN 3P R/W/Y V GLD | UBM | AV-D77 |
| | O | AV SEL | J 0902 | 87-A60-950-010 | | JACK,PIN 3P R/W/Y W/E GLD | UBM | AV-D77 |
| | O | AV SEL | J 0902 | 87-A60-950-010 | 1B | JACK,PIN 3P R/W/Y W/E GLD | EZBM | AV-D77 |
| | O | AV SEL | J 0902 | 87-A60-950-010 | 1B | JACK,PIN 3P R/W/Y W/E GLD | UBM | AV-D77 |
| | O | AV SEL | J 0903 | 87-A60-949-010 | | JACK,PIN 3P R/W/Y V GLD | UBM | AV-D77 |
| | O | AV SEL | J 0903 | 87-A60-949-010 | 1B | JACK,PIN 3P R/W/Y V GLD | EZBM | AV-D77 |
| | O | AV SEL | J 0903 | 87-A60-949-010 | 1B | JACK,PIN 3P R/W/Y V GLD | UBM | AV-D77 |
| | O | AV SEL | J 0904 | 87-A60-949-010 | | JACK,PIN 3P R/W/Y V GLD | UBM | AV-D77 |
| | O | AV SEL | J 0904 | 87-A60-949-010 | 1B | JACK,PIN 3P R/W/Y V GLD | EZBM | AV-D77 |
| | O | AV SEL | J 0904 | 87-A60-949-010 | 1B | JACK,PIN 3P R/W/Y V GLD | UBM | AV-D77 |
| | O | AV SEL | J 0905 | 87-A60-949-010 | | JACK,PIN 3P R/W/Y V GLD | UBM | AV-D77 |
| | O | AV SEL | J 0905 | 87-A60-949-010 | 1B | JACK,PIN 3P R/W/Y V GLD | EZBM | AV-D77 |
| | O | AV SEL | J 0905 | 87-A60-949-010 | 1B | JACK,PIN 3P R/W/Y V GLD | UBM | AV-D77 |
| | X | AV SEL | JR 0525 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0525 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | AV SEL | JR 0525 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0530 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0530 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0530 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0548 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0548 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | AV SEL | JR 0548 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0550 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0550 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0550 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0552 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0552 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | AV SEL | JR 0552 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0750 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0750 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0750 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0901 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | AV SEL | JR 0901 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0901 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0902 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0902 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0902 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0903 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0903 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0903 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0904 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0904 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0904 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0905 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0905 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | AV SEL | JR 0905 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0906 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0906 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0906 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0908 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0908 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0908 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0909 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0909 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | AV SEL | JR 0909 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0910 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0910 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0910 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0911 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0911 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0911 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0912 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0912 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | AV SEL | JR 0912 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0913 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0913 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0913 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0914 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0914 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0914 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0915 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0915 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0915 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0916 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0916 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | AV SEL | JR 0916 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0917 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0917 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | AV SEL | JR 0917 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0918 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0918 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0918 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0920 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0920 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | AV SEL | JR 0920 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | AV SEL | JR 0921 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0921 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0921 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0922 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0922 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0922 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0923 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | AV SEL | JR 0923 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | JR 0923 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | AV SEL | L 0901 | 87-005-239-080 | | COIL,100UH K LAL03 | UBM | AV-D77 |
| | O | AV SEL | L 0901 | 87-005-239-080 | 0E | COIL,100UH K LAL03 | EZBM | AV-D77 |
| | O | AV SEL | L 0901 | 87-005-239-080 | 0E | COIL,100UH K LAL03 | UBM | AV-D77 |
| | S | AV SEL | Q 0901 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | AV SEL | Q 0901 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | AV SEL | Q 0901 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | AV SEL | Q 0902 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | AV SEL | Q 0902 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | AV SEL | Q 0902 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | AV SEL | Q 0903 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | AV SEL | Q 0903 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | AV SEL | Q 0903 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | AV SEL | Q 0904 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | AV SEL | Q 0904 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | AV SEL | Q 0904 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | AV SEL | Q 0905 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | AV SEL | Q 0905 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | AV SEL | Q 0905 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | AV SEL | Q 0906 | 87-A30-074-080 | | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | AV SEL | Q 0906 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | EZBM | AV-D77 |
| | S | AV SEL | Q 0906 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | AV SEL | Q 0907 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | AV SEL | Q 0907 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | AV SEL | Q 0907 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | O | AV SEL | R 0902 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | AV SEL | R 0902 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | AV SEL | R 0902 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | X | AV SEL | R 0903 | 88-118-334-080 | | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0903 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0903 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0904 | 88-118-334-080 | | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0904 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0904 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | O | AV SEL | R 0905 | 87-010-317-080 | | C-CAP,S 39P-50 J CH | UBM | AV-D77 |
| | O | AV SEL | R 0905 | 87-010-317-080 | 0E | C-CAP,S 39P-50 J CH | EZBM | AV-D77 |
| | O | AV SEL | R 0905 | 87-010-317-080 | 0E | C-CAP,S 39P-50 J CH | UBM | AV-D77 |
| | X | AV SEL | R 0907 | 88-118-334-080 | | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0907 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0907 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0908 | 88-118-334-080 | | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0908 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0908 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0909 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0909 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0909 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0910 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0910 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0910 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0911 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0911 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0911 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0912 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0912 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0912 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0913 | 88-121-820-080 | | RES,82-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0913 | 88-121-820-080 | 0E | RES,82-1/8W J | EZBM | AV-D77 |
| | X | AV SEL | R 0913 | 88-121-820-080 | 0E | RES,82-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0914 | 88-128-820-080 | | C-RES, 82-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0914 | 88-128-820-080 | 0E | C-RES, 82-1/8W J | EZBM | AV-D77 |
| | X | AV SEL | R 0914 | 88-128-820-080 | 0E | C-RES, 82-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0915 | 88-128-820-080 | | C-RES, 82-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0915 | 88-128-820-080 | 0E | C-RES, 82-1/8W J | EZBM | AV-D77 |
| | X | AV SEL | R 0915 | 88-128-820-080 | 0E | C-RES, 82-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0916 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0916 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0916 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0917 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0917 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0917 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0918 | 88-118-682-080 | | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0918 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0918 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0919 | 88-118-682-080 | | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0919 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0919 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0920 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0920 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0920 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | AV SEL | R 0921 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0921 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0921 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0922 | 88-130-471-080 | | RES,470-1/4W J | UBM | AV-D77 |
| | X | AV SEL | R 0922 | 88-130-471-080 | 0E | RES,470-1/4W J | EZBM | AV-D77 |
| | X | AV SEL | R 0922 | 88-130-471-080 | 0E | RES,470-1/4W J | UBM | AV-D77 |
| | X | AV SEL | R 0923 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0923 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0923 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0924 | 88-130-471-080 | | RES,470-1/4W J | UBM | AV-D77 |
| | X | AV SEL | R 0924 | 88-130-471-080 | 0E | RES,470-1/4W J | EZBM | AV-D77 |
| | X | AV SEL | R 0924 | 88-130-471-080 | 0E | RES,470-1/4W J | UBM | AV-D77 |
| | X | AV SEL | R 0925 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0925 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0925 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0926 | 88-130-471-080 | | RES,470-1/4W J | UBM | AV-D77 |
| | X | AV SEL | R 0926 | 88-130-471-080 | 0E | RES,470-1/4W J | EZBM | AV-D77 |
| | X | AV SEL | R 0926 | 88-130-471-080 | 0E | RES,470-1/4W J | UBM | AV-D77 |
| | X | AV SEL | R 0927 | 88-121-750-080 | | RES,75-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0927 | 88-121-750-080 | 0E | RES,75-1/8W J | EZBM | AV-D77 |
| | X | AV SEL | R 0927 | 88-121-750-080 | 0E | RES,75-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0928 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0928 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0928 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0929 | 88-121-750-080 | | RES,75-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0929 | 88-121-750-080 | 0E | RES,75-1/8W J | EZBM | AV-D77 |
| | X | AV SEL | R 0929 | 88-121-750-080 | 0E | RES,75-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0930 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | AV SEL | R 0931 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0931 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0931 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0932 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0932 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | AV SEL | R 0932 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | AV SEL | R 0933 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0933 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0933 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0934 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0934 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0934 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0935 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0935 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0935 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0936 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0936 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0936 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0937 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0937 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0937 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0938 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0938 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0938 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0939 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0939 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0939 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0940 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0940 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0940 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0941 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0941 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0941 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0942 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0942 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0942 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0943 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0943 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0943 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0944 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0944 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0944 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | AV SEL | R 0945 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0945 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0945 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0946 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0946 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0946 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0947 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0947 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0947 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0948 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0948 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0948 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0949 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0949 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0949 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0950 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | AV SEL | R 0950 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | AV SEL | R 0950 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | O | BBE | C 0601 | 87-010-378-080 | | CAP,E 10-16 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0601 | 87-010-378-080 | 0E | CAP,E 10-16 M 11L SME | EZBM | AV-D77 |
| | O | BBE | C 0601 | 87-010-378-080 | 0E | CAP,E 10-16 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0602 | 87-010-378-080 | | CAP,E 10-16 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0602 | 87-010-378-080 | 0E | CAP,E 10-16 M 11L SME | EZBM | AV-D77 |
| | O | BBE | C 0602 | 87-010-378-080 | 0E | CAP,E 10-16 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0603 | 87-012-156-080 | | C-CAP,S 220P-50 J CH GRM | UBM | AV-D77 |
| | O | BBE | C 0603 | 87-012-156-080 | 0E | C-CAP,S 220P-50 J CH GRM | EZBM | AV-D77 |
| | O | BBE | C 0603 | 87-012-156-080 | 0E | C-CAP,S 220P-50 J CH GRM | UBM | AV-D77 |
| | O | BBE | C 0604 | 87-012-156-080 | | C-CAP,S 220P-50 J CH GRM | UBM | AV-D77 |
| | O | BBE | C 0604 | 87-012-156-080 | 0E | C-CAP,S 220P-50 J CH GRM | EZBM | AV-D77 |
| | O | BBE | C 0604 | 87-012-156-080 | 0E | C-CAP,S 220P-50 J CH GRM | UBM | AV-D77 |
| | O | BBE | C 0605 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0605 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | BBE | C 0605 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0606 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0606 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | BBE | C 0606 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0607 | 87-012-140-080 | | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | BBE | C 0607 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | EZBM | AV-D77 |
| | O | BBE | C 0607 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | BBE | C 0608 | 87-012-140-080 | | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | BBE | C 0608 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | EZBM | AV-D77 |
| | O | BBE | C 0608 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | BBE | C 0609 | 87-010-188-080 | | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | BBE | C 0609 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | EZBM | AV-D77 |
| | O | BBE | C 0609 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | BBE | C 0610 | 87-010-188-080 | | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | BBE | C 0610 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | EZBM | AV-D77 |
| | O | BBE | C 0610 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | BBE | C 0611 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | BBE | C 0611 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |
| | O | BBE | C 0611 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | BBE | C 0612 | 87-010-195-080 | | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | BBE | C 0612 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | EZBM | AV-D77 |
| | O | BBE | C 0612 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | BBE | C 0613 | 87-010-195-080 | | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | BBE | C 0613 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | EZBM | AV-D77 |
| | O | BBE | C 0613 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | BBE | C 0614 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | BBE | C 0614 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |
| | O | BBE | C 0614 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | BBE | C 0615 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0615 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | BBE | C 0615 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0616 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0616 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | BBE | C 0616 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0617 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0617 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | BBE | C 0617 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0618 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | BBE | C 0618 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | BBE | C 0618 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0619 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0619 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | BBE | C 0619 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0620 | 87-010-101-080 | | CAP,E 220-16 M SME | UBM | AV-D77 |
| | O | BBE | C 0620 | 87-010-101-080 | 0E | CAP,E 220-16 M SME | EZBM | AV-D77 |
| | O | BBE | C 0620 | 87-010-101-080 | 0E | CAP,E 220-16 M SME | UBM | AV-D77 |
| | O | BBE | C 0621 | 87-010-260-080 | | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | BBE | C 0621 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | EZBM | AV-D77 |
| | O | BBE | C 0621 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | S | BBE | D 0601 | 87-A40-269-080 | | C-DIODE,MC2836 | UBM | AV-D77 |
| | S | BBE | D 0601 | 87-A40-269-080 | 0E | C-DIODE,MC2836 | EZBM | AV-D77 |
| | S | BBE | D 0601 | 87-A40-269-080 | 0E | C-DIODE,MC2836 | UBM | AV-D77 |
| | S | BBE | D 0602 | 87-A40-269-080 | | C-DIODE,MC2836 | UBM | AV-D77 |
| | S | BBE | D 0602 | 87-A40-269-080 | 0E | C-DIODE,MC2836 | EZBM | AV-D77 |
| | S | BBE | D 0602 | 87-A40-269-080 | 0E | C-DIODE,MC2836 | UBM | AV-D77 |
| | S | BBE | IC 0601 | 87-A20-056-010 | | IC,BA3880S | UBM | AV-D77 |
| | S | BBE | IC 0601 | 87-A20-056-010 | 1E | IC,BA3880S | EZBM | AV-D77 |
| | S | BBE | IC 0601 | 87-A20-056-010 | 1E | IC,BA3880S | UBM | AV-D77 |
| | X | BBE | JR 0604 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | BBE | JR 0604 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | BBE | JR 0604 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | BBE | JR 0605 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | BBE | JR 0605 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | BBE | JR 0605 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | BBE | JR 0701 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | BBE | JR 0701 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | BBE | JR 0701 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | BBE | JR 0703 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | BBE | JR 0703 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | BBE | JR 0703 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | BBE | R 0601 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | BBE | R 0601 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | BBE | R 0601 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | BBE | R 0602 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0602 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | BBE | R 0602 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0603 | 88-128-101-080 | | C-RES, 100-1/8W J | UBM | AV-D77 |
| | X | BBE | R 0603 | 88-128-101-080 | 0E | C-RES, 100-1/8W J | EZBM | AV-D77 |
| | X | BBE | R 0603 | 88-128-101-080 | 0E | C-RES, 100-1/8W J | UBM | AV-D77 |
| | X | BBE | R 0604 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0604 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | BBE | R 0604 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0605 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0605 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | BBE | R 0605 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0606 | 88-118-332-080 | | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0606 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | EZBM | AV-D77 |
| | X | BBE | R 0606 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0607 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0607 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |
| | X | BBE | R 0607 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0608 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0608 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | BBE | R 0608 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0609 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | BBE | R 0609 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | BBE | R 0609 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | O | DD CB MECHA | | 87-067-703-010 | | BVT2+3-10 W/O SL0T | UBM | AV-D77 |
| | O | DD CB MECHA | | 87-067-703-010 | 0E | BVT2+3-10 W/O SL0T | EZBM | AV-D77 |
| | O | DD CB MECHA | | 87-067-703-010 | 0E | BVT2+3-10 W/O SL0T | UBM | AV-D77 |
| | X | DD CB MECHA | | 8A-AR3-208-010 | | HT-SINK,TR AC3 | UBM | AV-D77 |
| | X | DD CB MECHA | | 8A-AR3-208-010 | 0E | HT-SINK,TR AC3 | EZBM | AV-D77 |
| | X | DD CB MECHA | | 8A-AR3-208-010 | 0E | HT-SINK,TR AC3 | UBM | AV-D77 |
| ! | X | DOLBY DIGITAL | | 87-839-301-510 | 0E | TUBE,UL 3-15 | EZBM | AV-D77 |
| ! | X | DOLBY DIGITAL | | 87-839-301-510 | 0E | TUBE,UL 3-15 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | * | 8A-AR1-625-010 | | PWB,DIGITAL | UBM | AV-D77 |
| | X | DOLBY DIGITAL | * | 8A-AR1-625-110 | 1C | PWB,DIGITAL | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | * | 8A-AR1-625-110 | 1C | PWB,DIGITAL | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | DOLBY DIGITAL | C 0100 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0100 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0100 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0101 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0101 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0101 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0102 | 87-010-374-080 | | CAP,E 47-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0102 | 87-010-374-080 | 0E | CAP,E 47-10 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0102 | 87-010-374-080 | 0E | CAP,E 47-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0105 | 87-012-140-080 | | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0105 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0105 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0106 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0106 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0106 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0107 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0107 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0107 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0108 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0108 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0108 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0109 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0109 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0109 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0110 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0110 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0110 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0111 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0111 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0111 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0112 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0112 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0112 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0113 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0113 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0113 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0114 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0114 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0114 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0115 | 87-010-374-080 | | CAP,E 47-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0115 | 87-010-374-080 | 0E | CAP,E 47-10 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0115 | 87-010-374-080 | 0E | CAP,E 47-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0118 | 87-010-402-080 | | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0118 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0118 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0119 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0119 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0119 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0120 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0120 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0120 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0121 | 87-010-263-080 | | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0121 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0121 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0122 | 87-010-311-080 | | C-CAP,S 12P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0122 | 87-010-311-080 | 0E | C-CAP,S 12P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0122 | 87-010-311-080 | 0E | C-CAP,S 12P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0123 | 87-010-313-080 | | C-CAP,S 18P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0123 | 87-010-313-080 | 0E | C-CAP,S 18P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0123 | 87-010-313-080 | 0E | C-CAP,S 18P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0125 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0125 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0125 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0126 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0126 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0126 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0127 | 87-010-101-080 | | CAP,E 220-16 M SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0127 | 87-010-101-080 | 0E | CAP,E 220-16 M SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0127 | 87-010-101-080 | 0E | CAP,E 220-16 M SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0128 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | DOLBY DIGITAL | C 0128 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0128 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0129 | 87-010-101-080 | | CAP,E 220-16 M SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0129 | 87-010-101-080 | 0E | CAP,E 220-16 M SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0129 | 87-010-101-080 | 0E | CAP,E 220-16 M SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0130 | 87-010-182-080 | | C-CAP,S 2200P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0130 | 87-010-182-080 | 0E | C-CAP,S 2200P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0130 | 87-010-182-080 | 0E | C-CAP,S 2200P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0131 | 87-010-263-080 | | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0131 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0131 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0132 | 87-010-263-080 | | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0132 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0132 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0133 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0133 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0133 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | C 0134 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | C 0134 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | C 0134 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0135 | 87-010-101-080 | | CAP,E 220-16 M SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0135 | 87-010-101-080 | 0E | CAP,E 220-16 M SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0135 | 87-010-101-080 | 0E | CAP,E 220-16 M SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0136 | 87-010-263-080 | | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0136 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0136 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0137 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0137 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0137 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0138 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0138 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0138 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0139 | 87-010-314-080 | | C-CAP,S 22P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0139 | 87-010-314-080 | 0E | C-CAP,S 22P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0139 | 87-010-314-080 | 0E | C-CAP,S 22P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0140 | 87-010-552-040 | | CAP,E 22-16 M 5L SRE | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0140 | 87-010-552-040 | 0E | CAP,E 22-16 M 5L SRE | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0140 | 87-010-552-040 | 0E | CAP,E 22-16 M 5L SRE | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0141 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0141 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0141 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0142 | 87-010-182-080 | | C-CAP,S 2200P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0142 | 87-010-182-080 | 0E | C-CAP,S 2200P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0142 | 87-010-182-080 | 0E | C-CAP,S 2200P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0143 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0143 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0143 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0144 | 87-010-312-080 | | C-CAP,S 15P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0144 | 87-010-312-080 | 0E | C-CAP,S 15P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0144 | 87-010-312-080 | 0E | C-CAP,S 15P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0145 | 87-012-154-080 | | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0145 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0145 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0146 | 87-012-154-080 | | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0146 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0146 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0147 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0147 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0147 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0148 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0148 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0148 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0149 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0149 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0149 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0150 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0150 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0150 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0151 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0151 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | DOLBY DIGITAL | C 0151 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0152 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0152 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0152 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0153 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0153 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0153 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0154 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0154 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0154 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0155 | 87-A10-369-080 | | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0155 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0155 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0156 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0156 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0156 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0157 | 87-012-154-080 | | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0157 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0157 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0158 | 87-012-154-080 | | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0158 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0158 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0159 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0159 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0159 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0160 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0160 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0160 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0161 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0161 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0161 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0162 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0162 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0162 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0163 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0163 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0163 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0164 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0164 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0164 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0165 | 87-A10-369-080 | | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0165 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0165 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0166 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0166 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0166 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0167 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0167 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0167 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0168 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0168 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0168 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0169 | 87-012-154-080 | | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0169 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0169 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0170 | 87-012-154-080 | | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0170 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0170 | 87-012-154-080 | 0E | C-CAP,S 150P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0171 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0171 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0171 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0172 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0172 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0172 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0173 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0173 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0173 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0174 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0174 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0174 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | DOLBY DIGITAL | C 0175 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0175 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0175 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0176 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0176 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0176 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0177 | 87-A10-369-080 | | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0177 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0177 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0178 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0178 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0178 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0179 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0179 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0179 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0180 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0180 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0180 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0181 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0181 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0181 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0182 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0182 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0182 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0183 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0183 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0183 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0184 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0184 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0184 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0185 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0185 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0185 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0186 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0186 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0186 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0187 | 87-016-083-080 | | C-CAP,S 0.15-16 K R | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0187 | 87-016-083-080 | 0E | C-CAP,S 0.15-16 K R | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0187 | 87-016-083-080 | 0E | C-CAP,S 0.15-16 K R | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0188 | 87-016-083-080 | | C-CAP,S 0.15-16 K R | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0188 | 87-016-083-080 | 0E | C-CAP,S 0.15-16 K R | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0188 | 87-016-083-080 | 0E | C-CAP,S 0.15-16 K R | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0189 | 87-016-083-080 | | C-CAP,S 0.15-16 K R | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0189 | 87-016-083-080 | 0E | C-CAP,S 0.15-16 K R | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0189 | 87-016-083-080 | 0E | C-CAP,S 0.15-16 K R | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0190 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0190 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0190 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0191 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0191 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0191 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0192 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0192 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0192 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0193 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0193 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0193 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0194 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0194 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0194 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0195 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0195 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0195 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0196 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0196 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0196 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0197 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0197 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0197 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0198 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | DOLBY DIGITAL | C 0198 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0198 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0199 | 87-A10-369-080 | | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0199 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0199 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0201 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0201 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0201 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0202 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0202 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0202 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0203 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0203 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0203 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0204 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0204 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0204 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0205 | 87-A10-369-080 | | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0205 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0205 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0206 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0206 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0206 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0207 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0207 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0207 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0208 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0208 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0208 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0209 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0209 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0209 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0210 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0210 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0210 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0211 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0211 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0211 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0212 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0212 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0212 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0213 | 87-A10-369-080 | | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0213 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0213 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0214 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0214 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0214 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0215 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0215 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0215 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0216 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0216 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0216 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | 0 | DOLBY DIGITAL | C 0217 | 87-A10-793-080 | 0E | C-CAP,S 0.12-16 K B | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0217 | 87-A10-793-080 | 0E | C-CAP,S 0.12-16 K B | UBM | AV-D77 |
| | X | DOLBY DIGITAL | C 0217 | 87-A10-793-080 | | C-CAP,S 0.12-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0218 | 87-A10-793-080 | 0E | C-CAP,S 0.12-16 K B | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0218 | 87-A10-793-080 | 0E | C-CAP,S 0.12-16 K B | UBM | AV-D77 |
| | X | DOLBY DIGITAL | C 0218 | 87-A10-793-080 | | C-CAP,S 0.12-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0219 | 87-010-993-080 | | C-CAP,S 0.056-25 K B MK212 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0219 | 87-010-993-080 | 0E | C-CAP,S 0.056-25 K B MK212 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0219 | 87-010-993-080 | 0E | C-CAP,S 0.056-25 K B MK212 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0220 | 87-A10-369-080 | | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0220 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0220 | 87-A10-369-080 | 0E | C-CAP,S 0.47-16 K B | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0221 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0221 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0221 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0222 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0222 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | DOLBY DIGITAL | C 0222 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0223 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0223 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0223 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0224 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0224 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0224 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0227 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0227 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0227 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0228 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0228 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0228 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0236 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0236 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0236 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0237 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0237 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0237 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0238 | 87-010-314-080 | | C-CAP,S 22P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0238 | 87-010-314-080 | 0E | C-CAP,S 22P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0238 | 87-010-314-080 | 0E | C-CAP,S 22P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0239 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0239 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0239 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0240 | 87-010-314-080 | | C-CAP,S 22P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0240 | 87-010-314-080 | 0E | C-CAP,S 22P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0240 | 87-010-314-080 | 0E | C-CAP,S 22P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0241 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0241 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0241 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0242 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0242 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0242 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | C 0244 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | C 0244 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | C 0244 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0245 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0245 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0245 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0253 | 87-010-263-080 | | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0253 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0253 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0255 | 87-010-378-080 | | CAP,E 10-16 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0255 | 87-010-378-080 | 0E | CAP,E 10-16 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0255 | 87-010-378-080 | 0E | CAP,E 10-16 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0268 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0268 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0268 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0272 | 87-010-186-080 | | C-CAP,S 4700P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0272 | 87-010-186-080 | 0E | C-CAP,S 4700P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0272 | 87-010-186-080 | 0E | C-CAP,S 4700P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0273 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0273 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0273 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0275 | 87-010-263-080 | | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0275 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0275 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0278 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0278 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0278 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0280 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0280 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0280 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0292 | 87-010-314-080 | | C-CAP,S 22P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0292 | 87-010-314-080 | 0E | C-CAP,S 22P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0292 | 87-010-314-080 | 0E | C-CAP,S 22P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0295 | 87-010-318-080 | | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0295 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0295 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | DOLBY DIGITAL | C 0301 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0301 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0301 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0302 | 87-010-248-080 | 0E | CAP,E 220-10 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0302 | 87-010-248-080 | 0E | CAP,E 220-10 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0302 | 87-010-762-080 | | CAP,E 220-10 M SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0317 | 87-016-462-080 | | C-CAP,S 1-16 Z F | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0317 | 87-016-462-080 | 0E | C-CAP,S 1-16 Z F | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0317 | 87-016-462-080 | 0E | C-CAP,S 1-16 Z F | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0318 | 87-016-462-080 | | C-CAP,S 1-16 Z F | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0318 | 87-016-462-080 | 0E | C-CAP,S 1-16 Z F | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0318 | 87-016-462-080 | 0E | C-CAP,S 1-16 Z F | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0336 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0336 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0336 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0337 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0337 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0337 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0338 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0338 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0338 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0339 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0339 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0339 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0340 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0340 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0340 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0341 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0341 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0341 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0342 | 87-010-180-080 | | C-CAP,S 1500P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0342 | 87-010-180-080 | 0E | C-CAP,S 1500P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0342 | 87-010-180-080 | 0E | C-CAP,S 1500P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0343 | 87-010-180-080 | | C-CAP,S 1500P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0343 | 87-010-180-080 | 0E | C-CAP,S 1500P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0343 | 87-010-180-080 | 0E | C-CAP,S 1500P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0344 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0344 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0344 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0402 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0402 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0403 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0403 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0403 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0406 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0406 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0407 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0407 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0410 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0410 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0411 | 87-018-131-080 | 0E | CAP,TC U 1000P-50 K B UP050 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0411 | 87-018-131-080 | 0E | CAP,TC U 1000P-50 K B UP050 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0412 | 87-A10-207-080 | 0E | CAP,TC U 0.01-50 K B UP050 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | C 0412 | 87-A10-207-080 | 0E | CAP,TC U 0.01-50 K B UP050 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | CN 0101 | 87-099-563-010 | | CONN,20P TUC-P20X-B1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | CN 0101 | 87-099-563-010 | 1A | CONN,20P TUC-P20X-B1 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | CN 0101 | 87-099-563-010 | 1A | CONN,20P TUC-P20X-B1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | CN 0102 | 87-A60-190-010 | | CONN,16P H TUC-P16X-B1 | UBM | AV-D77 |
| ! | O | DOLBY DIGITAL | CN 0102 | 87-A60-190-010 | 0E | CONN,16P H TUC-P16X-B1 | EZBM | AV-D77 |
| ! | O | DOLBY DIGITAL | CN 0102 | 87-A60-190-010 | 0E | CONN,16P H TUC-P16X-B1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | CN 0103 | 8Z-AR1-635-010 | | CONN ASSY,4P (DTS,AC-3) | UBM | AV-D77 |
| | O | DOLBY DIGITAL | CN 0103 | 8Z-AR1-635-010 | 0E | CONN ASSY,4P (DTS,AC-3) | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | CN 0103 | 8Z-AR1-635-010 | 0E | CONN ASSY,4P (DTS,AC-3) | UBM | AV-D77 |
| | O | DOLBY DIGITAL | CN 0105 | 87-A60-060-010 | | CONN,07P V 9604S-07C | UBM | AV-D77 |
| ! | O | DOLBY DIGITAL | CN 0105 | 87-A60-060-010 | 0E | CONN,07P V 9604S-07C | EZBM | AV-D77 |
| ! | O | DOLBY DIGITAL | CN 0105 | 87-A60-060-010 | 0E | CONN,07P V 9604S-07C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0101 | 87-A40-291-080 | | DIODE,1N4148M (CPT) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0101 | 87-A40-291-080 | 0E | DIODE,1N4148M (CPT) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0101 | 87-A40-291-080 | 0E | DIODE,1N4148M (CPT) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0301 | 87-A40-270-080 | | C-DIODE,MC2838 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | DOLBY DIGITAL | D 0301 | 87-A40-270-080 | 0E | C-DIODE,MC2838 | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0301 | 87-A40-270-080 | 0E | C-DIODE,MC2838 | UBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0302 | 87-A40-270-080 | | C-DIODE,MC2838 | UBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0302 | 87-A40-270-080 | 0E | C-DIODE,MC2838 | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0302 | 87-A40-270-080 | 0E | C-DIODE,MC2838 | UBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0403 | 87-A40-291-080 | | DIODE,1N4148M (CPT) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0403 | 87-A40-291-080 | 0E | DIODE,1N4148M (CPT) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0403 | 87-A40-291-080 | 0E | DIODE,1N4148M (CPT) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0404 | 87-A40-348-080 | | ZENER,MTZJ3.3A | UBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0404 | 87-A40-348-080 | 0E | ZENER,MTZJ3.3A | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | D 0404 | 87-A40-348-080 | 0E | ZENER,MTZJ3.3A | UBM | AV-D77 |
| | X | DOLBY DIGITAL | FB 0102 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | FB 0102 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | FB 0102 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0103 | 87-008-372-080 | | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0103 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0103 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0104 | 87-008-372-080 | | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0104 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0104 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0105 | 87-008-474-080 | | F-BEAD, BL02RN1-R62T2 EMI | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0105 | 87-008-474-080 | 0E | F-BEAD, BL02RN1-R62T2 EMI | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0105 | 87-008-474-080 | 0E | F-BEAD, BL02RN1-R62T2 EMI | UBM | AV-D77 |
| | X | DOLBY DIGITAL | FB 0107 | 88-100-000-090 | | PLATING-JW, | UBM | AV-D77 |
| | X | DOLBY DIGITAL | FB 0107 | 88-100-000-090 | 0E | PLATING-JW, | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | FB 0107 | 88-100-000-090 | 0E | PLATING-JW, | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0108 | 87-008-474-080 | | F-BEAD, BL02RN1-R62T2 EMI | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0108 | 87-008-474-080 | 0E | F-BEAD, BL02RN1-R62T2 EMI | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0108 | 87-008-474-080 | 0E | F-BEAD, BL02RN1-R62T2 EMI | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0110 | 87-008-372-080 | | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0110 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0110 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0111 | 87-008-372-080 | | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0111 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0111 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0112 | 87-005-212-080 | | COIL,220UH K EL0606 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0112 | 87-005-212-080 | 0E | COIL,220UH K EL0606 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | FB 0112 | 87-005-212-080 | 0E | COIL,220UH K EL0606 | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0101 | 87-A21-500-010 | 2D | C-IC,YSS912 | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0101 | 87-A21-500-010 | | C-IC,YSS912 | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0101 | 87-A21-501-010 | 2C | C-IC,YSS902 | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0102 | 87-A21-503-010 | 2P | C-IC,AK4527VQ | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0102 | 87-A21-503-010 | 2P | C-IC,AK4527VQ | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0102 | 87-A21-503-010 | | C-IC,AK4527VQ | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0103 | 87-020-903-010 | | IC,NJM7805FA | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0103 | 87-020-903-010 | 1B | IC,NJM7805FA | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0103 | 87-020-903-010 | 1B | IC,NJM7805FA | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0104 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0104 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0104 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0105 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0105 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0105 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0106 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0106 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0106 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0107 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0107 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0107 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0108 | 87-020-784-080 | 1B | C-IC,TC4053BF | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0108 | 87-020-784-080 | 1B | C-IC,TC4053BF | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0108 | 87-020-784-080 | | C-IC,TC4053BF | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0109 | 87-020-784-080 | 1B | C-IC,TC4053BF | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0109 | 87-020-784-080 | 1B | C-IC,TC4053BF | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0109 | 87-020-784-080 | | C-IC,TC4053BF | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0110 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0110 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0110 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0111 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0111 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| O | S | DOLBY DIGITAL | IC 0111 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0112 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0112 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0112 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0113 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0113 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0113 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0115 | 87-A21-504-010 | | IC,GP1F37R1 | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0115 | 87-A21-504-010 | 2A | IC,GP1F37R1 | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0115 | 87-A21-504-010 | 2A | IC,GP1F37R1 | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0118 | 87-001-604-080 | 1A | C-IC,TC74HCU04M | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0118 | 87-001-604-080 | 1A | C-IC,TC74HCU04M | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0118 | 87-001-604-080 | | C-IC,TC74HCU04M | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0119 | 87-020-784-080 | 1B | C-IC,TC4053BF | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0119 | 87-020-784-080 | 1B | C-IC,TC4053BF | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0119 | 87-020-784-080 | | C-IC,TC4053BF | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0120 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0120 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0120 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0121 | 87-002-298-080 | 1A | C-IC,TC74HC00AF | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0121 | 87-002-298-080 | 1A | C-IC,TC74HC00AF | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0121 | 87-002-298-080 | | C-IC,TC74HC00AF | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0122 | 87-A21-504-010 | | IC,GP1F37R1 | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0122 | 87-A21-504-010 | 2A | IC,GP1F37R1 | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0122 | 87-A21-504-010 | 2A | IC,GP1F37R1 | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0124 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0124 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0124 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0125 | 87-A20-736-010 | | IC,BA033ST | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0125 | 87-A20-736-010 | 1B | IC,BA033ST | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0125 | 87-A20-736-010 | 1B | IC,BA033ST | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0126 | 87-A21-499-040 | 1B | C-IC,SN74HC153A | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0126 | 87-A21-499-040 | 1B | C-IC,SN74HC153A | UBM | AV-D77 |
| O | S | DOLBY DIGITAL | IC 0126 | 87-A21-499-040 | | C-IC,SN74HC153A | UBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0127 | 87-A21-502-040 | 2A | C-IC,YSD917 | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | IC 0127 | 87-A21-502-040 | 2A | C-IC,YSD917 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | J 0101 | 87-A61-143-010 | | JACK,PIN 1P ORN GLD | UBM | AV-D77 |
| | O | DOLBY DIGITAL | J 0101 | 87-A61-143-010 | 1A | JACK,PIN 1P ORN GLD | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | J 0101 | 87-A61-143-010 | 1A | JACK,PIN 1P ORN GLD | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0100 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0100 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0100 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0101 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0101 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0101 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0102 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0102 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0102 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0103 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0103 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0103 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0104 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0104 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0104 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0105 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0105 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0105 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0106 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0106 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0106 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0107 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0107 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0107 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0108 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0108 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0108 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0109 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0109 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0109 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0110 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | JR 0110 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0110 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0111 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0111 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0111 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0112 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0112 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0112 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0113 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0113 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0113 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0114 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0114 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0114 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0115 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0115 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0115 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0116 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0116 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0116 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0117 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0117 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0117 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0118 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0118 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0118 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0119 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0119 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0119 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0120 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0120 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0120 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | DOLBY DIGITAL | JR 0121 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | JR 0121 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | JR 0121 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0122 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0122 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0122 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0123 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0123 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0123 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0124 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0124 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0124 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0125 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0125 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0125 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0126 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0126 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0126 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0127 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0127 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0127 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0128 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0128 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0128 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0129 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0129 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0129 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0130 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0130 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0130 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0131 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0131 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0131 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0132 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0132 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0132 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0133 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0133 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | JR 0133 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0134 | 88-128-221-080 | | C-RES, 220-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0134 | 88-128-221-080 | 0E | C-RES, 220-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0134 | 88-128-221-080 | 0E | C-RES, 220-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0135 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0135 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0135 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0136 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0136 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0136 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0137 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0137 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0137 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0138 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0138 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0138 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0139 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0139 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0139 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0140 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0140 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0140 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0141 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0141 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0141 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0142 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0142 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0142 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0143 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0143 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0143 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0144 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0144 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0144 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0145 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0145 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0145 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0146 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0146 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0146 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0147 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0147 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0147 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0148 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0148 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0148 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0149 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0149 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0149 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0150 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0150 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0150 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0151 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0151 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0151 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0153 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0153 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0153 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0154 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0154 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0154 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0155 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0155 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0155 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0156 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0156 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0156 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0157 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0157 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0157 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | JR 0158 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0158 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0158 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0159 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0159 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0159 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0160 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0160 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0160 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0161 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0161 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0161 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0162 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0162 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0162 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0163 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0163 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0163 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0164 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0164 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0164 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0165 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0165 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0165 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0166 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0166 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0166 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0167 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0167 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0167 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0168 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0168 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0168 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0169 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0169 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0169 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0170 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0170 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0170 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0171 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0171 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0171 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0172 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0172 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0172 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0173 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0173 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0173 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0174 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0174 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0174 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0175 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0175 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0175 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0176 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0176 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0176 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0177 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0177 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0177 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0178 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0178 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0178 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0179 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0179 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0179 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0180 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0180 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0180 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0182 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | JR 0182 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0182 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0183 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0183 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | JR 0183 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0102 | 87-A50-095-010 | | COIL,68UH RCR875D | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0102 | 87-A50-095-010 | 1A | COIL,68UH RCR875D | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0102 | 87-A50-095-010 | 1A | COIL,68UH RCR875D | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0103 | 87-005-274-080 | | COIL,68UH K LAL03 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0103 | 87-005-274-080 | 0E | COIL,68UH K LAL03 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0103 | 87-005-274-080 | 0E | COIL,68UH K LAL03 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0104 | 87-008-501-080 | | FLTR, DSS306-55 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0104 | 87-008-501-080 | 0E | FLTR, DSS306-55 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0104 | 87-008-501-080 | 0E | FLTR, DSS306-55 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0106 | 87-008-372-080 | | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0106 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0106 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0107 | 87-008-501-080 | | FLTR, DSS306-55 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0107 | 87-008-501-080 | 0E | FLTR, DSS306-55 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0107 | 87-008-501-080 | 0E | FLTR, DSS306-55 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0108 | 87-008-501-080 | | FLTR, DSS306-55 | UBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0108 | 87-008-501-080 | 0E | FLTR, DSS306-55 | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | L 0108 | 87-008-501-080 | 0E | FLTR, DSS306-55 | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0101 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0101 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0101 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0102 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0103 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0103 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0103 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0105 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0105 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0105 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0107 | 87-A30-074-080 | | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0107 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0107 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0108 | 87-A30-073-080 | | C-TR,RT1N 141C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0108 | 87-A30-073-080 | 0E | C-TR,RT1N 141C | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0108 | 87-A30-073-080 | 0E | C-TR,RT1N 141C | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0109 | 87-A30-086-070 | | C-TR,CSD1306E | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0109 | 87-A30-086-070 | 0E | C-TR,CSD1306E | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0109 | 87-A30-086-070 | 0E | C-TR,CSD1306E | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0110 | 87-A30-086-070 | | C-TR,CSD1306E | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0110 | 87-A30-086-070 | 0E | C-TR,CSD1306E | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0110 | 87-A30-086-070 | 0E | C-TR,CSD1306E | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0111 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0111 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0111 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0112 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0112 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0112 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0404 | 87-026-608-080 | | C-TR,DTC123JK | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0404 | 87-026-608-080 | 0E | C-TR,DTC123JK | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0404 | 87-026-608-080 | 0E | C-TR,DTC123JK | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0405 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0405 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | DOLBY DIGITAL | Q 0405 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0103 | 88-128-331-080 | | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0103 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0103 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0104 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0104 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0104 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0106 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0106 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0106 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0108 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0108 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0108 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0109 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0109 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0109 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0110 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0110 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0110 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0111 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0111 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0111 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0112 | 88-128-101-080 | | C-RES, 100-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0112 | 88-128-101-080 | 0E | C-RES, 100-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0112 | 88-128-101-080 | 0E | C-RES, 100-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0113 | 88-128-101-080 | | C-RES, 100-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0113 | 88-128-101-080 | 0E | C-RES, 100-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0113 | 88-128-101-080 | 0E | C-RES, 100-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0114 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0114 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0114 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0115 | 88-100-000-080 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0115 | 88-100-000-080 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0115 | 88-100-000-080 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0117 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0117 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0117 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0118 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0118 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0118 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0119 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0119 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0119 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0120 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0120 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0120 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0121 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0121 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0121 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0125 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0125 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0125 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0126 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0126 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0126 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0128 | 88-118-271-080 | | C-RES,S 270-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0128 | 88-118-271-080 | 0E | C-RES,S 270-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0128 | 88-118-271-080 | 0E | C-RES,S 270-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0128 | 88-118-271-080 | 0E | C-RES,S 270-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0128 | 88-118-271-080 | 0E | C-RES,S 270-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0129 | 88-121-101-080 | | RES,100-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0129 | 88-121-101-080 | 0E | RES,100-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0129 | 88-121-101-080 | 0E | RES,100-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0130 | 88-118-271-080 | | C-RES,S 270-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0130 | 88-118-271-080 | 0E | C-RES,S 270-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0130 | 88-118-271-080 | 0E | C-RES,S 270-1/10W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | R 0130 | 88-118-271-080 | 0E | C-RES,S 270-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0130 | 88-118-271-080 | 0E | C-RES,S 270-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0131 | 88-121-101-080 | | RES,100-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0131 | 88-121-101-080 | 0E | RES,100-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0131 | 88-121-101-080 | 0E | RES,100-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0133 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0133 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0133 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0137 | 88-118-820-080 | | C-RES,S 82-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0137 | 88-118-820-080 | 0E | C-RES,S 82-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0137 | 88-118-820-080 | 0E | C-RES,S 82-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0138 | 88-118-681-080 | | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0138 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0138 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0139 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0139 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0139 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0139 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0139 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0140 | 88-118-183-080 | | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0140 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0140 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0141 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0141 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0141 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0142 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0142 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0142 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0143 | 88-118-221-080 | | C-RES,S 220-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0143 | 88-118-221-080 | 0E | C-RES,S 220-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0143 | 88-118-221-080 | 0E | C-RES,S 220-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0147 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0147 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0147 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0148 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0148 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0148 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0149 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0149 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0149 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0149 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0149 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0150 | 88-118-392-080 | | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0150 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0150 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0150 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0150 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0151 | 88-118-392-080 | | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0151 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0151 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0151 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0151 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0153 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0153 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0153 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0154 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0154 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0154 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0155 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0155 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0155 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0156 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0156 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0156 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0157 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0157 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0157 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0158 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0158 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0158 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | R 0159 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0159 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0159 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0160 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0160 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0160 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0161 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0161 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0161 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0162 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0162 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0162 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0163 | 88-118-392-080 | | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0163 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0163 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0163 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0163 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0164 | 88-118-392-080 | | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0164 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0164 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0164 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0164 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0165 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0165 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0165 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0166 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0166 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0166 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0167 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0167 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0167 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0168 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0168 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0168 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0171 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0171 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0171 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0172 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0172 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0172 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0173 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0173 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0173 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0173 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0173 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0175 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0175 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0175 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0176 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0176 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0176 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0177 | 88-118-392-080 | | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0177 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0177 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0177 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0177 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0178 | 88-118-392-080 | | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0178 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0178 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0178 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0178 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0179 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0179 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0179 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0180 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0180 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0180 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0181 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0181 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0181 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | R 0182 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0182 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0182 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0185 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0185 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0185 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0186 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0186 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0186 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0187 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0187 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0187 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0187 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0187 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0188 | 88-121-124-080 | | RES,120K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0188 | 88-121-124-080 | 0E | RES,120K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0188 | 88-121-124-080 | 0E | RES,120K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0189 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0189 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0189 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0190 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0190 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0190 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0191 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0191 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0191 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0192 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0192 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0192 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0193 | 88-118-393-080 | | C-RES,S 39K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0193 | 88-118-393-080 | 0E | C-RES,S 39K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0193 | 88-118-393-080 | 0E | C-RES,S 39K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0193 | 88-118-393-080 | 0E | C-RES,S 39K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0193 | 88-118-393-080 | 0E | C-RES,S 39K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0194 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0194 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0194 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0195 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0195 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0195 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0196 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0196 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0196 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0197 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0197 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0197 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0197 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0197 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0198 | 88-128-103-080 | | C-RES, 10K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0198 | 88-128-103-080 | 0E | C-RES, 10K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0198 | 88-128-103-080 | 0E | C-RES, 10K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0199 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0200 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0200 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0200 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0201 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0201 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0201 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0201 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0201 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0202 | 88-121-152-080 | | RES,1.5K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0202 | 88-121-152-080 | 0E | RES,1.5K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0202 | 88-121-152-080 | 0E | RES,1.5K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0203 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0203 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0203 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0204 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0204 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0204 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0205 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | R 0205 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0205 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0206 | 88-121-124-080 | | RES,120K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0206 | 88-121-124-080 | 0E | RES,120K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0206 | 88-121-124-080 | 0E | RES,120K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0207 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0207 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0207 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0208 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0208 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0208 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0209 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0209 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0209 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0210 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0210 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0210 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0211 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0211 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0211 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0212 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0212 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0212 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0213 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0213 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0213 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0214 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0214 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0214 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0215 | 88-128-153-080 | | C-RES, 15K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0215 | 88-128-153-080 | 0E | C-RES, 15K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0215 | 88-128-153-080 | 0E | C-RES, 15K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0216 | 88-128-153-080 | | C-RES, 15K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0216 | 88-128-153-080 | 0E | C-RES, 15K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0216 | 88-128-153-080 | 0E | C-RES, 15K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0217 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0217 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0217 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0218 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0218 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0218 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0218 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0219 | 88-128-152-080 | | C-RES, 1.5K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0219 | 88-128-152-080 | 0E | C-RES, 1.5K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0219 | 88-128-152-080 | 0E | C-RES, 1.5K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0220 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0220 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0220 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0220 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0221 | 88-118-183-080 | | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0221 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0221 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0222 | 88-118-183-080 | | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0222 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0222 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0223 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0223 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0223 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0224 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0224 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0224 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0225 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0225 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0225 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0225 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0225 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0226 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0226 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | R 0226 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0227 | 88-118-183-080 | | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0227 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0227 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0228 | 88-118-183-080 | | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0228 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0228 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0229 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0229 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0229 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0230 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0230 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0230 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0231 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0231 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0231 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0231 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0231 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0233 | 88-118-183-080 | | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0233 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0233 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0234 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0234 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0234 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0235 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0235 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0235 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0236 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0236 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0236 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0237 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0237 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0237 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0238 | 88-118-681-080 | | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0238 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0238 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0239 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0239 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0239 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0240 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0240 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0240 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0243 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0243 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0243 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0244 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0244 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0244 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0245 | 88-118-471-080 | | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0245 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0245 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0245 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0246 | 88-118-333-080 | | C-RES,S 33K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0246 | 88-118-333-080 | 0E | C-RES,S 33K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0246 | 88-118-333-080 | 0E | C-RES,S 33K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0246 | 88-118-333-080 | 0E | C-RES,S 33K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0246 | 88-118-333-080 | 0E | C-RES,S 33K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0267 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0267 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0267 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0268 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0268 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0268 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0269 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0269 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0269 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0270 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0270 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0270 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | R 0271 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0271 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0271 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0272 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0272 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0272 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0272 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0272 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0273 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0273 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0273 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0273 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0273 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0275 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0275 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0275 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0275 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0275 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0276 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0276 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0276 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0276 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0276 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0277 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0277 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0277 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0278 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0278 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0278 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0279 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0279 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0279 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0280 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0280 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0280 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0281 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0281 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0281 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0282 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0282 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0282 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0283 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0283 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0283 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0284 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0284 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0284 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0284 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0284 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0285 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0285 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0285 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0285 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0285 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0286 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0286 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0286 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0287 | 88-118-470-080 | | C-RES,S 47-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0287 | 88-118-470-080 | 0E | C-RES,S 47-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0287 | 88-118-470-080 | 0E | C-RES,S 47-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0287 | 88-118-470-080 | 0E | C-RES,S 47-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0287 | 88-118-470-080 | 0E | C-RES,S 47-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0289 | 88-121-471-080 | | RES,470-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0289 | 88-121-471-080 | 0E | RES,470-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0289 | 88-121-471-080 | 0E | RES,470-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0290 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0290 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0290 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0291 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0291 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | R 0291 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0292 | 88-118-221-080 | | C-RES,S 220-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0292 | 88-118-221-080 | 0E | C-RES,S 220-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0292 | 88-118-221-080 | 0E | C-RES,S 220-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0295 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0295 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0295 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0298 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0298 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0298 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0299 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0299 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0299 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0300 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0300 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0300 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0301 | 88-121-222-080 | | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0301 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0301 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0302 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0302 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0302 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0302 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0302 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0303 | 88-121-222-080 | | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0303 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0303 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0304 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0304 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0304 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0304 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0304 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0305 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0305 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0305 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0310 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0310 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0310 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0310 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0310 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0313 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0313 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0313 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0313 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0313 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0314 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0314 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0314 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0314 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0314 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0315 | 88-121-331-080 | | RES,330-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0315 | 88-121-331-080 | 0E | RES,330-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0315 | 88-121-331-080 | 0E | RES,330-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0316 | 88-121-331-080 | | RES,330-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0316 | 88-121-331-080 | 0E | RES,330-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0316 | 88-121-331-080 | 0E | RES,330-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0317 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0317 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0317 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0317 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0317 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0318 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0318 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0318 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0318 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0318 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0319 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0319 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0319 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0319 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | R 0319 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0320 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0320 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0320 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0320 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0320 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0321 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0321 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0321 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0321 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0321 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0322 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0322 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0322 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0323 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0323 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0323 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0323 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0323 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0324 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0324 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0324 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0333 | 88-118-221-080 | | C-RES,S 220-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0333 | 88-118-221-080 | 0E | C-RES,S 220-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0333 | 88-118-221-080 | 0E | C-RES,S 220-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0378 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0378 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0378 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0379 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0379 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0379 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0380 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0380 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0380 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0381 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0381 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0381 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0382 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0382 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0382 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0383 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0383 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0383 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0384 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0384 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0384 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0385 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0385 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0385 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0386 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0386 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0386 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0386 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0386 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0387 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0387 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0387 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0388 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0388 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0388 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0389 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0389 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0389 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0389 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0389 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0390 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0390 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0390 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0391 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0391 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | DOLBY DIGITAL | R 0391 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0392 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0392 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0392 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0392 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0392 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0393 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0393 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0393 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0393 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0393 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0409 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0409 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0409 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0410 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0410 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0410 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0411 | 88-118-100-080 | | C-RES,S 10-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0411 | 88-118-100-080 | 0E | C-RES,S 10-1/10W J | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | R 0411 | 88-118-100-080 | 0E | C-RES,S 10-1/10W J | UBM | AV-D77 |
| | X | DOLBY DIGITAL | W 0102 | 89-990-073-410 | 0E | WIRE,U24X0-7-5 F | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | W 0102 | 89-990-073-410 | 0E | WIRE,U24X0-7-5 F | UBM | AV-D77 |
| | X | DOLBY DIGITAL | W 0103 | 89-995-123-410 | 0E | WIRE,U24X5-12-5 F | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | W 0103 | 89-995-123-410 | 0E | WIRE,U24X5-12-5 F | UBM | AV-D77 |
| | X | DOLBY DIGITAL | W 0105 | 89-993-103-410 | 0E | WIRE,U24X3 -10-5F | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | W 0105 | 89-993-103-410 | 0E | WIRE,U24X3 -10-5F | UBM | AV-D77 |
| | X | DOLBY DIGITAL | W 0106 | 89-990-073-410 | 0E | WIRE,U24X0-7-5 F | EZBM | AV-D77 |
| | X | DOLBY DIGITAL | W 0106 | 89-990-073-410 | 0E | WIRE,U24X0-7-5 F | UBM | AV-D77 |
| | O | DOLBY DIGITAL | X 0102 | 87-A70-243-010 | | VIB,XTAL 24.576MHZ | UBM | AV-D77 |
| | O | DOLBY DIGITAL | X 0102 | 87-A70-243-010 | 1B | VIB,XTAL 24.576MHZ | EZBM | AV-D77 |
| | O | DOLBY DIGITAL | X 0102 | 87-A70-243-010 | 1B | VIB,XTAL 24.576MHZ | UBM | AV-D77 |
| | X | ELECTRICAL | | 80-XV1-218-010 | | CUSH-S,PWB | UBM | AV-D77 |
| | X | ELECTRICAL | | 80-XV1-218-010 | 0E | CUSH-S,PWB | UBM | AV-D77 |
| | X | ELECTRICAL | | 80-XV1-218-010 | 0E | CUSH-S,PWB | EZBM | AV-D77 |
| | X | ELECTRICAL | | 82-JT1-206-010 | | CLOTH,15-50-0.5 | UBM | AV-D77 |
| ! | X | ELECTRICAL | | 82-JT1-206-010 | 0E | CLOTH,15-50-0.5 | EZBM | AV-D77 |
| ! | X | ELECTRICAL | | 82-JT1-206-010 | 0E | CLOTH,15-50-0.5 | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-003-317-010 | | F-BEAD,15-25-15 E2515MRT | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-003-317-010 | 1C | F-BEAD,15-25-15 E2515MRT | EZBM | AV-D77 |
| | O | ELECTRICAL | | 87-003-317-010 | 1C | F-BEAD,15-25-15 E2515MRT | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-119-080 | | CAP,TC U 100P-50 K B UP050 | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-131-080 | | CAP,TC U 1000P-50 K B UP050 | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-132-080 | | CAP,TC U 2200P-16 N X UP050 | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-132-080 | 0E | CAP,TC U 2200P-16 N X UP050 | EZBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-132-080 | 0E | CAP,TC U 2200P-16 N X UP050 | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-203-080 | | CAP,TC U 8200P-16 N Y UP050 | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-203-080 | 0E | CAP,TC U 8200P-16 N Y UP050 | EZBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-203-080 | 0E | CAP,TC U 8200P-16 N Y UP050 | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-209-080 | | CAP,TC U 0.1-50 Z F UP050 | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-209-080 | 0E | CAP,TC U 0.1-50 Z F UP050 | EZBM | AV-D77 |
| | O | ELECTRICAL | | 87-018-209-080 | 0E | CAP,TC U 0.1-50 Z F UP050 | UBM | AV-D77 |
| | S | ELECTRICAL | | 87-035-489-010 | | FUSE,4A 125V T 237 | UBM | AV-D77 |
| ! | S | ELECTRICAL | | 87-035-489-010 | 1A | FUSE,4A 125V T 237 | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-069-033-010 | | CABLE,TIE | UBM | AV-D77 |
| ! | X | ELECTRICAL | | 87-069-033-010 | 0E | CABLE,TIE | EZBM | AV-D77 |
| ! | X | ELECTRICAL | | 87-069-033-010 | 0E | CABLE,TIE | EZBM | AV-D77 |
| ! | X | ELECTRICAL | | 87-069-033-010 | 0E | CABLE,TIE | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-069-036-010 | | CABLE,TIE 146(N) | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-069-036-010 | 0E | CABLE,TIE 146(N) | EZBM | AV-D77 |
| | X | ELECTRICAL | | 87-069-036-010 | 0E | CABLE,TIE 146(N) | UBM | AV-D77 |
| ! | O | ELECTRICAL | | 87-085-185-010 | 0E | BUSHING,AC CORD(E) CM-22B | EZBM | AV-D77 |
| | O | ELECTRICAL | | 87-085-189-010 | | BUSHING,AC CORD(U) CM-22C | UBM | AV-D77 |
| ! | O | ELECTRICAL | | 87-085-189-010 | 0E | BUSHING,AC CORD(U) CM-22C | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-098-266-010 | | LBL,FUSE 4A | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-098-335-010 | | LBL,REPLACEMENT | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-098-335-010 | 0E | LBL,REPLACEMENT | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-098-374-010 | | LBL,FUSE 10A 125V | UBM | AV-D77 |
| ! | X | ELECTRICAL | | 87-098-374-010 | 0E | LBL,FUSE 10A 125V | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-098-381-010 | | LBL,FUSE 7A 125V | UBM | AV-D77 |
| ! | X | ELECTRICAL | | 87-098-381-010 | 0E | LBL,FUSE 7A 125V | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | ELECTRICAL | | 87-450-414-010 | 0E | TERMINAL,LB 4 NI | EZBM | AV-D77 |
| | X | ELECTRICAL | | 87-839-301-010 | | TUBE,UL 3-10 | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-839-301-510 | | TUBE,UL 3-15 | UBM | AV-D77 |
| ! | X | ELECTRICAL | | 87-839-301-510 | 0E | TUBE,UL 3-15 | EZBM | AV-D77 |
| ! | X | ELECTRICAL | | 87-839-301-510 | 0E | TUBE,UL 3-15 | EZBM | AV-D77 |
| ! | X | ELECTRICAL | | 87-839-301-510 | 0E | TUBE,UL 3-15 | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-839-303-010 | | TUBE,UL 3-30 | UBM | AV-D77 |
| ! | X | ELECTRICAL | | 87-839-303-010 | 0E | TUBE,UL 3-30 | EZBM | AV-D77 |
| ! | X | ELECTRICAL | | 87-839-303-010 | 0E | TUBE,UL 3-30 | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-A10-207-080 | | CAP,TC U 0.01-50 K B UP050 | UBM | AV-D77 |
| | O | ELECTRICAL | | 87-A10-207-080 | 0E | CAP,TC U 0.01-50 K B UP050 | EZBM | AV-D77 |
| | O | ELECTRICAL | | 87-A10-207-080 | 0E | CAP,TC U 0.01-50 K B UP050 | EZBM | AV-D77 |
| ! | O | ELECTRICAL | | 87-A80-092-010 | 1C | AC CORD ASSY,E BLK SUN FAI | EZBM | AV-D77 |
| | O | ELECTRICAL | | 87-A80-110-010 | | AC CORD ASSY,U SPT-2W | UBM | AV-D77 |
| ! | O | ELECTRICAL | | 87-A80-110-010 | 1B | AC CORD ASSY,U SPT-2W | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-A80-159-010 | | WIRE,4-1007 AWG18 | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-A90-243-010 | 0E | LBL,FUSE T6.3A L | EZBM | AV-D77 |
| | X | ELECTRICAL | | 87-A91-278-010 | | LBL,FUSE 125MA 125V | UBM | AV-D77 |
| | X | ELECTRICAL | | 87-A91-278-010 | 0E | LBL,FUSE 125MA 125V | UBM | AV-D77 |
| | X | ELECTRICAL | | 88-121-103-080 | | RES,10K-1/8W J | UBM | AV-D77 |
| | X | ELECTRICAL | | 88-121-224-080 | | RES,220K-1/8W J | UBM | AV-D77 |
| | O | ELECTRICAL | | 88-904-121-110 | | FF-CABLE,4P 1.25 120MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 88-904-121-110 | 0E | FF-CABLE,4P 1.25 120MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 88-904-181-110 | 0E | FF-CABLE,4P 1.25 | EZBM | AV-D77 |
| | O | ELECTRICAL | | 88-907-401-110 | | FF-CABLE, 7P 1.25 400MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 88-907-401-110 | 0E | FF-CABLE, 7P 1.25 400MM | EZBM | AV-D77 |
| | O | ELECTRICAL | | 88-907-401-110 | 0E | FF-CABLE, 7P 1.25 400MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 88-908-101-110 | | FF-CABLE, 8P 1.25 100MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 88-908-101-110 | 0E | FF-CABLE, 8P 1.25 100MM | EZBM | AV-D77 |
| | O | ELECTRICAL | | 88-908-101-110 | 0E | FF-CABLE, 8P 1.25 100MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 88-912-101-110 | | FF-CABLE, 12P 1.25 100MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 88-912-101-110 | 0E | FF-CABLE, 12P 1.25 100MM | EZBM | AV-D77 |
| | O | ELECTRICAL | | 88-912-101-110 | 0E | FF-CABLE, 12P 1.25 100MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 88-912-161-110 | | FF-CABLE,12P 1.25 160MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 88-912-161-110 | 0E | FF-CABLE,12P 1.25 160MM | EZBM | AV-D77 |
| | O | ELECTRICAL | | 88-912-161-110 | 0E | FF-CABLE,12P 1.25 160MM | UBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-031-110 | | WIRE,U24X5-3-3 | UBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-031-110 | 0E | WIRE,U24X5-3-3 | EZBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-031-110 | 0E | WIRE,U24X5-3-3 | UBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-051-110 | | WIRE,U24X5-5-3/3 | UBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-051-110 | 0E | WIRE,U24X5-5-3/3 | EZBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-051-110 | 0E | WIRE,U24X5-5-3/3 | UBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-071-110 | | WIRE,U24X5-7-3 | UBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-101-110 | | WIRE,U24X5-10-3 | UBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-101-110 | | WIRE,U24X5-10-3 | UBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-101-110 | 0E | WIRE,U24X5-10-3 | EZBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-101-110 | 0E | WIRE,U24X5-10-3 | UBM | AV-D77 |
| | | ELECTRICAL | | 89-995-141-110 | | WIRE,U24X5-14-3 | UBM | AV-D77 |
| | X | ELECTRICAL | | 89-995-141-110 | 0E | WIRE,U24X5-14-3 | UBM | AV-D77 |
| | X | ELECTRICAL | | 8A-AR1-646-010 | | TUBE,UL 22-90 BLK | UBM | AV-D77 |
| | X | ELECTRICAL | | 8A-AR1-646-010 | 1A | TUBE,UL 22-90 BLK | EZBM | AV-D77 |
| | X | ELECTRICAL | | 8A-AR1-646-010 | 1A | TUBE,UL 22-90 BLK | UBM | AV-D77 |
| | O | ELECTRICAL | | 8A-AR2-645-010 | | FF-CABLE,14P 1.25 380MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 8A-AR2-645-010 | 1A | FF-CABLE,14P 1.25 380MM | EZBM | AV-D77 |
| | O | ELECTRICAL | | 8A-AR2-645-010 | 1A | FF-CABLE,14P 1.25 380MM | UBM | AV-D77 |
| | X | ELECTRICAL | | 8A-AR3-205-110 | | PLATE,SUB PT U | UBM | AV-D77 |
| | X | ELECTRICAL | | 8A-AR3-205-110 | 1C | PLATE,SUB PT U | UBM | AV-D77 |
| | O | ELECTRICAL | | 8A-AR3-643-010 | | FF-CABLE,32P 1.25 430MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 8A-AR3-643-010 | 1D | FF-CABLE,32P 1.25 430MM | UBM | AV-D77 |
| | O | ELECTRICAL | | 8A-AR3-644-010 | 1D | FF-CABLE,35P 1.25 430MM | EZBM | AV-D77 |
| | X | ELECTRICAL | | 8Z-AR2-609-010 | | TUBE,UL 11.1-80 | UBM | AV-D77 |
| | X | ELECTRICAL | | 8Z-AR2-609-010 | 0E | TUBE,UL 11.1-80 | EZBM | AV-D77 |
| | X | ELECTRICAL | | 8Z-AR2-609-010 | 0E | TUBE,UL 11.1-80 | UBM | AV-D77 |
| | X | ELECTRICAL | | A8-AZA-893-030 | | AZA-8 ULHM1 | UBM | AV-D77 |
| | X | ELECTRICAL | | A8-AZA-893-030 | -- | AZA-8 ULHM1 | UBM | AV-D77 |
| | X | ELECTRICAL | | A8-AZA-895-030 | -- | AZA-8 EZM1 | EZBM | AV-D77 |
| | O | ELECTRICAL | C 0001 | 87-018-209-080 | | CAP,TC U 0.1-50 Z F UP050 | UBM | AV-D77 |
| | O | ELECTRICAL | C 0001 | 87-018-209-080 | 0E | CAP,TC U 0.1-50 Z F UP050 | UBM | AV-D77 |
| | O | ELECTRICAL | C 0233 | 87-A12-314-080 | | CAP,CER 47P-500 J SL | UBM | AV-D77 |
| | O | ELECTRICAL | C 0234 | 87-A12-314-080 | | CAP,CER 47P-500 J SL | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | ELECTRICAL | C 0336 | 87-A12-314-080 | | CAP,CER 47P-500 J SL | UBM | AV-D77 |
| | O | ELECTRICAL | C 0421 | 87-A12-314-080 | | CAP,CER 47P-500 J SL | UBM | AV-D77 |
| | O | ELECTRICAL | C 0422 | 87-A12-314-080 | | CAP,CER 47P-500 J SL | UBM | AV-D77 |
| | X | ELECTRICAL | C 0803 | 88-214-810-810 | | CAP,CER 0.01-50 M Y | UBM | AV-D77 |
| | X | ELECTRICAL | C 0803 | 88-214-810-810 | 0E | CAP,CER 0.01-50 M Y | UBM | AV-D77 |
| | O | ELECTRICAL | C 0847 | 87-015-699-040 | | CAP,E 10-50 M 7L SRA | UBM | AV-D77 |
| | O | ELECTRICAL | C 0848 | 87-010-405-040 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| ! | S | ELECTRICAL | F 0101 | 87-035-370-010 | 1A | FUSE,6.3A 250V T | EZBM | AV-D77 |
| | S | ELECTRICAL | F 0101 | 87-035-494-010 | | FUSE,10A 125V T 237 | UBM | AV-D77 |
| ! | S | ELECTRICAL | F 0101 | 87-035-494-010 | 0E | FUSE,10A 125V T 237 | UBM | AV-D77 |
| | S | ELECTRICAL | IC 0127 | 87-A21-502-010 | | C-IC,YSD917 | UBM | AV-D77 |
| | O | ELECTRICAL | PT 0002 | 8Z-NF8-661-010 | | PT,SUB ZNF-8(U) | UBM | AV-D77 |
| ! | O | ELECTRICAL | PT 0002 | 8Z-NF8-661-010 | 1D | PT,SUB ZNF-8(U) | UBM | AV-D77 |
| | O | ELECTRICAL | PT 0101 | 8A-AR1-605-010 | | PT,AAR-1(U) | UBM | AV-D77 |
| | O | ELECTRICAL | PT 0101 | 8A-AR1-605-010 | 2D | PT,AAR-1(U) | UBM | AV-D77 |
| ! | O | ELECTRICAL | PT 0101 | 8A-AR1-609-010 | 2D | PT,AAR-1EZ (KAMI) | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0213 | 87-A30-097-010 | | TR,FN1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0213 | 87-A30-097-010 | 1C | TR,FN1016 | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0213 | 87-A30-097-010 | 1C | TR,FN1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0214 | 87-A30-097-010 | | TR,FN1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0214 | 87-A30-097-010 | 1C | TR,FN1016 | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0214 | 87-A30-097-010 | 1C | TR,FN1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0215 | 87-A30-098-010 | | TR,FP1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0215 | 87-A30-098-010 | 1C | TR,FP1016 | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0215 | 87-A30-098-010 | 1C | TR,FP1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0216 | 87-A30-098-010 | | TR,FP1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0216 | 87-A30-098-010 | 1C | TR,FP1016 | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0216 | 87-A30-098-010 | 1C | TR,FP1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0313 | 87-A30-097-010 | | TR,FN1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0313 | 87-A30-097-010 | 1C | TR,FN1016 | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0313 | 87-A30-097-010 | 1C | TR,FN1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0314 | 87-A30-097-010 | | TR,FN1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0314 | 87-A30-097-010 | 1C | TR,FN1016 | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0314 | 87-A30-097-010 | 1C | TR,FN1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0315 | 87-A30-098-010 | | TR,FP1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0315 | 87-A30-098-010 | 1C | TR,FP1016 | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0315 | 87-A30-098-010 | 1C | TR,FP1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0316 | 87-A30-098-010 | | TR,FP1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0316 | 87-A30-098-010 | 1C | TR,FP1016 | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0316 | 87-A30-098-010 | 1C | TR,FP1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0407 | 87-A30-097-010 | | TR,FN1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0407 | 87-A30-097-010 | 1C | TR,FN1016 | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0407 | 87-A30-097-010 | 1C | TR,FN1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0408 | 87-A30-098-010 | | TR,FP1016 | UBM | AV-D77 |
| | S | ELECTRICAL | Q 0408 | 87-A30-098-010 | 1C | TR,FP1016 | EZBM | AV-D77 |
| | S | ELECTRICAL | Q 0408 | 87-A30-098-010 | 1C | TR,FP1016 | UBM | AV-D77 |
| | X | ELECTRICAL | R 0412 | 88-121-104-080 | 0E | RES,100K-1/8W J | EZBM | AV-D77 |
| | X | ELECTRICAL | R 0412 | 88-121-104-080 | 0E | RES,100K-1/8W J | UBM | AV-D77 |
| | X | ELECTRICAL | R 0413 | 88-121-104-080 | 0E | RES,100K-1/8W J | EZBM | AV-D77 |
| | X | ELECTRICAL | R 0413 | 88-121-104-080 | 0E | RES,100K-1/8W J | UBM | AV-D77 |
| | X | ELECTRICAL | R 0414 | 88-121-104-080 | 0E | RES,100K-1/8W J | EZBM | AV-D77 |
| | X | ELECTRICAL | R 0414 | 88-121-104-080 | 0E | RES,100K-1/8W J | UBM | AV-D77 |
| | X | ELECTRICAL | R 0712 | 88-121-683-080 | | RES,68K-1/8W J | UBM | AV-D77 |
| | X | ELECTRICAL | W 0102 | 89-995-061-110 | | WIRE,U24X5-6-3/3 | UBM | AV-D77 |
| | O | FRCB MECHA | | 8A-AR3-201-010 | | GUIDE,FL | UBM | AV-D77 |
| | O | FRCB MECHA | | 8A-AR3-201-010 | 0E | GUIDE,FL | EZBM | AV-D77 |
| | O | FRCB MECHA | | 8A-AR3-201-010 | 0E | GUIDE,FL | UBM | AV-D77 |
| | O | FUNCTION | C 0501 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0501 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0501 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0502 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0502 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0502 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0503 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0503 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | FUNCTION | C 0503 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0504 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0504 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | FUNCTION | C 0504 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | X | FUNCTION | C 0505 | 88-700-860-810 | | CAP,M 0.068-50 J AMZV | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | FUNCTION | C 0505 | 88-700-860-810 | 0E | CAP,M 0.068-50 J AMZV | EZBM | AV-D77 |
| | X | FUNCTION | C 0505 | 88-700-860-810 | 0E | CAP,M 0.068-50 J AMZV | UBM | AV-D77 |
| | X | FUNCTION | C 0506 | 88-700-860-810 | | CAP,M 0.068-50 J AMZV | UBM | AV-D77 |
| | X | FUNCTION | C 0506 | 88-700-860-810 | 0E | CAP,M 0.068-50 J AMZV | EZBM | AV-D77 |
| | X | FUNCTION | C 0506 | 88-700-860-810 | 0E | CAP,M 0.068-50 J AMZV | UBM | AV-D77 |
| | X | FUNCTION | C 0507 | 88-700-629-810 | | CAP,M 1200P-50 J | UBM | AV-D77 |
| | X | FUNCTION | C 0507 | 88-700-629-810 | 0E | CAP,M 1200P-50 J | EZBM | AV-D77 |
| | X | FUNCTION | C 0507 | 88-700-629-810 | 0E | CAP,M 1200P-50 J | UBM | AV-D77 |
| | X | FUNCTION | C 0508 | 88-700-629-810 | | CAP,M 1200P-50 J | UBM | AV-D77 |
| | X | FUNCTION | C 0508 | 88-700-629-810 | 0E | CAP,M 1200P-50 J | EZBM | AV-D77 |
| | X | FUNCTION | C 0508 | 88-700-629-810 | 0E | CAP,M 1200P-50 J | UBM | AV-D77 |
| | X | FUNCTION | C 0509 | 88-700-889-810 | | CAP,M 0.018-50 J | UBM | AV-D77 |
| | X | FUNCTION | C 0509 | 88-700-889-810 | 0E | CAP,M 0.018-50 J | EZBM | AV-D77 |
| | X | FUNCTION | C 0509 | 88-700-889-810 | 0E | CAP,M 0.018-50 J | UBM | AV-D77 |
| | X | FUNCTION | C 0510 | 88-700-889-810 | | CAP,M 0.018-50 J | UBM | AV-D77 |
| | X | FUNCTION | C 0510 | 88-700-889-810 | 0E | CAP,M 0.018-50 J | EZBM | AV-D77 |
| | X | FUNCTION | C 0510 | 88-700-889-810 | 0E | CAP,M 0.018-50 J | UBM | AV-D77 |
| | O | FUNCTION | C 0511 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0511 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0511 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0512 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0512 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0512 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0513 | 87-010-260-080 | | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0513 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0513 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0514 | 87-010-260-080 | | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0514 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0514 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0515 | 87-010-370-080 | | CAP,E 330-6.3 M SME | UBM | AV-D77 |
| | O | FUNCTION | C 0515 | 87-010-370-080 | 0E | CAP,E 330-6.3 M SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0515 | 87-010-370-080 | 0E | CAP,E 330-6.3 M SME | UBM | AV-D77 |
| | O | FUNCTION | C 0516 | 87-010-370-080 | | CAP,E 330-6.3 M SME | UBM | AV-D77 |
| | O | FUNCTION | C 0516 | 87-010-370-080 | 0E | CAP,E 330-6.3 M SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0516 | 87-010-370-080 | 0E | CAP,E 330-6.3 M SME | UBM | AV-D77 |
| | O | FUNCTION | C 0517 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | FUNCTION | C 0517 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | FUNCTION | C 0517 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | FUNCTION | C 0518 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | FUNCTION | C 0518 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | FUNCTION | C 0518 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | FUNCTION | C 0519 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | FUNCTION | C 0519 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | FUNCTION | C 0519 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | FUNCTION | C 0520 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | FUNCTION | C 0520 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | FUNCTION | C 0520 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | FUNCTION | C 0531 | 87-010-213-080 | | C-CAP,S 0.015-25 K B GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0531 | 87-010-213-080 | 0E | C-CAP,S 0.015-25 K B GRM | EZBM | AV-D77 |
| | O | FUNCTION | C 0531 | 87-010-213-080 | 0E | C-CAP,S 0.015-25 K B GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0532 | 87-010-992-080 | | C-CAP,S 0.047-25 K B MK212 | UBM | AV-D77 |
| | O | FUNCTION | C 0532 | 87-010-992-080 | 0E | C-CAP,S 0.047-25 K B MK212 | EZBM | AV-D77 |
| | O | FUNCTION | C 0532 | 87-010-992-080 | 0E | C-CAP,S 0.047-25 K B MK212 | UBM | AV-D77 |
| | O | FUNCTION | C 0533 | 87-015-785-080 | | C-CAP, 0.1-25 Z F C3216 | UBM | AV-D77 |
| | O | FUNCTION | C 0533 | 87-015-785-080 | 0E | C-CAP, 0.1-25 Z F C3216 | EZBM | AV-D77 |
| | O | FUNCTION | C 0533 | 87-015-785-080 | 0E | C-CAP, 0.1-25 Z F C3216 | UBM | AV-D77 |
| | O | FUNCTION | C 0535 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0535 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0535 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0536 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0536 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0536 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | X | FUNCTION | C 0537 | 88-710-919-810 | | CAP,M 0.1-50 J TFL | UBM | AV-D77 |
| | X | FUNCTION | C 0537 | 88-710-919-810 | 0E | CAP,M 0.1-50 J TFL | EZBM | AV-D77 |
| | X | FUNCTION | C 0537 | 88-710-919-810 | 0E | CAP,M 0.1-50 J TFL | UBM | AV-D77 |
| | X | FUNCTION | C 0538 | 88-710-919-810 | | CAP,M 0.1-50 J TFL | UBM | AV-D77 |
| | X | FUNCTION | C 0538 | 88-710-919-810 | 0E | CAP,M 0.1-50 J TFL | EZBM | AV-D77 |
| | X | FUNCTION | C 0538 | 88-710-919-810 | 0E | CAP,M 0.1-50 J TFL | UBM | AV-D77 |
| | O | FUNCTION | C 0539 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0539 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | FUNCTION | C 0539 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0540 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0540 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0540 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0541 | 87-010-185-080 | | C-CAP,S 3900P-50 K B | UBM | AV-D77 |
| | O | FUNCTION | C 0541 | 87-010-185-080 | 0E | C-CAP,S 3900P-50 K B | EZBM | AV-D77 |
| | O | FUNCTION | C 0541 | 87-010-185-080 | 0E | C-CAP,S 3900P-50 K B | UBM | AV-D77 |
| | O | FUNCTION | C 0542 | 87-010-185-080 | | C-CAP,S 3900P-50 K B | UBM | AV-D77 |
| | O | FUNCTION | C 0542 | 87-010-185-080 | 0E | C-CAP,S 3900P-50 K B | EZBM | AV-D77 |
| | O | FUNCTION | C 0542 | 87-010-185-080 | 0E | C-CAP,S 3900P-50 K B | UBM | AV-D77 |
| | X | FUNCTION | C 0543 | 88-710-969-810 | | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | X | FUNCTION | C 0543 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | EZBM | AV-D77 |
| | X | FUNCTION | C 0543 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | X | FUNCTION | C 0544 | 88-710-969-810 | | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | X | FUNCTION | C 0544 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | EZBM | AV-D77 |
| | X | FUNCTION | C 0544 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | X | FUNCTION | C 0545 | 88-710-989-810 | | CAP,M 0.056-50 J TFL | UBM | AV-D77 |
| | X | FUNCTION | C 0545 | 88-710-989-810 | 0E | CAP,M 0.056-50 J TFL | EZBM | AV-D77 |
| | X | FUNCTION | C 0545 | 88-710-989-810 | 0E | CAP,M 0.056-50 J TFL | UBM | AV-D77 |
| | X | FUNCTION | C 0546 | 88-710-989-810 | | CAP,M 0.056-50 J TFL | UBM | AV-D77 |
| | X | FUNCTION | C 0546 | 88-710-989-810 | 0E | CAP,M 0.056-50 J TFL | EZBM | AV-D77 |
| | X | FUNCTION | C 0546 | 88-710-989-810 | 0E | CAP,M 0.056-50 J TFL | UBM | AV-D77 |
| | O | FUNCTION | C 0547 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0547 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0547 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0549 | 87-016-081-080 | | C-CAP,S 0.1-16 K R GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0549 | 87-016-081-080 | 0E | C-CAP,S 0.1-16 K R GRM | EZBM | AV-D77 |
| | O | FUNCTION | C 0549 | 87-016-081-080 | 0E | C-CAP,S 0.1-16 K R GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0550 | 87-016-081-080 | | C-CAP,S 0.1-16 K R GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0550 | 87-016-081-080 | 0E | C-CAP,S 0.1-16 K R GRM | EZBM | AV-D77 |
| | O | FUNCTION | C 0550 | 87-016-081-080 | 0E | C-CAP,S 0.1-16 K R GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0554 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | FUNCTION | C 0554 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | FUNCTION | C 0554 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | FUNCTION | C 0555 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0555 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0555 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0556 | 87-010-248-080 | | CAP,E 220-10 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0556 | 87-010-248-080 | 0E | CAP,E 220-10 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0556 | 87-010-248-080 | 0E | CAP,E 220-10 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0557 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0557 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0557 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0559 | 87-010-183-080 | | C-CAP,S 2700P-50 K B GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0559 | 87-010-183-080 | 0E | C-CAP,S 2700P-50 K B GRM | EZBM | AV-D77 |
| | O | FUNCTION | C 0559 | 87-010-183-080 | 0E | C-CAP,S 2700P-50 K B GRM | UBM | AV-D77 |
| | O | FUNCTION | C 0561 | 87-012-140-080 | | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | FUNCTION | C 0561 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | EZBM | AV-D77 |
| | O | FUNCTION | C 0561 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | FUNCTION | C 0562 | 87-012-140-080 | | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | FUNCTION | C 0562 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | EZBM | AV-D77 |
| | O | FUNCTION | C 0562 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | FUNCTION | C 0565 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0565 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0565 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0566 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | C 0566 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | FUNCTION | C 0566 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | FUNCTION | CN 0501 | 87-A60-039-010 | | CONN,32P V 9604S-32C | UBM | AV-D77 |
| ! | O | FUNCTION | CN 0501 | 87-A60-039-010 | 1A | CONN,32P V 9604S-32C | UBM | AV-D77 |
| | O | FUNCTION | CN 0501 | 87-A60-553-010 | 0E | CONN,35P V 9604S-35C | EZBM | AV-D77 |
| | O | FUNCTION | CN 0502 | 87-A60-054-010 | | CONN,14P V 9604S-14C | UBM | AV-D77 |
| ! | O | FUNCTION | CN 0502 | 87-A60-054-010 | 0E | CONN,14P V 9604S-14C | EZBM | AV-D77 |
| ! | O | FUNCTION | CN 0502 | 87-A60-054-010 | 0E | CONN,14P V 9604S-14C | UBM | AV-D77 |
| | O | FUNCTION | CN 0503 | 87-A60-056-010 | | CONN,12P V 9604S-12C | UBM | AV-D77 |
| ! | O | FUNCTION | CN 0503 | 87-A60-056-010 | 0E | CONN,12P V 9604S-12C | EZBM | AV-D77 |
| ! | O | FUNCTION | CN 0503 | 87-A60-056-010 | 0E | CONN,12P V 9604S-12C | UBM | AV-D77 |
| | O | FUNCTION | CN 0506 | 87-A60-063-010 | 0E | CONN,04P V 9604S-04C | EZBM | AV-D77 |
| | O | FUNCTION | CN 0702 | 87-099-668-010 | | CONN,9P TUC-P 9P-B1 | UBM | AV-D77 |
| | O | FUNCTION | CN 0702 | 87-099-668-010 | 0E | CONN,9P TUC-P 9P-B1 | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | FUNCTION | CN 0702 | 87-099-668-010 | 0E | CONN,9P TUC-P 9P-B1 | UBM | AV-D77 |
| | O | FUNCTION | CN 0901 | 87-A60-619-010 | | CONN,2P V 2MM JMT | UBM | AV-D77 |
| | O | FUNCTION | CN 0901 | 87-A60-619-010 | 0E | CONN,2P V 2MM JMT | EZBM | AV-D77 |
| | O | FUNCTION | CN 0901 | 87-A60-619-010 | 0E | CONN,2P V 2MM JMT | UBM | AV-D77 |
| | S | FUNCTION | D 0501 | 87-A40-438-080 | | ZENER,MTZJ4.7A | UBM | AV-D77 |
| | S | FUNCTION | D 0501 | 87-A40-438-080 | 0E | ZENER,MTZJ4.7A | EZBM | AV-D77 |
| | S | FUNCTION | D 0501 | 87-A40-438-080 | 0E | ZENER,MTZJ4.7A | UBM | AV-D77 |
| | S | FUNCTION | D 0502 | 87-A40-438-080 | | ZENER,MTZJ4.7A | UBM | AV-D77 |
| | S | FUNCTION | D 0502 | 87-A40-438-080 | 0E | ZENER,MTZJ4.7A | EZBM | AV-D77 |
| | S | FUNCTION | D 0502 | 87-A40-438-080 | 0E | ZENER,MTZJ4.7A | UBM | AV-D77 |
| | S | FUNCTION | D 0503 | 87-070-274-080 | | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | FUNCTION | D 0503 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | EZBM | AV-D77 |
| | S | FUNCTION | D 0503 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | UBM | AV-D77 |
| | X | FUNCTION | D 0504 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | FUNCTION | D 0504 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | FUNCTION | D 0504 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | S | FUNCTION | IC 0501 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | EZBM | AV-D77 |
| | S | FUNCTION | IC 0501 | 87-017-022-080 | 1A | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| O | S | FUNCTION | IC 0501 | 87-017-022-080 | | C-IC,NJM2068M-D(T1) | UBM | AV-D77 |
| | S | FUNCTION | IC 0502 | 87-017-726-080 | 1B | C-IC,BU4052BCF | EZBM | AV-D77 |
| | S | FUNCTION | IC 0502 | 87-017-726-080 | 1B | C-IC,BU4052BCF | UBM | AV-D77 |
| O | S | FUNCTION | IC 0502 | 87-017-726-080 | | C-IC,BU4052BCF | UBM | AV-D77 |
| | S | FUNCTION | IC 0503 | 87-A21-202-040 | 1H | C-IC,M62445AFP | EZBM | AV-D77 |
| | S | FUNCTION | IC 0503 | 87-A21-202-040 | 1H | C-IC,M62445AFP | UBM | AV-D77 |
| O | S | FUNCTION | IC 0503 | 87-A21-202-040 | | C-IC,M62445AFP | UBM | AV-D77 |
| | O | FUNCTION | J 0501 | 87-A60-947-010 | | JACK,PIN 4P W/R GLD | UBM | AV-D77 |
| | O | FUNCTION | J 0501 | 87-A60-947-010 | 1C | JACK,PIN 4P W/R GLD | EZBM | AV-D77 |
| | O | FUNCTION | J 0501 | 87-A60-947-010 | 1C | JACK,PIN 4P W/R GLD | UBM | AV-D77 |
| | O | FUNCTION | J 0502 | 87-A60-947-010 | | JACK,PIN 4P W/R GLD | UBM | AV-D77 |
| | O | FUNCTION | J 0502 | 87-A60-947-010 | 1C | JACK,PIN 4P W/R GLD | EZBM | AV-D77 |
| | O | FUNCTION | J 0502 | 87-A60-947-010 | 1C | JACK,PIN 4P W/R GLD | UBM | AV-D77 |
| | X | FUNCTION | JR 0152 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0152 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0152 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0493 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0493 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0493 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0501 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0501 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0501 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0502 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0502 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0502 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0503 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0503 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0503 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0504 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0504 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0504 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0505 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0505 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0505 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0506 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0506 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0506 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0507 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0507 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0507 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0513 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0513 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0513 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0514 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0514 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0514 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0515 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0515 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0515 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0522 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0522 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0522 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | FUNCTION | JR 0523 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0523 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0524 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0524 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0524 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0526 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0526 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0526 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0531 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0531 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0531 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0532 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0532 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0532 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0534 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0534 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0534 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0538 | 88-128-473-080 | | C-RES, 47K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | JR 0538 | 88-128-473-080 | 0E | C-RES, 47K-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | JR 0538 | 88-128-473-080 | 0E | C-RES, 47K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | JR 0539 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0539 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0539 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0540 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0540 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0540 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0541 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0541 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0541 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0542 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0542 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0542 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0543 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0543 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0543 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0544 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0544 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0544 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0553 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0553 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0553 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0554 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0554 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0554 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0555 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0555 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0555 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0556 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0556 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0556 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0557 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0557 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0557 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0560 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0560 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0560 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0561 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0561 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0561 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0562 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0562 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0562 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0563 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0563 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0563 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0564 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0564 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0564 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0565 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0565 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | FUNCTION | JR 0565 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0575 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0575 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0575 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0576 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0576 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0576 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0577 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0577 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0577 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0578 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0578 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0578 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0579 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0579 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0579 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0580 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0580 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0580 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0583 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0583 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0583 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0584 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0584 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0584 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0585 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0585 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0585 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0586 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0586 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0586 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0588 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0588 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0588 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0589 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0589 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0589 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0593 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0593 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0593 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0603 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0603 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0603 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0638 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0638 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0638 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0639 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0639 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0639 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0706 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0706 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0706 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0707 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0707 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0707 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0708 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0708 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0708 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0811 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0811 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0811 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0812 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0812 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0812 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0813 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0813 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | JR 0813 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | JR 0930 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0930 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0930 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | FUNCTION | JR 0931 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0931 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0931 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0932 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0932 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0932 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0933 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | JR 0933 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | JR 0933 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | R 0501 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0501 | 88-118-330-080 | | C-RES,S 33-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0501 | 88-118-330-080 | 0E | C-RES,S 33-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0502 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0502 | 88-118-330-080 | | C-RES,S 33-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0502 | 88-118-330-080 | 0E | C-RES,S 33-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0503 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0503 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0503 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0504 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0504 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0504 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0505 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0505 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0505 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0506 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0506 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0506 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0507 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0507 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0507 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0508 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0508 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0508 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0509 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0509 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0509 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0510 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0510 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0510 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0511 | 88-118-392-080 | | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0511 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0511 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0512 | 88-118-392-080 | | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0512 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0512 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0513 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0513 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0513 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0514 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0514 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0514 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0515 | 88-128-221-080 | | C-RES, 220-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0515 | 88-128-221-080 | 0E | C-RES, 220-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0515 | 88-128-221-080 | 0E | C-RES, 220-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0516 | 88-128-221-080 | | C-RES, 220-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0516 | 88-128-221-080 | 0E | C-RES, 220-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0516 | 88-128-221-080 | 0E | C-RES, 220-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0517 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0517 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0517 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0518 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0518 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0518 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0519 | 88-118-332-080 | | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0519 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0519 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0520 | 88-118-332-080 | | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0520 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0520 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0521 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | FUNCTION | R 0521 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | R 0521 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | R 0522 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | R 0522 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | R 0522 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | R 0523 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0523 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0523 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0524 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0524 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0524 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0529 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0529 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0529 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0530 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0530 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0530 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0531 | 88-118-183-080 | | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0531 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0531 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0532 | 88-118-183-080 | | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0532 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0532 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0533 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0533 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0533 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0534 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0534 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0534 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0535 | 88-121-392-080 | | RES,3.9K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0535 | 88-121-392-080 | 0E | RES,3.9K-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0535 | 88-121-392-080 | 0E | RES,3.9K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0536 | 88-128-562-080 | | C-RES, 5.6K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0536 | 88-128-562-080 | 0E | C-RES, 5.6K-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0536 | 88-128-562-080 | 0E | C-RES, 5.6K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0537 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0537 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0537 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0538 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0538 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0538 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0539 | 88-118-123-080 | | C-RES,S 12K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0539 | 88-118-123-080 | 0E | C-RES,S 12K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0539 | 88-118-123-080 | 0E | C-RES,S 12K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0540 | 88-118-123-080 | | C-RES,S 12K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0540 | 88-118-123-080 | 0E | C-RES,S 12K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0540 | 88-118-123-080 | 0E | C-RES,S 12K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0541 | 88-118-273-080 | | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0541 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0541 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0542 | 88-118-273-080 | | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0542 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0542 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0543 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0543 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0543 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0544 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0544 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0544 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0545 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0545 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0545 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0546 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0546 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0546 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0547 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0547 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0547 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0548 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0548 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | FUNCTION | R 0548 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0549 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | R 0549 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | FUNCTION | R 0549 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | FUNCTION | R 0550 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0550 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0550 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0551 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0551 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0551 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0552 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0552 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0552 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0553 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0553 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0553 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0554 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0554 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0554 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0555 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0555 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0555 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0556 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0556 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0556 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0557 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0557 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0557 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0558 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0558 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0558 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0559 | 88-118-184-080 | | C-RES,S 180K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0559 | 88-118-184-080 | 0E | C-RES,S 180K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0559 | 88-118-184-080 | 0E | C-RES,S 180K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0560 | 88-118-184-080 | | C-RES,S 180K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0560 | 88-118-184-080 | 0E | C-RES,S 180K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0560 | 88-118-184-080 | 0E | C-RES,S 180K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0561 | 88-121-103-080 | | RES,10K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0561 | 88-121-103-080 | 0E | RES,10K-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0561 | 88-121-103-080 | 0E | RES,10K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0562 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0562 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0562 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0563 | 88-121-103-080 | | RES,10K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0563 | 88-121-103-080 | 0E | RES,10K-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0563 | 88-121-103-080 | 0E | RES,10K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0564 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0564 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0564 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0565 | 88-121-103-080 | | RES,10K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0565 | 88-121-103-080 | 0E | RES,10K-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0565 | 88-121-103-080 | 0E | RES,10K-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0566 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0566 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0566 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0567 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0567 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0567 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0568 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0568 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0568 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0569 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0569 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0569 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0570 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0570 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0570 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0571 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0571 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0571 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | FUNCTION | R 0572 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0572 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0572 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0573 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0573 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0573 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0574 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0574 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0574 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0575 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0575 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0575 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0576 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0576 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0576 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0577 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0577 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0577 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0578 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | R 0578 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | FUNCTION | R 0578 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | FUNCTION | R 0579 | 88-128-560-080 | | C-RES, 56-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0579 | 88-128-560-080 | 0E | C-RES, 56-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0579 | 88-128-560-080 | 0E | C-RES, 56-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0581 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0581 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0581 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0582 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0582 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0582 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0583 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0583 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0583 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0584 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0584 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0584 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0585 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0585 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0585 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0586 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0586 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0586 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | O | FUNCTION | R 0587 | 87-A00-126-080 | | RES,M/F 220-1W J VTP | UBM | AV-D77 |
| | O | FUNCTION | R 0587 | 87-A00-126-080 | 0E | RES,M/F 220-1W J VTP | EZBM | AV-D77 |
| | O | FUNCTION | R 0587 | 87-A00-126-080 | 0E | RES,M/F 220-1W J VTP | UBM | AV-D77 |
| | X | FUNCTION | R 0588 | 88-128-390-080 | | C-RES, 39-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0588 | 88-128-390-080 | 0E | C-RES, 39-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0588 | 88-128-390-080 | 0E | C-RES, 39-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0591 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0591 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0591 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0592 | 88-128-560-080 | | C-RES, 56-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0592 | 88-128-560-080 | 0E | C-RES, 56-1/8W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0592 | 88-128-560-080 | 0E | C-RES, 56-1/8W J | UBM | AV-D77 |
| | X | FUNCTION | R 0593 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0593 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0593 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0594 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0594 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0594 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0595 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0595 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0595 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0596 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0596 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0596 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0597 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0597 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0597 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0598 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | FUNCTION | R 0598 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0598 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0599 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0599 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0599 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0638 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | R 0638 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | FUNCTION | R 0638 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | FUNCTION | W 0108 | 89-991-123-410 | | WIRE,U24X1-12-5/5 | UBM | AV-D77 |
| | X | FUNCTION | W 0111 | 89-992-103-410 | | WIRE,U24X2-10-5/5 | UBM | AV-D77 |
| | O | GEQ | C 0758 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0758 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | GEQ | C 0758 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0759 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | GEQ | C 0759 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | GEQ | C 0759 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | X | GEQ | C 0760 | 88-710-949-810 | | CAP,M 0.47-50 J TFL | UBM | AV-D77 |
| | X | GEQ | C 0760 | 88-710-949-810 | 1A | CAP,M 0.47-50 J TFL | EZBM | AV-D77 |
| | X | GEQ | C 0760 | 88-710-949-810 | 1A | CAP,M 0.47-50 J TFL | UBM | AV-D77 |
| | O | GEQ | C 0761 | 87-010-198-080 | | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0761 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | EZBM | AV-D77 |
| | O | GEQ | C 0761 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0762 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0762 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |
| | O | GEQ | C 0762 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | X | GEQ | C 0763 | 88-710-969-810 | | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | X | GEQ | C 0763 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | EZBM | AV-D77 |
| | X | GEQ | C 0763 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | O | GEQ | C 0764 | 87-010-185-080 | | C-CAP,S 3900P-50 K B | UBM | AV-D77 |
| | O | GEQ | C 0764 | 87-010-185-080 | 0E | C-CAP,S 3900P-50 K B | EZBM | AV-D77 |
| | O | GEQ | C 0764 | 87-010-185-080 | 0E | C-CAP,S 3900P-50 K B | UBM | AV-D77 |
| | O | GEQ | C 0765 | 87-010-194-080 | | C-CAP,S 0.047-25 Z F | UBM | AV-D77 |
| | O | GEQ | C 0765 | 87-010-194-080 | 0E | C-CAP,S 0.047-25 Z F | EZBM | AV-D77 |
| | O | GEQ | C 0765 | 87-010-194-080 | 0E | C-CAP,S 0.047-25 Z F | UBM | AV-D77 |
| | O | GEQ | C 0766 | 87-010-181-080 | | C-CAP,S 1800P-50 K B GRM | UBM | AV-D77 |
| | O | GEQ | C 0766 | 87-010-181-080 | 0E | C-CAP,S 1800P-50 K B GRM | EZBM | AV-D77 |
| | O | GEQ | C 0766 | 87-010-181-080 | 0E | C-CAP,S 1800P-50 K B GRM | UBM | AV-D77 |
| | O | GEQ | C 0767 | 87-010-198-080 | | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0767 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | EZBM | AV-D77 |
| | O | GEQ | C 0767 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0768 | 87-010-994-080 | | C-CAP,S 680P-50 J CH | UBM | AV-D77 |
| | O | GEQ | C 0768 | 87-010-994-080 | 0E | C-CAP,S 680P-50 J CH | EZBM | AV-D77 |
| | O | GEQ | C 0768 | 87-010-994-080 | 0E | C-CAP,S 680P-50 J CH | UBM | AV-D77 |
| | O | GEQ | C 0769 | 87-010-188-080 | | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0769 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | EZBM | AV-D77 |
| | O | GEQ | C 0769 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0770 | 87-012-145-080 | | C-CAP,S 270P-50 J CH GRM | UBM | AV-D77 |
| | O | GEQ | C 0770 | 87-012-145-080 | 0E | C-CAP,S 270P-50 J CH GRM | EZBM | AV-D77 |
| | O | GEQ | C 0770 | 87-012-145-080 | 0E | C-CAP,S 270P-50 J CH GRM | UBM | AV-D77 |
| | O | GEQ | C 0771 | 87-010-183-080 | | C-CAP,S 2700P-50 K B GRM | UBM | AV-D77 |
| | O | GEQ | C 0771 | 87-010-183-080 | 0E | C-CAP,S 2700P-50 K B GRM | EZBM | AV-D77 |
| | O | GEQ | C 0771 | 87-010-183-080 | 0E | C-CAP,S 2700P-50 K B GRM | UBM | AV-D77 |
| | O | GEQ | C 0772 | 87-012-145-080 | | C-CAP,S 270P-50 J CH GRM | UBM | AV-D77 |
| | O | GEQ | C 0772 | 87-012-145-080 | 0E | C-CAP,S 270P-50 J CH GRM | EZBM | AV-D77 |
| | O | GEQ | C 0772 | 87-012-145-080 | 0E | C-CAP,S 270P-50 J CH GRM | UBM | AV-D77 |
| | O | GEQ | C 0773 | 87-010-188-080 | | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0773 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | EZBM | AV-D77 |
| | O | GEQ | C 0773 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0774 | 87-010-994-080 | | C-CAP,S 680P-50 J CH | UBM | AV-D77 |
| | O | GEQ | C 0774 | 87-010-994-080 | 0E | C-CAP,S 680P-50 J CH | EZBM | AV-D77 |
| | O | GEQ | C 0774 | 87-010-994-080 | 0E | C-CAP,S 680P-50 J CH | UBM | AV-D77 |
| | O | GEQ | C 0775 | 87-010-198-080 | | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0775 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | EZBM | AV-D77 |
| | O | GEQ | C 0775 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0776 | 87-010-181-080 | | C-CAP,S 1800P-50 K B GRM | UBM | AV-D77 |
| | O | GEQ | C 0776 | 87-010-181-080 | 0E | C-CAP,S 1800P-50 K B GRM | EZBM | AV-D77 |
| | O | GEQ | C 0776 | 87-010-181-080 | 0E | C-CAP,S 1800P-50 K B GRM | UBM | AV-D77 |
| | O | GEQ | C 0777 | 87-010-194-080 | | C-CAP,S 0.047-25 Z F | UBM | AV-D77 |
| | O | GEQ | C 0777 | 87-010-194-080 | 0E | C-CAP,S 0.047-25 Z F | EZBM | AV-D77 |
| | O | GEQ | C 0777 | 87-010-194-080 | 0E | C-CAP,S 0.047-25 Z F | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | GEQ | C 0778 | 87-010-185-080 | | C-CAP,S 3900P-50 K B | UBM | AV-D77 |
| | O | GEQ | C 0778 | 87-010-185-080 | 0E | C-CAP,S 3900P-50 K B | EZBM | AV-D77 |
| | O | GEQ | C 0778 | 87-010-185-080 | 0E | C-CAP,S 3900P-50 K B | UBM | AV-D77 |
| | X | GEQ | C 0779 | 88-710-969-810 | | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | X | GEQ | C 0779 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | EZBM | AV-D77 |
| | X | GEQ | C 0779 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | O | GEQ | C 0780 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0780 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |
| | O | GEQ | C 0780 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | X | GEQ | C 0781 | 88-710-949-810 | | CAP,M 0.47-50 J TFL | UBM | AV-D77 |
| | X | GEQ | C 0781 | 88-710-949-810 | 1A | CAP,M 0.47-50 J TFL | EZBM | AV-D77 |
| | X | GEQ | C 0781 | 88-710-949-810 | 1A | CAP,M 0.47-50 J TFL | UBM | AV-D77 |
| | O | GEQ | C 0782 | 87-010-183-080 | | C-CAP,S 2700P-50 K B GRM | UBM | AV-D77 |
| | O | GEQ | C 0782 | 87-010-183-080 | 0E | C-CAP,S 2700P-50 K B GRM | EZBM | AV-D77 |
| | O | GEQ | C 0782 | 87-010-183-080 | 0E | C-CAP,S 2700P-50 K B GRM | UBM | AV-D77 |
| | O | GEQ | C 0783 | 87-010-198-080 | | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | GEQ | C 0783 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | EZBM | AV-D77 |
| | O | GEQ | C 0783 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | X | GEQ | C 0784 | 88-710-949-810 | | CAP,M 0.47-50 J TFL | UBM | AV-D77 |
| | X | GEQ | C 0784 | 88-710-949-810 | 1A | CAP,M 0.47-50 J TFL | EZBM | AV-D77 |
| | X | GEQ | C 0784 | 88-710-949-810 | 1A | CAP,M 0.47-50 J TFL | UBM | AV-D77 |
| | X | GEQ | C 0785 | 88-710-969-810 | | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | X | GEQ | C 0785 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | EZBM | AV-D77 |
| | X | GEQ | C 0785 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | O | GEQ | C 0786 | 87-010-402-080 | | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0786 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | EZBM | AV-D77 |
| | O | GEQ | C 0786 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0787 | 87-010-402-080 | | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0787 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | EZBM | AV-D77 |
| | O | GEQ | C 0787 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0788 | 87-010-260-080 | | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0788 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | EZBM | AV-D77 |
| | O | GEQ | C 0788 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0789 | 87-010-260-080 | | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0789 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | EZBM | AV-D77 |
| | O | GEQ | C 0789 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0790 | 87-010-260-080 | | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0790 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | EZBM | AV-D77 |
| | O | GEQ | C 0790 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0791 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0791 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | GEQ | C 0791 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0792 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0792 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | GEQ | C 0792 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | GEQ | C 0793 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | GEQ | C 0793 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | GEQ | C 0793 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | GEQ | C 0794 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | GEQ | C 0794 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | GEQ | C 0794 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | X | GEQ | C 0795 | 88-710-969-810 | | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | X | GEQ | C 0795 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | EZBM | AV-D77 |
| | X | GEQ | C 0795 | 88-710-969-810 | 0E | CAP,M 0.12-50 J TFL ECQV | UBM | AV-D77 |
| | X | GEQ | C 0796 | 88-710-949-810 | | CAP,M 0.47-50 J TFL | UBM | AV-D77 |
| | X | GEQ | C 0796 | 88-710-949-810 | 1A | CAP,M 0.47-50 J TFL | EZBM | AV-D77 |
| | X | GEQ | C 0796 | 88-710-949-810 | 1A | CAP,M 0.47-50 J TFL | UBM | AV-D77 |
| | O | GEQ | C 0797 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | GEQ | C 0797 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | GEQ | C 0797 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | GEQ | C 0798 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | GEQ | C 0798 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | GEQ | C 0798 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | GEQ | C 0799 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | GEQ | C 0799 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | GEQ | C 0799 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | GEQ | CN 0701 | 87-099-670-010 | | CONN,9P TUC-P9X-B1 | UBM | AV-D77 |
| | O | GEQ | CN 0701 | 87-099-670-010 | 0E | CONN,9P TUC-P9X-B1 | EZBM | AV-D77 |
| | O | GEQ | CN 0701 | 87-099-670-010 | 0E | CONN,9P TUC-P9X-B1 | UBM | AV-D77 |
| | O | GEQ | CN 0702 | 8A-AR3-653-010 | | CONN ASSY,10P (GEQ) | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | GEQ | CN 0702 | 8A-AR3-653-010 | 1B | CONN ASSY,10P (GEQ) | EZBM | AV-D77 |
| | O | GEQ | CN 0702 | 8A-AR3-653-010 | 1B | CONN ASSY,10P (GEQ) | UBM | AV-D77 |
| | S | GEQ | D 0721 | 87-A40-344-080 | | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | GEQ | D 0721 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | EZBM | AV-D77 |
| | S | GEQ | D 0721 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | GEQ | D 0722 | 87-A40-002-080 | | ZENER,MTZJ5.1C | UBM | AV-D77 |
| | S | GEQ | D 0722 | 87-A40-002-080 | 0E | ZENER,MTZJ5.1C | EZBM | AV-D77 |
| | S | GEQ | D 0722 | 87-A40-002-080 | 0E | ZENER,MTZJ5.1C | UBM | AV-D77 |
| | S | GEQ | D 0723 | 87-A40-344-080 | | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | GEQ | D 0723 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | EZBM | AV-D77 |
| | S | GEQ | D 0723 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | GEQ | IC 0701 | 87-A20-437-010 | 2A | C-IC,M62431FP | EZBM | AV-D77 |
| | S | GEQ | IC 0701 | 87-A20-437-010 | 2A | C-IC,M62431FP | UBM | AV-D77 |
| O | S | GEQ | IC 0701 | 87-A20-437-010 | | C-IC,M62431FP | UBM | AV-D77 |
| | X | GEQ | JR 0703 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | GEQ | JR 0703 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | GEQ | JR 0703 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | GEQ | JR 0704 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | GEQ | JR 0704 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | GEQ | JR 0704 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | GEQ | JR 0705 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | GEQ | JR 0705 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | GEQ | JR 0705 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | GEQ | JR 0706 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | GEQ | JR 0706 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | GEQ | JR 0706 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | GEQ | R 0780 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0780 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | GEQ | R 0780 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0781 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0781 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | GEQ | R 0781 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0782 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0782 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | GEQ | R 0782 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0783 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0783 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | GEQ | R 0783 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0784 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0784 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | GEQ | R 0784 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0785 | 88-128-122-080 | | C-RES, 1.2K-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0785 | 88-128-122-080 | 0E | C-RES, 1.2K-1/8W J | EZBM | AV-D77 |
| | X | GEQ | R 0785 | 88-128-122-080 | 0E | C-RES, 1.2K-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0787 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0787 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | GEQ | R 0787 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0788 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0788 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | GEQ | R 0788 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0789 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0789 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | GEQ | R 0789 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0790 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0790 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | GEQ | R 0790 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0792 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0792 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | GEQ | R 0792 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0793 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0793 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | GEQ | R 0793 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0794 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0794 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | GEQ | R 0794 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0795 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0795 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | GEQ | R 0795 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0796 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0796 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | GEQ | R 0796 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | GEQ | R 0797 | 88-128-470-080 | | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | GEQ | R 0797 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | EZBM | AV-D77 |
| | X | GEQ | R 0797 | 88-128-470-080 | 0E | C-RES, 47-1/8W J | UBM | AV-D77 |
| | X | KEY CON SW | JR 0653 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | KEY CON SW | JR 0653 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | KEY CON SW | JR 0653 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | KEY CON SW | JR 0654 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | KEY CON SW | JR 0654 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | KEY CON SW | JR 0654 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | KEY CON SW | JR 0655 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | KEY CON SW | JR 0655 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | KEY CON SW | JR 0655 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | KNOB | | 8A-AR1-003-010 | | KEY,BASS U | UBM | AV-D77 |
| | X | KNOB | | 8A-AR1-003-010 | -- | KEY,BASS U | EZBM | AV-D77 |
| | X | KNOB | | 8A-AR1-003-010 | -- | KEY,BASS U | UBM | AV-D77 |
| | O | KNOB | | 8A-AR1-016-010 | | KEY,ASSY ENTER | UBM | AV-D77 |
| | O | KNOB | | 8A-AR1-016-010 | 1C | KEY,ASSY ENTER | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR1-016-010 | 1C | KEY,ASSY ENTER | UBM | AV-D77 |
| | O | KNOB | | 8A-AR1-017-010 | | KEY,ASSY DOLBY | UBM | AV-D77 |
| | O | KNOB | | 8A-AR1-017-010 | 1C | KEY,ASSY DOLBY | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-006-010 | | KNOB,RTRY JOG | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-006-010 | 0E | KNOB,RTRY JOG | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR3-006-010 | 0E | KNOB,RTRY JOG | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-007-010 | | RING,VOL | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-007-010 | 1D | RING,VOL | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR3-007-010 | 1D | RING,VOL | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-011-010 | | BTN,SP | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-011-010 | 1A | BTN,SP | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR3-011-010 | 1A | BTN,SP | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-014-010 | | BTN,SUR | UBM | AV-D77 |
| | X | KNOB | | 8A-AR3-014-010 | -- | BTN,SUR | EZBM | AV-D77 |
| | X | KNOB | | 8A-AR3-014-010 | -- | BTN,SUR | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-015-010 | | BTN,DSP | UBM | AV-D77 |
| | X | KNOB | | 8A-AR3-015-010 | -- | BTN,DSP | EZBM | AV-D77 |
| | X | KNOB | | 8A-AR3-015-010 | -- | BTN,DSP | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-016-010 | | BTN,GEQ | UBM | AV-D77 |
| | X | KNOB | | 8A-AR3-016-010 | -- | BTN,GEQ | EZBM | AV-D77 |
| | X | KNOB | | 8A-AR3-016-010 | -- | BTN,GEQ | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-017-010 | | BTN,ENTER | UBM | AV-D77 |
| | X | KNOB | | 8A-AR3-017-010 | -- | BTN,ENTER | EZBM | AV-D77 |
| | X | KNOB | | 8A-AR3-017-010 | -- | BTN,ENTER | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-018-010 | | BTN,UP | UBM | AV-D77 |
| | X | KNOB | | 8A-AR3-018-010 | -- | BTN,UP | EZBM | AV-D77 |
| | X | KNOB | | 8A-AR3-018-010 | -- | BTN,UP | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-019-010 | | BTN,DOWN | UBM | AV-D77 |
| | X | KNOB | | 8A-AR3-019-010 | -- | BTN,DOWN | EZBM | AV-D77 |
| | X | KNOB | | 8A-AR3-019-010 | -- | BTN,DOWN | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-020-010 | | KEY,ECO | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-020-010 | 0E | KEY,ECO | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR3-020-010 | 0E | KEY,ECO | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-021-010 | | KEY,POWER | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-021-010 | 0E | KEY,POWER | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR3-021-010 | 0E | KEY,POWER | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-022-010 | | KEY,MONITOR U | UBM | AV-D77 |
| | X | KNOB | | 8A-AR3-022-010 | -- | KEY,MONITOR U | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-024-010 | | KEY,BAL | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-024-010 | 0E | KEY,BAL | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR3-024-010 | 0E | KEY,BAL | UBM | AV-D77 |
| | X | KNOB | | 8A-AR3-027-010 | -- | KEY,MONITOR EZ | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR3-029-010 | 1D | KEY,ASSY DOLBY EZ | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR3-045-010 | | KNOB,RTRY VOL | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-045-010 | 1A | KNOB,RTRY VOL | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR3-045-010 | 1A | KNOB,RTRY VOL | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-047-010 | | RING,FUN | UBM | AV-D77 |
| | O | KNOB | | 8A-AR3-047-010 | 1D | RING,FUN | EZBM | AV-D77 |
| | O | KNOB | | 8A-AR3-047-010 | 1D | RING,FUN | UBM | AV-D77 |
| | X | LBL,POP | | 87-B40-034-010 | | LBL,USA 1-800 | UBM | AV-D77 |
| | X | LBL,POP | | 87-B40-034-010 | 1B | LBL,USA 1-800 | UBM | AV-D77 |
| | X | LBL,POP | | 8A-AR2-970-010 | 0E | LBL,POP U | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | LBL,POP | | 8A-AR2-971-010 | | LBL,POP 77U | UBM | AV-D77 |
| | X | LBL,POP | | 8A-NF8-972-010 | | LBL,POP ENG | UBM | AV-D77 |
| | X | LBL,POP | | 8A-NF8-972-010 | 0E | LBL,POP ENG | UBM | AV-D77 |
| | O | MACB MECHA | | 87-067-579-010 | | BVT2+3-8 W/0 SL0T | UBM | AV-D77 |
| | O | MACB MECHA | | 87-067-579-010 | 0E | BVT2+3-8 W/0 SL0T | EZBM | AV-D77 |
| | O | MACB MECHA | | 87-067-579-010 | 0E | BVT2+3-8 W/0 SL0T | UBM | AV-D77 |
| | X | MACB MECHA | | 88-AR1-213-010 | | HT-SINK,FET | UBM | AV-D77 |
| | X | MACB MECHA | | 88-AR1-213-010 | 0E | HT-SINK,FET | EZBM | AV-D77 |
| | X | MACB MECHA | | 88-AR1-213-010 | 0E | HT-SINK,FET | UBM | AV-D77 |
| | X | MECHANICAL | | 8A-AR1-204-010 | | CHAS,MAIN 96-80 | UBM | AV-D77 |
| | X | MECHANICAL | | 8A-AR1-204-010 | 2M | CHAS,MAIN 96-80 | EZBM | AV-D77 |
| | X | MECHANICAL | | 8A-AR1-204-010 | 2M | CHAS,MAIN 96-80 | UBM | AV-D77 |
| | X | MICON | | 8A-AR2-611-010 | | PWB,FRONT (2M) | UBM | AV-D77 |
| | X | MICON | | 8A-AR2-611-110 | 1D | PWB,FRONT (2M) | EZBM | AV-D77 |
| | X | MICON | | 8A-AR2-611-110 | 1D | PWB,FRONT (2M) | UBM | AV-D77 |
| | O | MICON | C 0707 | 87-010-382-040 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0707 | 87-010-382-040 | 0E | CAP,E 22-25 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0707 | 87-010-382-040 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0708 | 87-010-382-040 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0708 | 87-010-382-040 | 0E | CAP,E 22-25 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0708 | 87-010-382-040 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0709 | 87-010-382-040 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0709 | 87-010-382-040 | 0E | CAP,E 22-25 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0709 | 87-010-382-040 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0710 | 87-010-382-040 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0710 | 87-010-382-040 | 0E | CAP,E 22-25 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0710 | 87-010-382-040 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0711 | 87-010-263-040 | | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0711 | 87-010-263-040 | 0E | CAP,E 100-10 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0711 | 87-010-263-040 | 0E | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0712 | 87-010-382-040 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0712 | 87-010-382-040 | 0E | CAP,E 22-25 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0712 | 87-010-382-040 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0714 | 87-010-560-040 | | CAP,E 10-50 M 5L MA | UBM | AV-D77 |
| | O | MICON | C 0714 | 87-010-560-040 | 0E | CAP,E 10-50 M 5L MA | EZBM | AV-D77 |
| | O | MICON | C 0714 | 87-010-560-040 | 0E | CAP,E 10-50 M 5L MA | UBM | AV-D77 |
| | O | MICON | C 0715 | 87-010-318-080 | | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0715 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0715 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0716 | 87-010-318-080 | | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0716 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0716 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0717 | 87-010-318-080 | | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0717 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0717 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0718 | 87-015-699-040 | | CAP,E 10-50 M 7L SRA | UBM | AV-D77 |
| | O | MICON | C 0718 | 87-015-699-040 | 0E | CAP,E 10-50 M 7L SRA | EZBM | AV-D77 |
| | O | MICON | C 0718 | 87-015-699-040 | 0E | CAP,E 10-50 M 7L SRA | UBM | AV-D77 |
| | O | MICON | C 0719 | 87-015-699-040 | | CAP,E 10-50 M 7L SRA | UBM | AV-D77 |
| | O | MICON | C 0719 | 87-015-699-040 | 0E | CAP,E 10-50 M 7L SRA | EZBM | AV-D77 |
| | O | MICON | C 0719 | 87-015-699-040 | 0E | CAP,E 10-50 M 7L SRA | UBM | AV-D77 |
| | O | MICON | C 0720 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0720 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0720 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0721 | 87-010-318-080 | | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0721 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0721 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0722 | 87-010-318-080 | | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0722 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0722 | 87-010-318-080 | 0E | C-CAP,S 47P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0723 | 87-010-405-040 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0723 | 87-010-405-040 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0723 | 87-010-405-040 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0801 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0801 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0801 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0802 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0802 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0802 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0803 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | MICON | C 0803 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | MICON | C 0803 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0805 | 87-010-198-080 | | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0805 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | EZBM | AV-D77 |
| | O | MICON | C 0805 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0806 | 87-010-400-040 | | CAP,E 0.47-50 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0806 | 87-010-400-040 | 0E | CAP,E 0.47-50 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0806 | 87-010-400-040 | 0E | CAP,E 0.47-50 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0807 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0807 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | MICON | C 0807 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0808 | 87-010-498-040 | | CAP,E 10-16 M 5L SRE | UBM | AV-D77 |
| | O | MICON | C 0808 | 87-010-498-040 | 0E | CAP,E 10-16 M 5L SRE | EZBM | AV-D77 |
| | O | MICON | C 0808 | 87-010-498-040 | 0E | CAP,E 10-16 M 5L SRE | UBM | AV-D77 |
| | O | MICON | C 0809 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0809 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | MICON | C 0809 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0810 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0810 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | MICON | C 0810 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0811 | 87-A10-189-040 | | CAP,E 220-10 M 5L | UBM | AV-D77 |
| | O | MICON | C 0811 | 87-A10-189-040 | 0E | CAP,E 220-10 M 5L | EZBM | AV-D77 |
| | O | MICON | C 0811 | 87-A10-189-040 | 0E | CAP,E 220-10 M 5L | UBM | AV-D77 |
| | O | MICON | C 0812 | 87-A10-189-040 | | CAP,E 220-10 M 5L | UBM | AV-D77 |
| | O | MICON | C 0812 | 87-A10-189-040 | 0E | CAP,E 220-10 M 5L | EZBM | AV-D77 |
| | O | MICON | C 0812 | 87-A10-189-040 | 0E | CAP,E 220-10 M 5L | UBM | AV-D77 |
| | O | MICON | C 0814 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0814 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | MICON | C 0814 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | X | MICON | C 0815 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | C 0815 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | C 0815 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | O | MICON | C 0816 | 87-010-312-080 | | C-CAP,S 15P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0816 | 87-010-312-080 | 0E | C-CAP,S 15P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0816 | 87-010-312-080 | 0E | C-CAP,S 15P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0817 | 87-012-155-080 | | C-CAP,S 180P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0817 | 87-012-155-080 | 0E | C-CAP,S 180P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0817 | 87-012-155-080 | 0E | C-CAP,S 180P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0818 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0818 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | MICON | C 0818 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0819 | 87-012-156-080 | | C-CAP,S 220P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0819 | 87-012-156-080 | 0E | C-CAP,S 220P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0819 | 87-012-156-080 | 0E | C-CAP,S 220P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0820 | 87-012-156-080 | | C-CAP,S 220P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0820 | 87-012-156-080 | 0E | C-CAP,S 220P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0820 | 87-012-156-080 | 0E | C-CAP,S 220P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0821 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0821 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | MICON | C 0821 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0822 | 87-010-182-080 | | C-CAP,S 2200P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0822 | 87-010-182-080 | 0E | C-CAP,S 2200P-50 K B C2012 | EZBM | AV-D77 |
| | O | MICON | C 0822 | 87-010-182-080 | 0E | C-CAP,S 2200P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0823 | 87-010-182-080 | | C-CAP,S 2200P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0823 | 87-010-182-080 | 0E | C-CAP,S 2200P-50 K B C2012 | EZBM | AV-D77 |
| | O | MICON | C 0823 | 87-010-182-080 | 0E | C-CAP,S 2200P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0824 | 87-010-182-080 | | C-CAP,S 2200P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0824 | 87-010-182-080 | 0E | C-CAP,S 2200P-50 K B C2012 | EZBM | AV-D77 |
| | O | MICON | C 0824 | 87-010-182-080 | 0E | C-CAP,S 2200P-50 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0825 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0825 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | MICON | C 0825 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0826 | 87-010-405-040 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0826 | 87-010-405-040 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0826 | 87-010-405-040 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0827 | 87-010-198-080 | | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0827 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | EZBM | AV-D77 |
| | O | MICON | C 0827 | 87-010-198-080 | 0E | C-CAP,S 0.022-25 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0828 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0828 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | MICON | C 0828 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0829 | 87-012-156-080 | | C-CAP,S 220P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0829 | 87-012-156-080 | 0E | C-CAP,S 220P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0829 | 87-012-156-080 | 0E | C-CAP,S 220P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0830 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0830 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |
| | O | MICON | C 0830 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | MICON | C 0831 | 87-A10-189-040 | | CAP,E 220-10 M 5L | UBM | AV-D77 |
| | O | MICON | C 0831 | 87-A10-189-040 | 0E | CAP,E 220-10 M 5L | EZBM | AV-D77 |
| | O | MICON | C 0831 | 87-A10-189-040 | 0E | CAP,E 220-10 M 5L | UBM | AV-D77 |
| | O | MICON | C 0832 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0832 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | MICON | C 0832 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | MICON | C 0833 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | MICON | C 0833 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | MICON | C 0833 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | MICON | C 0834 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | MICON | C 0834 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | MICON | C 0834 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | MICON | C 0835 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | MICON | C 0835 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | MICON | C 0835 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | MICON | C 0836 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0836 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0836 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0837 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0837 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0837 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0838 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0838 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0838 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0839 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0839 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0839 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0840 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0840 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0840 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0841 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0841 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0841 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0842 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0842 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0842 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0843 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0843 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0843 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0844 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0844 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0844 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0845 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0845 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0845 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0846 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0846 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0846 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0847 | 87-015-699-040 | 0E | CAP,E 10-50 M 7L SRA | EZBM | AV-D77 |
| | O | MICON | C 0847 | 87-015-699-040 | 0E | CAP,E 10-50 M 7L SRA | UBM | AV-D77 |
| | O | MICON | C 0848 | 87-010-405-040 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0848 | 87-010-405-040 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0849 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | MICON | C 0849 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | MICON | C 0849 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | MICON | C 0850 | 87-010-408-040 | | CAP,E 47-50 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0850 | 87-010-408-040 | 0E | CAP,E 47-50 M 11L SME | EZBM | AV-D77 |
| | O | MICON | C 0850 | 87-010-408-040 | 0E | CAP,E 47-50 M 11L SME | UBM | AV-D77 |
| | O | MICON | C 0852 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0852 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0852 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0853 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0853 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | MICON | C 0853 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0854 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0854 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0854 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0855 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0855 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0855 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0856 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0856 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0856 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0857 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0857 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0857 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0858 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0858 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0858 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0859 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0859 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0859 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0860 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0860 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0860 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0861 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0861 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0861 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0862 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0862 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0862 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | MICON | C 0864 | 87-012-157-080 | | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0864 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | EZBM | AV-D77 |
| | O | MICON | C 0864 | 87-012-157-080 | 0E | C-CAP,S 330P-50 J CH GRM | UBM | AV-D77 |
| | O | MICON | C 0866 | 87-012-140-080 | | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | MICON | C 0866 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | EZBM | AV-D77 |
| | O | MICON | C 0866 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | MICON | CN 0801 | 87-A60-079-010 | | CONN,08P H 9604S-08F | UBM | AV-D77 |
| ! | O | MICON | CN 0801 | 87-A60-079-010 | 0E | CONN,08P H 9604S-08F | EZBM | AV-D77 |
| ! | O | MICON | CN 0801 | 87-A60-079-010 | 0E | CONN,08P H 9604S-08F | UBM | AV-D77 |
| | O | MICON | CN 0802 | 87-A60-064-010 | | CONN,32P H 9604S-32F | UBM | AV-D77 |
| ! | O | MICON | CN 0802 | 87-A60-064-010 | 1A | CONN,32P H 9604S-32F | UBM | AV-D77 |
| | O | MICON | CN 0802 | 87-A61-195-010 | 1A | CONN,35P H 9604S-35C | EZBM | AV-D77 |
| | O | MICON | CN 0803 | 87-099-755-010 | | CONN,14P H 9604 | UBM | AV-D77 |
| ! | O | MICON | CN 0803 | 87-099-755-010 | 0E | CONN,14P H 9604 | EZBM | AV-D77 |
| ! | O | MICON | CN 0803 | 87-099-755-010 | 0E | CONN,14P H 9604 | UBM | AV-D77 |
| | O | MICON | CN 0805 | 87-A60-076-010 | | CONN,12P H 9604S-12F | UBM | AV-D77 |
| | O | MICON | CN 0805 | 87-A60-076-010 | 0E | CONN,12P H 9604S-12F | EZBM | AV-D77 |
| | O | MICON | CN 0805 | 87-A60-076-010 | 0E | CONN,12P H 9604S-12F | UBM | AV-D77 |
| | S | MICON | D 0707 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0707 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0707 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0708 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0708 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0708 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0709 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0709 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0709 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0710 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0710 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0710 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0747 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0747 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0747 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | X | MICON | D 0801 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | MICON | D 0801 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | MICON | D 0801 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | S | MICON | D 0802 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0802 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0802 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0803 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0803 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0803 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | MICON | D 0804 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0804 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0804 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0805 | 87-A40-344-080 | | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | MICON | D 0805 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | EZBM | AV-D77 |
| | S | MICON | D 0805 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | X | MICON | D 0807 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | MICON | D 0807 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | MICON | D 0807 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | S | MICON | D 0810 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0812 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0815 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0815 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0818 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0818 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0818 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0819 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0819 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0819 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0820 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0820 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0820 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0821 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0821 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0821 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0822 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0822 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0822 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0823 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0823 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0823 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0824 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0824 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | MICON | D 0824 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0826 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | MICON | D 0826 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | O | MICON | FL 0801 | 8A-AR1-602-010 | | FL,BJ759GK | UBM | AV-D77 |
| | O | MICON | FL 0801 | 8A-AR1-602-010 | 2Y | FL,BJ759GK | EZBM | AV-D77 |
| | O | MICON | FL 0801 | 8A-AR1-602-010 | 2Y | FL,BJ759GK | UBM | AV-D77 |
| | S | MICON | IC 0701 | 87-A21-481-040 | 1B | C-IC,HD74HC4051FP | EZBM | AV-D77 |
| | S | MICON | IC 0701 | 87-A21-481-040 | 1B | C-IC,HD74HC4051FP | UBM | AV-D77 |
| O | S | MICON | IC 0701 | 87-A21-481-040 | | C-IC,HD74HC4051FP | UBM | AV-D77 |
| | S | MICON | IC 0702 | 87-017-915-080 | 1B | C-IC,BU4094BCF | EZBM | AV-D77 |
| | S | MICON | IC 0702 | 87-017-915-080 | 1B | C-IC,BU4094BCF | UBM | AV-D77 |
| O | S | MICON | IC 0702 | 87-017-915-080 | | C-IC,BU4094BCF | UBM | AV-D77 |
| | S | MICON | IC 0703 | 87-017-915-080 | 1B | C-IC,BU4094BCF | EZBM | AV-D77 |
| | S | MICON | IC 0703 | 87-017-915-080 | 1B | C-IC,BU4094BCF | UBM | AV-D77 |
| O | S | MICON | IC 0703 | 87-017-915-080 | | C-IC,BU4094BCF | UBM | AV-D77 |
| | S | MICON | IC 0801 | 8A-AR1-603-010 | 1H | C-IC,UPD780228GF-068 | UBM | AV-D77 |
| O | S | MICON | IC 0801 | 8A-AR1-603-010 | | C-IC,UPD780228GF-068 | UBM | AV-D77 |
| | S | MICON | IC 0801 | 8A-AR3-601-110 | 1H | C-IC,UPD780228GF-071 | EZBM | AV-D77 |
| | S | MICON | IC 0802 | 87-070-083-010 | | IC,GP1U281X | UBM | AV-D77 |
| | S | MICON | IC 0802 | 87-070-083-010 | 1C | IC,GP1U281X | EZBM | AV-D77 |
| | S | MICON | IC 0802 | 87-070-083-010 | 1C | IC,GP1U281X | UBM | AV-D77 |
| | X | MICON | JR 0801 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0801 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0801 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0802 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0802 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0802 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0803 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0803 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0803 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0804 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0804 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0804 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0805 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0805 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0805 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0806 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | JR 0806 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0806 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0807 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0807 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0807 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0808 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0808 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0808 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0809 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0809 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0809 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0810 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0810 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0810 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0811 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0811 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0811 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0812 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0812 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0812 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0813 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0813 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | MICON | JR 0813 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0814 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0814 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | MICON | JR 0814 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0815 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0815 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | MICON | JR 0815 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0816 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0816 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0816 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0817 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0817 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0817 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0818 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0818 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0818 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0819 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0819 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0819 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0820 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0820 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0820 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0821 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0821 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0821 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0822 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0822 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0822 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0824 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0824 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | MICON | JR 0824 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0825 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0825 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | MICON | JR 0825 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0827 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0827 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0827 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0828 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0828 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0828 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0829 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0829 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0829 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0830 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0830 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | MICON | JR 0830 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0831 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0831 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | JR 0831 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0832 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0832 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | JR 0832 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | JR 0833 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0833 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | MICON | JR 0833 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0837 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0837 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | MICON | JR 0837 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0901 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | MICON | JR 0901 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | MICON | JR 0901 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | MICON | L 0801 | 87-A50-434-010 | | COIL,CLK 4.19M(TOKO) | UBM | AV-D77 |
| | O | MICON | L 0801 | 87-A50-434-010 | 0E | COIL,CLK 4.19M(TOKO) | EZBM | AV-D77 |
| | O | MICON | L 0801 | 87-A50-434-010 | 0E | COIL,CLK 4.19M(TOKO) | UBM | AV-D77 |
| | O | MICON | LED0703 | 87-A40-317-010 | | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0703 | 87-A40-317-010 | 0E | LED,SLR-342VCT31 RED | EZBM | AV-D77 |
| | O | MICON | LED0703 | 87-A40-317-010 | 0E | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0704 | 87-A40-317-080 | | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0704 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | EZBM | AV-D77 |
| | O | MICON | LED0704 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0705 | 87-A40-317-080 | | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0705 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | EZBM | AV-D77 |
| | O | MICON | LED0705 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0706 | 87-A40-317-080 | | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0706 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | EZBM | AV-D77 |
| | O | MICON | LED0706 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0707 | 87-A40-317-080 | | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0707 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | EZBM | AV-D77 |
| | O | MICON | LED0707 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0708 | 87-A40-317-080 | | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0708 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | EZBM | AV-D77 |
| | O | MICON | LED0708 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0709 | 87-A40-317-080 | | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0709 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | EZBM | AV-D77 |
| | O | MICON | LED0709 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0710 | 87-A40-317-080 | | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0710 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | EZBM | AV-D77 |
| | O | MICON | LED0710 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0711 | 87-A40-317-080 | | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0711 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | EZBM | AV-D77 |
| | O | MICON | LED0711 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0712 | 87-A40-317-080 | | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | O | MICON | LED0712 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | EZBM | AV-D77 |
| | O | MICON | LED0712 | 87-A40-317-080 | 0E | LED,SLR-342VCT31 RED | UBM | AV-D77 |
| | X | MICON | PR 0801 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | MICON | PR 0801 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | S | MICON | Q 0719 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0719 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | MICON | Q 0719 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0720 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0720 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | MICON | Q 0720 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0721 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0721 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | MICON | Q 0721 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0722 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0722 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | MICON | Q 0722 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0723 | 89-112-965-080 | | TR,2SA1296GR | UBM | AV-D77 |
| | S | MICON | Q 0723 | 89-112-965-080 | 0E | TR,2SA1296GR | EZBM | AV-D77 |
| | S | MICON | Q 0723 | 89-112-965-080 | 0E | TR,2SA1296GR | UBM | AV-D77 |
| | S | MICON | Q 0724 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0724 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | MICON | Q 0724 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0801 | 87-A30-074-080 | | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | MICON | Q 0801 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | EZBM | AV-D77 |
| | S | MICON | Q 0801 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | MICON | Q 0802 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | MICON | Q 0802 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | MICON | Q 0802 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0803 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | MICON | Q 0803 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | MICON | Q 0803 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | MICON | Q 0804 | 87-026-610-080 | | TR,KTC3198GR | UBM | AV-D77 |
| | S | MICON | Q 0804 | 87-026-610-080 | 0E | TR,KTC3198GR | EZBM | AV-D77 |
| | S | MICON | Q 0804 | 87-026-610-080 | 0E | TR,KTC3198GR | UBM | AV-D77 |
| | S | MICON | Q 0805 | 87-A30-074-080 | | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | MICON | Q 0805 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | EZBM | AV-D77 |
| | S | MICON | Q 0805 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | MICON | Q 0806 | 87-A30-087-080 | | C-FET,2SK2158 | UBM | AV-D77 |
| | S | MICON | Q 0806 | 87-A30-087-080 | 0E | C-FET,2SK2158 | EZBM | AV-D77 |
| | S | MICON | Q 0806 | 87-A30-087-080 | 0E | C-FET,2SK2158 | UBM | AV-D77 |
| | S | MICON | Q 0807 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0807 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | MICON | Q 0807 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0808 | 87-A30-071-080 | | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0808 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | EZBM | AV-D77 |
| | S | MICON | Q 0808 | 87-A30-071-080 | 0E | C-TR,RT1N 144C | UBM | AV-D77 |
| | S | MICON | Q 0809 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | MICON | Q 0809 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | MICON | Q 0809 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | X | MICON | R 0701 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0701 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0701 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0702 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0702 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0702 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0703 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0703 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0703 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0704 | 88-121-103-080 | | RES,10K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0704 | 88-121-103-080 | 0E | RES,10K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0704 | 88-121-103-080 | 0E | RES,10K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0705 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0710 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0710 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0710 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0711 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0711 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0711 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0712 | 88-118-683-080 | 0E | C-RES,S 68K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0712 | 88-118-683-080 | 0E | C-RES,S 68K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0721 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0721 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0721 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0722 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0722 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0722 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0732 | 88-118-681-080 | | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0732 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0732 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0733 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0733 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0733 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0734 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0734 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0734 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0735 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0735 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0735 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0736 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0736 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0736 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0737 | 88-121-473-080 | | RES,47K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0737 | 88-121-473-080 | 0E | RES,47K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0737 | 88-121-473-080 | 0E | RES,47K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0738 | 88-121-473-080 | | RES,47K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0738 | 88-121-473-080 | 0E | RES,47K-1/8W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | R 0738 | 88-121-473-080 | 0E | RES,47K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0739 | 88-121-473-080 | | RES,47K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0739 | 88-121-473-080 | 0E | RES,47K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0739 | 88-121-473-080 | 0E | RES,47K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0740 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0740 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0740 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0741 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0741 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0741 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0742 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0742 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0742 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0743 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0743 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0743 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0744 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0744 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0744 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0745 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0745 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0745 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0746 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0746 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0746 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0747 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0747 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0747 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0748 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0748 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0748 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0749 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0749 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0749 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0750 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0750 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0750 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0751 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0751 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0751 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0752 | 88-128-472-080 | | C-RES, 4.7K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0752 | 88-128-472-080 | 0E | C-RES, 4.7K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0752 | 88-128-472-080 | 0E | C-RES, 4.7K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0753 | 88-128-222-080 | | C-RES, 2.2K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0753 | 88-128-222-080 | 0E | C-RES, 2.2K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0753 | 88-128-222-080 | 0E | C-RES, 2.2K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0754 | 88-121-103-080 | | RES,10K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0754 | 88-121-103-080 | 0E | RES,10K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0754 | 88-121-103-080 | 0E | RES,10K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0755 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0755 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0755 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0756 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0756 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0756 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0757 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0757 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0757 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0758 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0758 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0758 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0759 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0759 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0759 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0761 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0761 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0761 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0762 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | MICON | R 0762 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | MICON | R 0762 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | R 0763 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0763 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0763 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0764 | 88-121-331-080 | | RES,330-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0764 | 88-121-331-080 | 0E | RES,330-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0764 | 88-121-331-080 | 0E | RES,330-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0765 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0765 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0765 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0766 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0766 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0766 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0767 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0767 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0767 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0768 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0768 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0768 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0769 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0769 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0769 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0770 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0770 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0770 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0771 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0771 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0771 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0772 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0772 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0772 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0773 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0773 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0773 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0800 | 88-118-122-080 | | C-RES,S 1.2K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0800 | 88-118-122-080 | 0E | C-RES,S 1.2K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0800 | 88-118-122-080 | 0E | C-RES,S 1.2K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0801 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0801 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0801 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0802 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0802 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0802 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0803 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0803 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0803 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0804 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0804 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0804 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0805 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0805 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0805 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0806 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0806 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0806 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0807 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0807 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0807 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0808 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0808 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0808 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0809 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0809 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0809 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0811 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0811 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0811 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0814 | 88-121-104-080 | | RES,100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0814 | 88-121-104-080 | 0E | RES,100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0814 | 88-121-104-080 | 0E | RES,100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0815 | 88-121-104-080 | | RES,100K-1/8W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | R 0815 | 88-121-104-080 | 0E | RES,100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0815 | 88-121-104-080 | 0E | RES,100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0816 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0816 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0816 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0817 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0817 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0817 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0818 | 88-118-333-080 | | C-RES,S 33K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0818 | 88-118-333-080 | 0E | C-RES,S 33K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0818 | 88-118-333-080 | 0E | C-RES,S 33K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0819 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0819 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0819 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0820 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0820 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0820 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0821 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0821 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0821 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0822 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0822 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0822 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0823 | 88-128-180-080 | | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0823 | 88-128-180-080 | 0E | C-RES, 18-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0823 | 88-128-180-080 | 0E | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0824 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | R 0824 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | R 0824 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | R 0825 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | R 0825 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | R 0825 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | R 0826 | 88-118-471-080 | | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0826 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0826 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0827 | 88-128-272-080 | | C-RES, 2.7K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0827 | 88-128-272-080 | 0E | C-RES, 2.7K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0827 | 88-128-272-080 | 0E | C-RES, 2.7K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0828 | 88-130-479-080 | | RES,4.7-1/4W J | UBM | AV-D77 |
| | X | MICON | R 0828 | 88-130-479-080 | 0E | RES,4.7-1/4W J | EZBM | AV-D77 |
| | X | MICON | R 0828 | 88-130-479-080 | 0E | RES,4.7-1/4W J | UBM | AV-D77 |
| | X | MICON | R 0829 | 88-118-474-080 | | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0829 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0829 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0834 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0834 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0834 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0835 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0835 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0835 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0836 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0836 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0836 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0837 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0837 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0837 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0838 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0838 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0838 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0839 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0839 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0839 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0840 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0840 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0840 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0841 | 88-121-470-080 | | RES,47-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0841 | 88-121-470-080 | 0E | RES,47-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0841 | 88-121-470-080 | 0E | RES,47-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0842 | 88-121-563-080 | | RES,56K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0842 | 88-121-563-080 | 0E | RES,56K-1/8W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | R 0842 | 88-121-563-080 | 0E | RES,56K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0843 | 88-118-273-080 | | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0843 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0843 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0844 | 88-118-682-080 | | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0844 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0844 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0845 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0845 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0845 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0846 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0846 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0846 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0847 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0847 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0847 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0848 | 88-118-273-080 | | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0848 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0848 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0849 | 88-118-682-080 | | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0849 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0849 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0850 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0850 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0850 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0851 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0851 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0851 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0853 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0853 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0853 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0854 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0854 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0854 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0855 | 88-121-821-080 | | RES,820-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0855 | 88-121-821-080 | 0E | RES,820-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0855 | 88-121-821-080 | 0E | RES,820-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0856 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0856 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0856 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0857 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0857 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0857 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0858 | 88-121-122-080 | | RES,1.2K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0858 | 88-121-122-080 | 0E | RES,1.2K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0858 | 88-121-122-080 | 0E | RES,1.2K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0859 | 88-121-152-080 | | RES,1.5K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0859 | 88-121-152-080 | 0E | RES,1.5K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0859 | 88-121-152-080 | 0E | RES,1.5K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0860 | 88-121-222-080 | | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0860 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0860 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0861 | 88-121-272-080 | | RES,2.7K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0861 | 88-121-272-080 | 0E | RES,2.7K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0861 | 88-121-272-080 | 0E | RES,2.7K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0862 | 88-118-332-080 | | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0862 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0862 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0863 | 88-118-392-080 | | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0863 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0863 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0864 | 88-118-682-080 | | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0864 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0864 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0866 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0866 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0866 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0867 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0867 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0867 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | R 0868 | 88-121-821-080 | | RES,820-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0868 | 88-121-821-080 | 0E | RES,820-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0868 | 88-121-821-080 | 0E | RES,820-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0869 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0869 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0869 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0870 | 88-121-103-080 | | RES,10K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0870 | 88-121-103-080 | 0E | RES,10K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0870 | 88-121-103-080 | 0E | RES,10K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0871 | 88-121-103-080 | | RES,10K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0871 | 88-121-103-080 | 0E | RES,10K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0871 | 88-121-103-080 | 0E | RES,10K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0872 | 88-118-561-080 | | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0872 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0872 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0873 | 88-118-561-080 | | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0873 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0873 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0874 | 88-118-561-080 | | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0874 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0874 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0875 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0875 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0875 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0876 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0876 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0876 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0877 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0877 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0877 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0878 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0878 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0878 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0879 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0879 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0879 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0880 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0880 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0880 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0881 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0881 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0881 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0882 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0882 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0882 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0883 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0883 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0883 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0884 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0884 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0884 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0885 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0885 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0885 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0886 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0886 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0886 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0887 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0887 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0887 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0888 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0888 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0888 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0889 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0889 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0889 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0890 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0890 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0890 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0891 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | R 0891 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0891 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0892 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0892 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0892 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0893 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0893 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0893 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0894 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0894 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0894 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0895 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0895 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0895 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0896 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0896 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0896 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0897 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0897 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0897 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0898 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0898 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0898 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0899 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0899 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0899 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0900 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0900 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0900 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0901 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0901 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0901 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0902 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0902 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0902 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0903 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0903 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0903 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0904 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0904 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0904 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0905 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0905 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0905 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0906 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0906 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0906 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0907 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0907 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0907 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0908 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0908 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0908 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0909 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0909 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0909 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0910 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0910 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0910 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0911 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0911 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0911 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0912 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0912 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0912 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0913 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0913 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0913 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0914 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0914 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | R 0914 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0915 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0915 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0915 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0916 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0916 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0916 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0917 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0917 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0917 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0918 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0918 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0918 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0920 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0920 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0920 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0921 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0921 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0921 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0922 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0922 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0922 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0923 | 88-128-104-080 | | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0923 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0923 | 88-128-104-080 | 0E | C-RES, 100K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0924 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | MICON | R 0924 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | MICON | R 0924 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | MICON | R 0925 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0925 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0925 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0926 | 88-128-152-080 | | C-RES, 1.5K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0926 | 88-128-152-080 | 0E | C-RES, 1.5K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0926 | 88-128-152-080 | 0E | C-RES, 1.5K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0927 | 88-121-682-080 | | RES,6.8K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0927 | 88-121-682-080 | 0E | RES,6.8K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0927 | 88-121-682-080 | 0E | RES,6.8K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0928 | 88-121-682-080 | | RES,6.8K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0928 | 88-121-682-080 | 0E | RES,6.8K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0928 | 88-121-682-080 | 0E | RES,6.8K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0929 | 88-128-152-080 | | C-RES, 1.5K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0929 | 88-128-152-080 | 0E | C-RES, 1.5K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0929 | 88-128-152-080 | 0E | C-RES, 1.5K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0930 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | MICON | R 0930 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | MICON | R 0930 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | MICON | R 0931 | 88-128-223-080 | | C-RES, 22K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0931 | 88-128-223-080 | 0E | C-RES, 22K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0931 | 88-128-223-080 | 0E | C-RES, 22K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0932 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0932 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0932 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0933 | 88-118-221-080 | 0E | C-RES,S 220-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0934 | 88-118-221-080 | 0E | C-RES,S 220-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0935 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0936 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0936 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0936 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0937 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0937 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0937 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0938 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0938 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0938 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0939 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0939 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0939 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0940 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0940 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0940 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | R 0941 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0941 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0943 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0943 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0943 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0944 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0944 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0944 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0945 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0945 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0945 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0946 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0946 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0946 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0947 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0947 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0947 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0948 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0948 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0948 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0949 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0949 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0949 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0950 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | R 0950 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | R 0950 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | R 0951 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | R 0951 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | MICON | R 0951 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | MICON | R 0959 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0959 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0959 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0960 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0960 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0960 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0961 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0961 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0961 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0962 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0962 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0962 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0963 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0963 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0963 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0964 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0964 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0964 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0965 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0965 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0965 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0966 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0966 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0966 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0967 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0967 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0967 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0968 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0968 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0968 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0969 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0969 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0969 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0970 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0970 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0970 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0971 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0971 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0971 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0972 | 88-121-223-080 | | RES,22K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0972 | 88-121-223-080 | 0E | RES,22K-1/8W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | MICON | R 0972 | 88-121-223-080 | 0E | RES,22K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0975 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0975 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0975 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0976 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0976 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | MICON | R 0976 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | MICON | R 0979 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0979 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0979 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0980 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | MICON | R 0980 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | MICON | R 0980 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | O | MICON | S 0801 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0801 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0801 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0802 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0802 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0802 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0803 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0804 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0805 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0806 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0806 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0806 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0807 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0807 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0807 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0808 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0808 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0808 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0809 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0809 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0809 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0812 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0812 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0812 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0813 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0813 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0813 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0814 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0814 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0814 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0815 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0815 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0815 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0816 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0816 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0816 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0817 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | S 0817 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | MICON | S 0817 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | MICON | SW 0801 | 87-A91-646-010 | | SW,RTRY EC12E12204 | UBM | AV-D77 |
| | O | MICON | SW 0801 | 87-A91-646-010 | 1A | SW,RTRY EC12E12204 | EZBM | AV-D77 |
| | O | MICON | SW 0801 | 87-A91-646-010 | 1A | SW,RTRY EC12E12204 | UBM | AV-D77 |
| | O | MICON | SW 0802 | 87-A91-647-010 | | SW,RTRY EC12E12504 | UBM | AV-D77 |
| | O | MICON | SW 0802 | 87-A91-647-010 | 1A | SW,RTRY EC12E12504 | EZBM | AV-D77 |
| | O | MICON | SW 0802 | 87-A91-647-010 | 1A | SW,RTRY EC12E12504 | UBM | AV-D77 |
| | X | OTHERS | | 86-AR5-221-010 | | CUSH,PL | UBM | AV-D77 |
| | X | OTHERS | | 86-AR5-221-010 | 0E | CUSH,PL | EZBM | AV-D77 |
| | X | OTHERS | | 86-AR5-221-010 | 0E | CUSH,PL | UBM | AV-D77 |
| | X | OTHERS | | 86-NFZ-205-010 | | CUSH, 12.5-15.5-2 (NP) | UBM | AV-D77 |
| ! | X | OTHERS | | 86-NFZ-205-010 | 0E | CUSH, 12.5-15.5-2 (NP) | EZBM | AV-D77 |
| ! | X | OTHERS | | 86-NFZ-205-010 | 0E | CUSH, 12.5-15.5-2 (NP) | UBM | AV-D77 |
| | O | OTHERS | | 87-033-209-010 | | TERMINAL,EARTH 1P | UBM | AV-D77 |
| | O | OTHERS | | 87-033-209-010 | 0E | TERMINAL,EARTH 1P | EZBM | AV-D77 |
| | O | OTHERS | | 87-033-209-010 | 0E | TERMINAL,EARTH 1P | UBM | AV-D77 |
| | X | OTHERS | | 87-064-080-010 | | BINDER,WIRE | UBM | AV-D77 |
| | X | OTHERS | | 87-064-080-010 | 0E | BINDER,WIRE | EZBM | AV-D77 |
| | X | OTHERS | | 87-064-080-010 | 0E | BINDER,WIRE | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | OTHERS | | 87-067-058-010 | | W-F,3.2-8-0.5 W/ADH | UBM | AV-D77 |
| | O | OTHERS | | 87-067-058-010 | 0E | W-F,3.2-8-0.5 W/ADH | EZBM | AV-D77 |
| | O | OTHERS | | 87-067-058-010 | 0E | W-F,3.2-8-0.5 W/ADH | UBM | AV-D77 |
| | O | OTHERS | | 87-084-077-010 | | RIVET, NYL3.5-4.5 | UBM | AV-D77 |
| | O | OTHERS | | 87-084-077-010 | 0E | RIVET, NYL3.5-4.5 | EZBM | AV-D77 |
| | O | OTHERS | | 87-084-077-010 | 0E | RIVET, NYL3.5-4.5 | UBM | AV-D77 |
| | O | OTHERS | | 88-AR1-203-010 | | HLDR,TU | UBM | AV-D77 |
| ! | O | OTHERS | | 88-AR1-203-010 | 0E | HLDR,TU | EZBM | AV-D77 |
| ! | O | OTHERS | | 88-AR1-203-010 | 0E | HLDR,TU | UBM | AV-D77 |
| | O | OTHERS | | 88-AR1-218-010 | | HLDR,PWB H8.9 | UBM | AV-D77 |
| | O | OTHERS | | 88-AR1-218-010 | 0E | HLDR,PWB H8.9 | EZBM | AV-D77 |
| | O | OTHERS | | 88-AR1-218-010 | 0E | HLDR,PWB H8.9 | UBM | AV-D77 |
| | X | OTHERS | | 88-AR2-210-010 | | CUSH,PL C | UBM | AV-D77 |
| | X | OTHERS | | 88-AR2-210-010 | 0E | CUSH,PL C | EZBM | AV-D77 |
| | X | OTHERS | | 88-AR2-210-010 | 0E | CUSH,PL C | UBM | AV-D77 |
| | X | OTHERS | | 88-NF5-599-010 | | SH, 2-5-0.4 W/ADH | UBM | AV-D77 |
| | X | OTHERS | | 88-NF5-599-010 | 0E | SH, 2-5-0.4 W/ADH | EZBM | AV-D77 |
| | X | OTHERS | | 88-NF5-599-010 | 0E | SH, 2-5-0.4 W/ADH | UBM | AV-D77 |
| | O | OTHERS | | 8A-AR1-201-010 | 0E | HLDR,EQ PWB | EZBM | AV-D77 |
| | X | OTHERS | | 8A-AR2-202-010 | | PLATE,PWB PT U | UBM | AV-D77 |
| | X | OTHERS | | 8A-AR2-202-010 | 1B | PLATE,PWB PT U | EZBM | AV-D77 |
| | X | OTHERS | | 8A-AR2-202-010 | 1B | PLATE,PWB PT U | UBM | AV-D77 |
| | X | OTHERS | | 8A-AR2-203-010 | -- | SH, PC 35-35-0.5 W/ADH | EZBM | AV-D77 |
| | X | OTHERS | | 8A-AR2-210-010 | | SH, 2.5-4.5-0.6 W/ADH | UBM | AV-D77 |
| | X | OTHERS | | 8A-AR2-210-010 | 0E | SH, 2.5-4.5-0.6 W/ADH | EZBM | AV-D77 |
| | X | OTHERS | | 8A-AR2-210-010 | 0E | SH, 2.5-4.5-0.6 W/ADH | UBM | AV-D77 |
| | X | OTHERS | | 8A-AR3-203-010 | | HT-SINK,TR VM | UBM | AV-D77 |
| | X | OTHERS | | 8A-AR3-203-010 | 1E | HT-SINK,TR VM | EZBM | AV-D77 |
| | X | OTHERS | | 8A-AR3-203-010 | 1E | HT-SINK,TR VM | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-202-010 | | CHAS,FR | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-202-210 | 1C | CHAS,FR | EZBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-202-210 | 1C | CHAS,FR | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-204-210 | | PLATE,PT | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-204-210 | 1C | PLATE,PT | EZBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-204-210 | 1C | PLATE,PT | UBM | AV-D77 |
| | O | OTHERS | | 8Z-AR1-205-010 | | HLDR,HT-SINK | UBM | AV-D77 |
| | O | OTHERS | | 8Z-AR1-205-010 | 1D | HLDR,HT-SINK | EZBM | AV-D77 |
| | O | OTHERS | | 8Z-AR1-205-010 | 1D | HLDR,HT-SINK | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-214-010 | | HT-SINK,FIN 85 | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-214-010 | -- | HT-SINK,FIN 85 | EZBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-214-010 | -- | HT-SINK,FIN 85 | UBM | AV-D77 |
| | O | OTHERS | | 8Z-AR1-219-110 | | HLDR,PWB PRO | UBM | AV-D77 |
| | O | OTHERS | | 8Z-AR1-219-110 | 1A | HLDR,PWB PRO | EZBM | AV-D77 |
| | O | OTHERS | | 8Z-AR1-219-110 | 1A | HLDR,PWB PRO | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-236-010 | | PLATE,BOTTOM B | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-236-010 | 1A | PLATE,BOTTOM B | EZBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-236-010 | 1A | PLATE,BOTTOM B | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-239-010 | | HT-SINK,MAIN EZ | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-239-010 | -- | HT-SINK,MAIN EZ | EZBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-239-010 | -- | HT-SINK,MAIN EZ | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-240-010 | | HT-SINK,ASSY85 EZ | UBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-240-010 | 2B | HT-SINK,ASSY85 EZ | EZBM | AV-D77 |
| | X | OTHERS | | 8Z-AR1-240-010 | 2B | HT-SINK,ASSY85 EZ | UBM | AV-D77 |
| | O | OTHERS | | 8Z-NB8-240-010 | | COVER, PL | UBM | AV-D77 |
| | O | OTHERS | | 8Z-NB8-240-010 | 0E | COVER, PL | EZBM | AV-D77 |
| | O | OTHERS | | 8Z-NB8-240-010 | 0E | COVER, PL | UBM | AV-D77 |
| | X | PACKING DU | | 87-B40-098-010 | 0E | BAG,PV 0.025-650-750 PL | EZBM | AV-D77 |
| | X | PACKING DU | | 87-B40-098-010 | 0E | BAG,PV 0.025-650-750 PL | UBM | AV-D77 |
| G | X | PACKING DU | | 87-B40-098-010 | | BAG,PV 0.025-650-750 PL | UBM | AV-D77 |
| | X | PACKING DU | | 8A-AR2-851-110 | 1H | CUSHION,LEFT M | EZBM | AV-D77 |
| | X | PACKING DU | | 8A-AR2-851-110 | 1H | CUSHION,LEFT M | UBM | AV-D77 |
| G | X | PACKING DU | | 8A-AR2-851-110 | | CUSHION,LEFT M | UBM | AV-D77 |
| | X | PACKING DU | | 8A-AR2-852-010 | 1F | CUSHION,RIGHT M | EZBM | AV-D77 |
| | X | PACKING DU | | 8A-AR2-852-010 | 1F | CUSHION,RIGHT M | UBM | AV-D77 |
| G | X | PACKING DU | | 8A-AR2-852-010 | | CUSHION,RIGHT M | UBM | AV-D77 |
| | X | PACKING DU | | 8A-AR2-854-010 | 1H | CTN,PRINTED 77EZBM | EZBM | AV-D77 |
| | X | PACKING DU | | 8A-AR2-855-010 | 2A | CTN,PRINTED 77UBM | UBM | AV-D77 |
| G | X | PACKING DU | | 8A-AR2-855-010 | | CTN,PRINTED 77UBM | UBM | AV-D77 |
| | X | PACKING DU | | 92-370-716-010 | 1A | SH,FOAMED-MAT 0.31-700-500 | EZBM | AV-D77 |
| | X | PACKING DU | | 92-370-716-010 | 1A | SH,FOAMED-MAT 0.31-700-500 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| G | X | PACKING DU | | 92-370-716-010 | | SH,FOAMED-MAT 0.31-700-500 | UBM | AV-D77 |
| | X | PLATE | | 87-057-745-010 | 1B | LBL,CAUTION S | UBM | AV-D77 |
| G | X | PLATE | | 87-057-745-010 | | LBL,CAUTION S | UBM | AV-D77 |
| | X | PLATE | | 87-B40-281-010 | 0E | LBL,BAR-CODE A 35X8 | EZBM | AV-D77 |
| | X | PLATE | | 87-B40-282-010 | 0E | LBL,BAR-CODE AU 35X8 | UBM | AV-D77 |
| G | X | PLATE | | 87-B40-282-010 | | LBL,BAR-CODE AU 35X8 | UBM | AV-D77 |
| | O | PLATE | | 8A-AR1-009-010 | | WINDOW,DISP DTS | UBM | AV-D77 |
| | O | PLATE | | 8A-AR1-009-010 | 1B | WINDOW,DISP DTS | UBM | AV-D77 |
| | O | PLATE | | 8A-AR2-006-010 | 1B | WINDOW,DISP DIGI EZ | EZBM | AV-D77 |
| | O | PLATE | | 8A-AR3-009-010 | | REFLECTOR,FUN | UBM | AV-D77 |
| | O | PLATE | | 8A-AR3-009-010 | 0E | REFLECTOR,FUN | EZBM | AV-D77 |
| | O | PLATE | | 8A-AR3-009-010 | 0E | REFLECTOR,FUN | UBM | AV-D77 |
| | O | PLATE | | 8A-AR3-010-010 | | REFLECTOR,ECO | UBM | AV-D77 |
| | O | PLATE | | 8A-AR3-010-010 | 0E | REFLECTOR,ECO | EZBM | AV-D77 |
| | O | PLATE | | 8A-AR3-010-010 | 0E | REFLECTOR,ECO | UBM | AV-D77 |
| | O | POWER AMP | C 0203 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0203 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0203 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0204 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0204 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0204 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0205 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0205 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0205 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0206 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0206 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0206 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0209 | 87-010-406-080 | | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0209 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0209 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0210 | 87-010-406-080 | | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0210 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0210 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0211 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0211 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | POWER AMP | C 0211 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0212 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0212 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | POWER AMP | C 0212 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0215 | 87-A10-897-080 | | CAP,E 100-25 BP SME | UBM | AV-D77 |
| | O | POWER AMP | C 0215 | 87-A10-897-080 | 0E | CAP,E 100-25 BP SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0215 | 87-A10-897-080 | 0E | CAP,E 100-25 BP SME | UBM | AV-D77 |
| | O | POWER AMP | C 0216 | 87-A10-897-080 | | CAP,E 100-25 BP SME | UBM | AV-D77 |
| | O | POWER AMP | C 0216 | 87-A10-897-080 | 0E | CAP,E 100-25 BP SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0216 | 87-A10-897-080 | 0E | CAP,E 100-25 BP SME | UBM | AV-D77 |
| | O | POWER AMP | C 0217 | 87-A10-516-080 | | C-CAP,S 100P-200 J CH | UBM | AV-D77 |
| | O | POWER AMP | C 0217 | 87-A12-313-080 | -- | C-CAP,S 150P-200 J CH | EZBM | AV-D77 |
| | O | POWER AMP | C 0217 | 87-A12-313-080 | -- | C-CAP,S 150P-200 J CH | UBM | AV-D77 |
| | O | POWER AMP | C 0218 | 87-A10-516-080 | | C-CAP,S 100P-200 J CH | UBM | AV-D77 |
| | O | POWER AMP | C 0218 | 87-A12-313-080 | -- | C-CAP,S 150P-200 J CH | EZBM | AV-D77 |
| | O | POWER AMP | C 0218 | 87-A12-313-080 | -- | C-CAP,S 150P-200 J CH | UBM | AV-D77 |
| | X | POWER AMP | C 0219 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | C 0219 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | C 0219 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | C 0220 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | C 0220 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | C 0220 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | O | POWER AMP | C 0221 | 87-016-526-080 | | C-CAP,S 0.47-16 BK | UBM | AV-D77 |
| | O | POWER AMP | C 0221 | 87-016-526-080 | 0E | C-CAP,S 0.47-16 BK | EZBM | AV-D77 |
| | O | POWER AMP | C 0221 | 87-016-526-080 | 0E | C-CAP,S 0.47-16 BK | UBM | AV-D77 |
| | O | POWER AMP | C 0222 | 87-016-526-080 | | C-CAP,S 0.47-16 BK | UBM | AV-D77 |
| | O | POWER AMP | C 0222 | 87-016-526-080 | 0E | C-CAP,S 0.47-16 BK | EZBM | AV-D77 |
| | O | POWER AMP | C 0222 | 87-016-526-080 | 0E | C-CAP,S 0.47-16 BK | UBM | AV-D77 |
| | O | POWER AMP | C 0223 | 87-010-402-080 | | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0223 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0223 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0224 | 87-010-402-080 | | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0224 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0224 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0225 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | POWER AMP | C 0225 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0225 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0226 | 87-016-251-080 | | CAP,E 220-16 M SMG | UBM | AV-D77 |
| | O | POWER AMP | C 0226 | 87-016-251-080 | 0E | CAP,E 220-16 M SMG | EZBM | AV-D77 |
| | O | POWER AMP | C 0226 | 87-016-251-080 | 0E | CAP,E 220-16 M SMG | UBM | AV-D77 |
| | O | POWER AMP | C 0227 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0227 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0227 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0228 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0228 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0228 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0229 | 87-016-251-080 | | CAP,E 220-16 M SMG | UBM | AV-D77 |
| | O | POWER AMP | C 0229 | 87-016-251-080 | 0E | CAP,E 220-16 M SMG | EZBM | AV-D77 |
| | O | POWER AMP | C 0229 | 87-016-251-080 | 0E | CAP,E 220-16 M SMG | UBM | AV-D77 |
| | O | POWER AMP | C 0230 | 87-A10-354-080 | | C-CAP,S 0.047-50 K B | UBM | AV-D77 |
| | O | POWER AMP | C 0230 | 87-A10-354-080 | 0E | C-CAP,S 0.047-50 K B | EZBM | AV-D77 |
| | O | POWER AMP | C 0230 | 87-A10-354-080 | 0E | C-CAP,S 0.047-50 K B | UBM | AV-D77 |
| | O | POWER AMP | C 0231 | 87-A10-354-080 | | C-CAP,S 0.047-50 K B | UBM | AV-D77 |
| | O | POWER AMP | C 0231 | 87-A10-354-080 | 0E | C-CAP,S 0.047-50 K B | EZBM | AV-D77 |
| | O | POWER AMP | C 0231 | 87-A10-354-080 | 0E | C-CAP,S 0.047-50 K B | UBM | AV-D77 |
| | O | POWER AMP | C 0285 | 87-010-186-080 | | C-CAP,S 4700P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0285 | 87-010-186-080 | 0E | C-CAP,S 4700P-50 K B C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0285 | 87-010-186-080 | 0E | C-CAP,S 4700P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0287 | 87-010-190-080 | | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0287 | 87-010-190-080 | 0E | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0288 | 87-010-190-080 | | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0288 | 87-010-190-080 | 0E | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0289 | 87-010-190-080 | | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0289 | 87-010-190-080 | 0E | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0290 | 87-010-190-080 | | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0290 | 87-010-190-080 | 0E | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0291 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0291 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0291 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0292 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0292 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0292 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0293 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0293 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0293 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0294 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0294 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0294 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0295 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0295 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0295 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0296 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0296 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0296 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0297 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0297 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0297 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0298 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0298 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0298 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0303 | 87-010-179-080 | | C-CAP,S 1200P-50 K B GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0303 | 87-010-179-080 | 0E | C-CAP,S 1200P-50 K B GRM | EZBM | AV-D77 |
| | O | POWER AMP | C 0303 | 87-010-179-080 | 0E | C-CAP,S 1200P-50 K B GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0304 | 87-010-179-080 | | C-CAP,S 1200P-50 K B GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0304 | 87-010-179-080 | 0E | C-CAP,S 1200P-50 K B GRM | EZBM | AV-D77 |
| | O | POWER AMP | C 0304 | 87-010-179-080 | 0E | C-CAP,S 1200P-50 K B GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0305 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0305 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0305 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0306 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0306 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0306 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0308 | 87-016-299-080 | | CAP,E 10-100 M SME | UBM | AV-D77 |
| | O | POWER AMP | C 0308 | 87-016-299-080 | 0E | CAP,E 10-100 M SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0308 | 87-016-299-080 | 0E | CAP,E 10-100 M SME | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | POWER AMP | C 0309 | 87-010-406-080 | | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0309 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0309 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0310 | 87-010-406-080 | | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0310 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0310 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0311 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0311 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | POWER AMP | C 0311 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0312 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0312 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | POWER AMP | C 0312 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0315 | 87-A10-897-080 | | CAP,E 100-25 BP SME | UBM | AV-D77 |
| | O | POWER AMP | C 0315 | 87-A10-897-080 | 0E | CAP,E 100-25 BP SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0315 | 87-A10-897-080 | 0E | CAP,E 100-25 BP SME | UBM | AV-D77 |
| | O | POWER AMP | C 0316 | 87-A10-897-080 | | CAP,E 100-25 BP SME | UBM | AV-D77 |
| | O | POWER AMP | C 0316 | 87-A10-897-080 | 0E | CAP,E 100-25 BP SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0316 | 87-A10-897-080 | 0E | CAP,E 100-25 BP SME | UBM | AV-D77 |
| | O | POWER AMP | C 0317 | 87-A10-516-080 | | C-CAP,S 100P-200 J CH | UBM | AV-D77 |
| | O | POWER AMP | C 0317 | 87-A12-313-080 | -- | C-CAP,S 150P-200 J CH | EZBM | AV-D77 |
| | O | POWER AMP | C 0317 | 87-A12-313-080 | -- | C-CAP,S 150P-200 J CH | UBM | AV-D77 |
| | O | POWER AMP | C 0318 | 87-A10-516-080 | | C-CAP,S 100P-200 J CH | UBM | AV-D77 |
| | O | POWER AMP | C 0318 | 87-A12-313-080 | -- | C-CAP,S 150P-200 J CH | EZBM | AV-D77 |
| | O | POWER AMP | C 0318 | 87-A12-313-080 | -- | C-CAP,S 150P-200 J CH | UBM | AV-D77 |
| | O | POWER AMP | C 0321 | 87-016-526-080 | | C-CAP,S 0.47-16 BK | UBM | AV-D77 |
| | O | POWER AMP | C 0321 | 87-016-526-080 | 0E | C-CAP,S 0.47-16 BK | EZBM | AV-D77 |
| | O | POWER AMP | C 0321 | 87-016-526-080 | 0E | C-CAP,S 0.47-16 BK | UBM | AV-D77 |
| | O | POWER AMP | C 0322 | 87-016-526-080 | | C-CAP,S 0.47-16 BK | UBM | AV-D77 |
| | O | POWER AMP | C 0322 | 87-016-526-080 | 0E | C-CAP,S 0.47-16 BK | EZBM | AV-D77 |
| | O | POWER AMP | C 0322 | 87-016-526-080 | 0E | C-CAP,S 0.47-16 BK | UBM | AV-D77 |
| | O | POWER AMP | C 0323 | 87-010-402-080 | | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0323 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0323 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0324 | 87-010-402-080 | | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0324 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0324 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0325 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0325 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0325 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0327 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0327 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0327 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0328 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0328 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0328 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0330 | 87-A10-354-080 | | C-CAP,S 0.047-50 K B | UBM | AV-D77 |
| | O | POWER AMP | C 0330 | 87-A10-354-080 | 0E | C-CAP,S 0.047-50 K B | EZBM | AV-D77 |
| | O | POWER AMP | C 0330 | 87-A10-354-080 | 0E | C-CAP,S 0.047-50 K B | UBM | AV-D77 |
| | O | POWER AMP | C 0331 | 87-A10-354-080 | | C-CAP,S 0.047-50 K B | UBM | AV-D77 |
| | O | POWER AMP | C 0331 | 87-A10-354-080 | 0E | C-CAP,S 0.047-50 K B | EZBM | AV-D77 |
| | O | POWER AMP | C 0331 | 87-A10-354-080 | 0E | C-CAP,S 0.047-50 K B | UBM | AV-D77 |
| | O | POWER AMP | C 0334 | 87-A10-918-080 | | CAP,E 100-16 SMG | UBM | AV-D77 |
| | O | POWER AMP | C 0334 | 87-A10-918-080 | 0E | CAP,E 100-16 SMG | EZBM | AV-D77 |
| | O | POWER AMP | C 0334 | 87-A10-918-080 | 0E | CAP,E 100-16 SMG | UBM | AV-D77 |
| | O | POWER AMP | C 0335 | 87-A10-918-080 | | CAP,E 100-16 SMG | UBM | AV-D77 |
| | O | POWER AMP | C 0335 | 87-A10-918-080 | 0E | CAP,E 100-16 SMG | EZBM | AV-D77 |
| | O | POWER AMP | C 0335 | 87-A10-918-080 | 0E | CAP,E 100-16 SMG | UBM | AV-D77 |
| | O | POWER AMP | C 0385 | 87-010-186-080 | | C-CAP,S 4700P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0385 | 87-010-186-080 | 0E | C-CAP,S 4700P-50 K B C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0385 | 87-010-186-080 | 0E | C-CAP,S 4700P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0391 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0391 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0391 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0392 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0392 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0392 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0393 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0393 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0393 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0394 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | POWER AMP | C 0394 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0394 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0395 | 87-010-190-080 | | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0395 | 87-010-190-080 | 0E | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0396 | 87-010-190-080 | | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0396 | 87-010-190-080 | 0E | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0397 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0398 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0402 | 87-010-181-080 | | C-CAP,S 1800P-50 K B GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0402 | 87-010-181-080 | 0E | C-CAP,S 1800P-50 K B GRM | EZBM | AV-D77 |
| | O | POWER AMP | C 0402 | 87-010-181-080 | 0E | C-CAP,S 1800P-50 K B GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0403 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0403 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0403 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0405 | 87-010-406-080 | | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0405 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0405 | 87-010-406-080 | 0E | CAP,E 22-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0406 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0406 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | EZBM | AV-D77 |
| | O | POWER AMP | C 0406 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | POWER AMP | C 0408 | 87-A10-897-080 | | CAP,E 100-25 BP SME | UBM | AV-D77 |
| | O | POWER AMP | C 0408 | 87-A10-897-080 | 0E | CAP,E 100-25 BP SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0408 | 87-A10-897-080 | 0E | CAP,E 100-25 BP SME | UBM | AV-D77 |
| | O | POWER AMP | C 0409 | 87-A10-516-080 | | C-CAP,S 100P-200 J CH | UBM | AV-D77 |
| | O | POWER AMP | C 0409 | 87-A12-313-080 | -- | C-CAP,S 150P-200 J CH | EZBM | AV-D77 |
| | O | POWER AMP | C 0409 | 87-A12-313-080 | -- | C-CAP,S 150P-200 J CH | UBM | AV-D77 |
| | X | POWER AMP | C 0410 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | C 0410 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | C 0410 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | O | POWER AMP | C 0411 | 87-016-526-080 | | C-CAP,S 0.47-16 BK | UBM | AV-D77 |
| | O | POWER AMP | C 0411 | 87-016-526-080 | 0E | C-CAP,S 0.47-16 BK | EZBM | AV-D77 |
| | O | POWER AMP | C 0411 | 87-016-526-080 | 0E | C-CAP,S 0.47-16 BK | UBM | AV-D77 |
| | O | POWER AMP | C 0412 | 87-010-402-080 | | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0412 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER AMP | C 0412 | 87-010-402-080 | 0E | CAP,E 2.2-50 M 11L SME | UBM | AV-D77 |
| | O | POWER AMP | C 0413 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0413 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0413 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0414 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0414 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0414 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0416 | 87-016-299-080 | | CAP,E 10-100 M SME | UBM | AV-D77 |
| | O | POWER AMP | C 0416 | 87-016-299-080 | 0E | CAP,E 10-100 M SME | UBM | AV-D77 |
| | O | POWER AMP | C 0416 | 87-A11-937-080 | 0E | CAP,E 10-100 KME | EZBM | AV-D77 |
| | O | POWER AMP | C 0420 | 87-A10-354-080 | | C-CAP,S 0.047-50 K B | UBM | AV-D77 |
| | O | POWER AMP | C 0420 | 87-A10-354-080 | 0E | C-CAP,S 0.047-50 K B | EZBM | AV-D77 |
| | O | POWER AMP | C 0420 | 87-A10-354-080 | 0E | C-CAP,S 0.047-50 K B | UBM | AV-D77 |
| | O | POWER AMP | C 0485 | 87-010-186-080 | | C-CAP,S 4700P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0485 | 87-010-186-080 | 0E | C-CAP,S 4700P-50 K B C2012 | EZBM | AV-D77 |
| | O | POWER AMP | C 0485 | 87-010-186-080 | 0E | C-CAP,S 4700P-50 K B C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0491 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0491 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0491 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0492 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0492 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0492 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0493 | 87-010-190-080 | | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0493 | 87-010-190-080 | 0E | C-CAP,S 0.01-50 Z F C2012 | UBM | AV-D77 |
| | O | POWER AMP | C 0494 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0745 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0745 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0745 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0746 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | C 0746 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER AMP | C 0746 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER AMP | CNA0201 | 8Z-AR4-606-010 | | CONN ASSY,8P VH | UBM | AV-D77 |
| | O | POWER AMP | CNA0201 | 8Z-AR4-606-010 | 1B | CONN ASSY,8P VH | EZBM | AV-D77 |
| | O | POWER AMP | CNA0201 | 8Z-AR4-606-010 | 1B | CONN ASSY,8P VH | UBM | AV-D77 |
| | O | POWER AMP | CNA0202 | 8Z-AR4-605-010 | | CONN ASSY,6P VH | UBM | AV-D77 |
| | O | POWER AMP | CNA0202 | 8Z-AR4-605-010 | 1A | CONN ASSY,6P VH | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | POWER AMP | CNA0202 | 8Z-AR4-605-010 | 1A | CONN ASSY,6P VH | UBM | AV-D77 |
| | S | POWER AMP | D 0201 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0201 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0201 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0202 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0202 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0202 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0209 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0209 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0209 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0210 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0210 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0210 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0211 | 87-A40-646-010 | | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0211 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | EZBM | AV-D77 |
| | S | POWER AMP | D 0211 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0212 | 87-A40-646-010 | | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0212 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | EZBM | AV-D77 |
| | S | POWER AMP | D 0212 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0213 | 87-070-136-080 | | ZENER,MTZJ5.1B | UBM | AV-D77 |
| | S | POWER AMP | D 0213 | 87-070-136-080 | 0E | ZENER,MTZJ5.1B | UBM | AV-D77 |
| | S | POWER AMP | D 0213 | 87-A40-003-080 | 0E | ZENER,MTZJ4.3A | EZBM | AV-D77 |
| | S | POWER AMP | D 0214 | 87-A40-344-080 | | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | POWER AMP | D 0214 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | EZBM | AV-D77 |
| | S | POWER AMP | D 0214 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | POWER AMP | D 0215 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0215 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0215 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0216 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0216 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0216 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0217 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0217 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0217 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0218 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0218 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0218 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0219 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0219 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0219 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0220 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0220 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0220 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0221 | 87-070-274-080 | | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | POWER AMP | D 0221 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | EZBM | AV-D77 |
| | S | POWER AMP | D 0221 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | POWER AMP | D 0223 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0223 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0223 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0224 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0224 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0224 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0225 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0225 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0225 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0226 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0226 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0226 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0227 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0227 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0227 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0241 | 87-A40-488-080 | | DIODE,1SS244 | UBM | AV-D77 |
| | S | POWER AMP | D 0241 | 87-A40-488-080 | 0E | DIODE,1SS244 | EZBM | AV-D77 |
| | S | POWER AMP | D 0241 | 87-A40-488-080 | 0E | DIODE,1SS244 | UBM | AV-D77 |
| | S | POWER AMP | D 0242 | 87-A40-488-080 | | DIODE,1SS244 | UBM | AV-D77 |
| | S | POWER AMP | D 0242 | 87-A40-488-080 | 0E | DIODE,1SS244 | EZBM | AV-D77 |
| | S | POWER AMP | D 0242 | 87-A40-488-080 | 0E | DIODE,1SS244 | UBM | AV-D77 |
| | S | POWER AMP | D 0243 | 87-A40-345-080 | | ZENER,MTZJ10C | UBM | AV-D77 |
| | S | POWER AMP | D 0243 | 87-A40-345-080 | 0E | ZENER,MTZJ10C | EZBM | AV-D77 |
| | S | POWER AMP | D 0243 | 87-A40-345-080 | 0E | ZENER,MTZJ10C | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | POWER AMP | D 0281 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0281 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0301 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0301 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0301 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0302 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0302 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0302 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0309 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0309 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0309 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0310 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0310 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0310 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0311 | 87-A40-646-010 | | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0311 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | EZBM | AV-D77 |
| | S | POWER AMP | D 0311 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0312 | 87-A40-646-010 | | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0312 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | EZBM | AV-D77 |
| | S | POWER AMP | D 0312 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0313 | 87-070-136-080 | | ZENER,MTZJ5.1B | UBM | AV-D77 |
| | S | POWER AMP | D 0313 | 87-070-136-080 | 0E | ZENER,MTZJ5.1B | EZBM | AV-D77 |
| | S | POWER AMP | D 0313 | 87-070-136-080 | 0E | ZENER,MTZJ5.1B | UBM | AV-D77 |
| | S | POWER AMP | D 0314 | 87-A40-344-080 | | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | POWER AMP | D 0314 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | EZBM | AV-D77 |
| | S | POWER AMP | D 0314 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | POWER AMP | D 0315 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0315 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0315 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0316 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0316 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0316 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0317 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0317 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0317 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0318 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0318 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0318 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0319 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0319 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0319 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0320 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0320 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0320 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0321 | 87-070-274-080 | | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | POWER AMP | D 0321 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | EZBM | AV-D77 |
| | S | POWER AMP | D 0321 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | POWER AMP | D 0323 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0323 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0323 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0324 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0324 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0324 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0325 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0325 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0325 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0341 | 87-A40-488-080 | | DIODE,1SS244 | UBM | AV-D77 |
| | S | POWER AMP | D 0341 | 87-A40-488-080 | 0E | DIODE,1SS244 | EZBM | AV-D77 |
| | S | POWER AMP | D 0341 | 87-A40-488-080 | 0E | DIODE,1SS244 | UBM | AV-D77 |
| | S | POWER AMP | D 0342 | 87-A40-488-080 | | DIODE,1SS244 | UBM | AV-D77 |
| | S | POWER AMP | D 0342 | 87-A40-488-080 | 0E | DIODE,1SS244 | EZBM | AV-D77 |
| | S | POWER AMP | D 0342 | 87-A40-488-080 | 0E | DIODE,1SS244 | UBM | AV-D77 |
| | S | POWER AMP | D 0343 | 87-A40-345-080 | | ZENER,MTZJ10C | UBM | AV-D77 |
| | S | POWER AMP | D 0343 | 87-A40-345-080 | 0E | ZENER,MTZJ10C | EZBM | AV-D77 |
| | S | POWER AMP | D 0343 | 87-A40-345-080 | 0E | ZENER,MTZJ10C | UBM | AV-D77 |
| | S | POWER AMP | D 0345 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0345 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0345 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0346 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0346 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | POWER AMP | D 0346 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0401 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0401 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0401 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0405 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0405 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0405 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0406 | 87-A40-646-010 | | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0406 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | EZBM | AV-D77 |
| | S | POWER AMP | D 0406 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0407 | 87-A40-646-010 | | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0407 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | EZBM | AV-D77 |
| | S | POWER AMP | D 0407 | 87-A40-646-010 | 1B | DIODE,FMB-G16L | UBM | AV-D77 |
| | S | POWER AMP | D 0408 | 87-070-136-080 | | ZENER,MTZJ5.1B | UBM | AV-D77 |
| | S | POWER AMP | D 0408 | 87-070-136-080 | 0E | ZENER,MTZJ5.1B | EZBM | AV-D77 |
| | S | POWER AMP | D 0408 | 87-070-136-080 | 0E | ZENER,MTZJ5.1B | UBM | AV-D77 |
| | S | POWER AMP | D 0409 | 87-A40-344-080 | | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | POWER AMP | D 0409 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | EZBM | AV-D77 |
| | S | POWER AMP | D 0409 | 87-A40-344-080 | 0E | ZENER,MTZJ6.2C | UBM | AV-D77 |
| | S | POWER AMP | D 0410 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0410 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0410 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0411 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0411 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0411 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0412 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0412 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0412 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0413 | 87-070-274-080 | | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | POWER AMP | D 0413 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | EZBM | AV-D77 |
| | S | POWER AMP | D 0413 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | POWER AMP | D 0414 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0414 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0414 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0420 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0420 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0420 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0423 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0423 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0423 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0425 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0425 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0425 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0433 | 87-A40-345-080 | | ZENER,MTZJ10C | UBM | AV-D77 |
| | S | POWER AMP | D 0433 | 87-A40-345-080 | 0E | ZENER,MTZJ10C | EZBM | AV-D77 |
| | S | POWER AMP | D 0433 | 87-A40-345-080 | 0E | ZENER,MTZJ10C | UBM | AV-D77 |
| | S | POWER AMP | D 0441 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0441 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER AMP | D 0441 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0481 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0481 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0801 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER AMP | D 0801 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | X | POWER AMP | EP 0001 | 81-689-212-010 | | PLATE,EARTH | UBM | AV-D77 |
| | X | POWER AMP | EP 0001 | 81-689-212-010 | 0E | PLATE,EARTH | EZBM | AV-D77 |
| | X | POWER AMP | EP 0001 | 81-689-212-010 | 0E | PLATE,EARTH | UBM | AV-D77 |
| | X | POWER AMP | EP 0002 | 81-689-212-010 | | PLATE,EARTH | UBM | AV-D77 |
| | X | POWER AMP | EP 0002 | 81-689-212-010 | 0E | PLATE,EARTH | EZBM | AV-D77 |
| | X | POWER AMP | EP 0002 | 81-689-212-010 | 0E | PLATE,EARTH | UBM | AV-D77 |
| | O | POWER AMP | J 0715 | 87-A61-059-010 | | JACK,PIN 1P BLK W/O SW GOLD | UBM | AV-D77 |
| | O | POWER AMP | J 0715 | 87-A61-059-010 | 1A | JACK,PIN 1P BLK W/O SW GOLD | EZBM | AV-D77 |
| | O | POWER AMP | J 0715 | 87-A61-059-010 | 1A | JACK,PIN 1P BLK W/O SW GOLD | UBM | AV-D77 |
| | X | POWER AMP | JR 0110 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0110 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0110 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0202 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0202 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0202 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0203 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0203 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | JR 0203 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0204 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0204 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0204 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0206 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0206 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0206 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0209 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0209 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0209 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0210 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0210 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0210 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0212 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0212 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0212 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0213 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0213 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0213 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0216 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0216 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0216 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0218 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0218 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0218 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0219 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0219 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0219 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0220 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0220 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0220 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0221 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0221 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0221 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0222 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0222 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0222 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0223 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0223 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0223 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0224 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0224 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0224 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0225 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0225 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0225 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0227 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0227 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0227 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0228 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0228 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0228 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0229 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0229 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0229 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0230 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0230 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0230 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0231 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0231 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0231 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0232 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0232 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0232 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0233 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0233 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0233 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0235 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0235 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0235 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | JR 0236 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0236 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0236 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0237 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0237 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0237 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0239 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0239 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0239 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0240 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0240 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0240 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0242 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0242 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0242 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0243 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0243 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0243 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0244 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0244 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0244 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0245 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0245 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0245 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0246 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0246 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0246 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0289 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0289 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0289 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0299 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0299 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0299 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0301 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0301 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0301 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0302 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0302 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0302 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0304 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0304 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0304 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0305 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0305 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0305 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0306 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0306 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0306 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0307 | 88-148-000-080 | | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER AMP | JR 0307 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | EZBM | AV-D77 |
| | X | POWER AMP | JR 0307 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER AMP | JR 0308 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0308 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0308 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0310 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0310 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0310 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0311 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0311 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0311 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0313 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0313 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0313 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0316 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0316 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0316 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0317 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0317 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0317 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0318 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | JR 0318 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0318 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0322 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0322 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0322 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0323 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0323 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0323 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0324 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0324 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0324 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0325 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0325 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0325 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0326 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0326 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0326 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0328 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0328 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0328 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0329 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0329 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0329 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0330 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0330 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0330 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0331 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0331 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0331 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0332 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0332 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0332 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0333 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0333 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0333 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0334 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0334 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0334 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0335 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0335 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0335 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0338 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0338 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0338 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0339 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0339 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0339 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0341 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0341 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0341 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0359 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0359 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0359 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0402 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0402 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0402 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0403 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0403 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0403 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0404 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0404 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0404 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0406 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0406 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0406 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0407 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0407 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0407 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0408 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0408 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | JR 0408 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0410 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0410 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0410 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0411 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0411 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0411 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0412 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0412 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0412 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0414 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0414 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0414 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0415 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0415 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0415 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0417 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0417 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0417 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0420 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0420 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0420 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0421 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0421 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0421 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0422 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0422 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0422 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0423 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0423 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0423 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0424 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0424 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0424 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0425 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0425 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0425 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0426 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0426 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0426 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0427 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0427 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0427 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0430 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0430 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0430 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0432 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0432 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0432 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0433 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0433 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0433 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0435 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0435 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0435 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0436 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0436 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0436 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0441 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0441 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0441 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0452 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0452 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0452 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0454 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0454 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0454 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0481 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0481 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0481 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | JR 0483 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0483 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0483 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0484 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0484 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0484 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0487 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0487 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0487 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0488 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0488 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0488 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0491 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0491 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0491 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0570 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0570 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0570 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0571 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0571 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0571 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0572 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0572 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0572 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0573 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0573 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0573 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0641 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0641 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0641 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0730 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0730 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0730 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0758 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0758 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | JR 0758 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | JR 0759 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0759 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0759 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0760 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | JR 0760 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | JR 0760 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | POWER AMP | L 0291 | 87-003-383-010 | | COIL,1UH K | UBM | AV-D77 |
| | O | POWER AMP | L 0291 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | EZBM | AV-D77 |
| | O | POWER AMP | L 0291 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | UBM | AV-D77 |
| | O | POWER AMP | L 0292 | 87-003-383-010 | | COIL,1UH K | UBM | AV-D77 |
| | O | POWER AMP | L 0292 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | EZBM | AV-D77 |
| | O | POWER AMP | L 0292 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | UBM | AV-D77 |
| | O | POWER AMP | L 0293 | 87-003-383-010 | | COIL,1UH K | UBM | AV-D77 |
| | O | POWER AMP | L 0293 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | EZBM | AV-D77 |
| | O | POWER AMP | L 0293 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | UBM | AV-D77 |
| | O | POWER AMP | L 0294 | 87-003-383-010 | | COIL,1UH K | UBM | AV-D77 |
| | O | POWER AMP | L 0294 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | EZBM | AV-D77 |
| | O | POWER AMP | L 0294 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | UBM | AV-D77 |
| | O | POWER AMP | L 0391 | 87-003-383-010 | | COIL,1UH K | UBM | AV-D77 |
| | O | POWER AMP | L 0391 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | EZBM | AV-D77 |
| | O | POWER AMP | L 0391 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | UBM | AV-D77 |
| | O | POWER AMP | L 0392 | 87-003-383-010 | | COIL,1UH K | UBM | AV-D77 |
| | O | POWER AMP | L 0392 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | EZBM | AV-D77 |
| | O | POWER AMP | L 0392 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | UBM | AV-D77 |
| | O | POWER AMP | L 0491 | 87-003-383-010 | | COIL,1UH K | UBM | AV-D77 |
| | O | POWER AMP | L 0491 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | EZBM | AV-D77 |
| | O | POWER AMP | L 0491 | 87-A50-610-010 | 0E | COIL,1UH K(MDEC) | UBM | AV-D77 |
| | S | POWER AMP | PR 0201 | 87-026-682-080 | 0E | PROTECTOR,10A 491SERIES 60V | EZBM | AV-D77 |
| | S | POWER AMP | PR 0201 | 87-026-691-080 | | FUSE,10A 125V 251 | UBM | AV-D77 |
| ! | S | POWER AMP | PR 0201 | 87-026-691-080 | 1A | FUSE,10A 125V 251 | UBM | AV-D77 |
| | S | POWER AMP | PR 0202 | 87-026-682-080 | 0E | PROTECTOR,10A 491SERIES 60V | EZBM | AV-D77 |
| | S | POWER AMP | PR 0202 | 87-026-691-080 | | FUSE,10A 125V 251 | UBM | AV-D77 |
| ! | S | POWER AMP | PR 0202 | 87-026-691-080 | 1A | FUSE,10A 125V 251 | UBM | AV-D77 |
| | S | POWER AMP | PR 0301 | 87-026-682-080 | 0E | PROTECTOR,10A 491SERIES 60V | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | POWER AMP | PR 0301 | 87-026-691-080 | | FUSE,10A 125V 251 | UBM | AV-D77 |
| ! | S | POWER AMP | PR 0301 | 87-026-691-080 | 1A | FUSE,10A 125V 251 | UBM | AV-D77 |
| | S | POWER AMP | PR 0302 | 87-026-682-080 | 0E | PROTECTOR,10A 491SERIES 60V | EZBM | AV-D77 |
| | S | POWER AMP | PR 0302 | 87-026-691-080 | | FUSE,10A 125V 251 | UBM | AV-D77 |
| ! | S | POWER AMP | PR 0302 | 87-026-691-080 | 1A | FUSE,10A 125V 251 | UBM | AV-D77 |
| | S | POWER AMP | PR 0401 | 87-026-682-080 | 0E | PROTECTOR,10A 491SERIES 60V | EZBM | AV-D77 |
| | S | POWER AMP | PR 0401 | 87-026-691-080 | | FUSE,10A 125V 251 | UBM | AV-D77 |
| ! | S | POWER AMP | PR 0401 | 87-026-691-080 | 1A | FUSE,10A 125V 251 | UBM | AV-D77 |
| | S | POWER AMP | PR 0402 | 87-026-682-080 | 0E | PROTECTOR,10A 491SERIES 60V | EZBM | AV-D77 |
| | S | POWER AMP | PR 0402 | 87-026-691-080 | | FUSE,10A 125V 251 | UBM | AV-D77 |
| ! | S | POWER AMP | PR 0402 | 87-026-691-080 | 1A | FUSE,10A 125V 251 | UBM | AV-D77 |
| | S | POWER AMP | Q 0201 | 87-A30-257-080 | | C-TR,2SD1306E | UBM | AV-D77 |
| | S | POWER AMP | Q 0201 | 87-A30-257-080 | 0E | C-TR,2SD1306E | EZBM | AV-D77 |
| | S | POWER AMP | Q 0201 | 87-A30-257-080 | 0E | C-TR,2SD1306E | UBM | AV-D77 |
| | S | POWER AMP | Q 0202 | 87-A30-257-080 | | C-TR,2SD1306E | UBM | AV-D77 |
| | S | POWER AMP | Q 0202 | 87-A30-257-080 | 0E | C-TR,2SD1306E | EZBM | AV-D77 |
| | S | POWER AMP | Q 0202 | 87-A30-257-080 | 0E | C-TR,2SD1306E | UBM | AV-D77 |
| | S | POWER AMP | Q 0203 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0203 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0203 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0204 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0204 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0204 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0205 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0205 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0205 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0206 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0206 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0206 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0207 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0207 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0207 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0208 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0208 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0208 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0209 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0209 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0209 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0210 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0210 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0210 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0211 | 87-A30-190-080 | | TR,CC5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0211 | 87-A30-190-080 | 0E | TR,CC5551 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0211 | 87-A30-190-080 | 0E | TR,CC5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0212 | 87-A30-190-080 | | TR,CC5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0212 | 87-A30-190-080 | 0E | TR,CC5551 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0212 | 87-A30-190-080 | 0E | TR,CC5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0217 | 87-A30-106-070 | | C-TR,CMBT5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0217 | 87-A30-106-070 | 0E | C-TR,CMBT5551 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0217 | 87-A30-106-070 | 0E | C-TR,CMBT5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0218 | 87-A30-106-070 | | C-TR,CMBT5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0218 | 87-A30-106-070 | 0E | C-TR,CMBT5551 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0218 | 87-A30-106-070 | 0E | C-TR,CMBT5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0219 | 87-A30-186-010 | | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0219 | 87-A30-186-010 | 1B | FET,2SK3053 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0219 | 87-A30-186-010 | 1B | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0220 | 87-A30-186-010 | | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0220 | 87-A30-186-010 | 1B | FET,2SK3053 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0220 | 87-A30-186-010 | 1B | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0221 | 87-A30-072-080 | | C-TR,RT1P 144C | UBM | AV-D77 |
| | S | POWER AMP | Q 0221 | 87-A30-072-080 | 0E | C-TR,RT1P 144C | EZBM | AV-D77 |
| | S | POWER AMP | Q 0221 | 87-A30-072-080 | 0E | C-TR,RT1P 144C | UBM | AV-D77 |
| | S | POWER AMP | Q 0222 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0222 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0222 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0223 | 87-A30-074-080 | | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | POWER AMP | Q 0223 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | EZBM | AV-D77 |
| | S | POWER AMP | Q 0223 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | POWER AMP | Q 0224 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0224 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | POWER AMP | Q 0224 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0225 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0225 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0225 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0226 | 87-026-236-080 | | C-TR,DTC124EK | UBM | AV-D77 |
| | S | POWER AMP | Q 0226 | 87-026-236-080 | 0E | C-TR,DTC124EK | EZBM | AV-D77 |
| | S | POWER AMP | Q 0226 | 87-026-236-080 | 0E | C-TR,DTC124EK | UBM | AV-D77 |
| | S | POWER AMP | Q 0227 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0227 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0227 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0228 | 87-026-232-080 | | C-TR,DTA144WK | UBM | AV-D77 |
| | S | POWER AMP | Q 0228 | 87-026-232-080 | 0E | C-TR,DTA144WK | EZBM | AV-D77 |
| | S | POWER AMP | Q 0228 | 87-026-232-080 | 0E | C-TR,DTA144WK | UBM | AV-D77 |
| | S | POWER AMP | Q 0230 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0230 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0230 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0231 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0231 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0231 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0232 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0232 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0232 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0233 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0233 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0233 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0240 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0240 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0240 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0301 | 87-A30-257-080 | | C-TR,2SD1306E | UBM | AV-D77 |
| | S | POWER AMP | Q 0301 | 87-A30-257-080 | 0E | C-TR,2SD1306E | EZBM | AV-D77 |
| | S | POWER AMP | Q 0301 | 87-A30-257-080 | 0E | C-TR,2SD1306E | UBM | AV-D77 |
| | S | POWER AMP | Q 0302 | 87-A30-257-080 | | C-TR,2SD1306E | UBM | AV-D77 |
| | S | POWER AMP | Q 0302 | 87-A30-257-080 | 0E | C-TR,2SD1306E | EZBM | AV-D77 |
| | S | POWER AMP | Q 0302 | 87-A30-257-080 | 0E | C-TR,2SD1306E | UBM | AV-D77 |
| | S | POWER AMP | Q 0303 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0303 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0303 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0304 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0304 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0304 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0305 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0305 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0305 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0306 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0306 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0306 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0307 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0307 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0307 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0308 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0308 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0308 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0309 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0309 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0309 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0310 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0310 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0310 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0311 | 87-A30-190-080 | | TR,CC5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0311 | 87-A30-190-080 | 0E | TR,CC5551 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0311 | 87-A30-190-080 | 0E | TR,CC5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0312 | 87-A30-190-080 | | TR,CC5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0312 | 87-A30-190-080 | 0E | TR,CC5551 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0312 | 87-A30-190-080 | 0E | TR,CC5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0317 | 87-A30-106-070 | | C-TR,CMBT5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0317 | 87-A30-106-070 | 0E | C-TR,CMBT5551 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0317 | 87-A30-106-070 | 0E | C-TR,CMBT5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0318 | 87-A30-106-070 | | C-TR,CMBT5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0318 | 87-A30-106-070 | 0E | C-TR,CMBT5551 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0318 | 87-A30-106-070 | 0E | C-TR,CMBT5551 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | POWER AMP | Q 0319 | 87-A30-186-010 | | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0319 | 87-A30-186-010 | 1B | FET,2SK3053 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0319 | 87-A30-186-010 | 1B | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0320 | 87-A30-186-010 | | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0320 | 87-A30-186-010 | 1B | FET,2SK3053 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0320 | 87-A30-186-010 | 1B | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0321 | 87-A30-072-080 | | C-TR,RT1P 144C | UBM | AV-D77 |
| | S | POWER AMP | Q 0321 | 87-A30-072-080 | 0E | C-TR,RT1P 144C | EZBM | AV-D77 |
| | S | POWER AMP | Q 0321 | 87-A30-072-080 | 0E | C-TR,RT1P 144C | UBM | AV-D77 |
| | S | POWER AMP | Q 0322 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0322 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0322 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0323 | 87-A30-074-080 | | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | POWER AMP | Q 0323 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | EZBM | AV-D77 |
| | S | POWER AMP | Q 0323 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | POWER AMP | Q 0324 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0324 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0324 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0325 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0325 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0325 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0326 | 87-026-236-080 | | C-TR,DTC124EK | UBM | AV-D77 |
| | S | POWER AMP | Q 0326 | 87-026-236-080 | 0E | C-TR,DTC124EK | EZBM | AV-D77 |
| | S | POWER AMP | Q 0326 | 87-026-236-080 | 0E | C-TR,DTC124EK | UBM | AV-D77 |
| | S | POWER AMP | Q 0327 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0327 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0327 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0330 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0330 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0330 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0331 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0331 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0331 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0332 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0332 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0332 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0333 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0333 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0333 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0340 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0340 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0340 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0401 | 87-A30-257-080 | | C-TR,2SD1306E | UBM | AV-D77 |
| | S | POWER AMP | Q 0401 | 87-A30-257-080 | 0E | C-TR,2SD1306E | EZBM | AV-D77 |
| | S | POWER AMP | Q 0401 | 87-A30-257-080 | 0E | C-TR,2SD1306E | UBM | AV-D77 |
| | S | POWER AMP | Q 0402 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0402 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0402 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0403 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0403 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0403 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0404 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0404 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0404 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0405 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0405 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0405 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0406 | 87-A30-190-080 | | TR,CC5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0406 | 87-A30-190-080 | 0E | TR,CC5551 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0406 | 87-A30-190-080 | 0E | TR,CC5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0409 | 87-A30-106-070 | | C-TR,CMBT5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0409 | 87-A30-106-070 | 0E | C-TR,CMBT5551 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0409 | 87-A30-106-070 | 0E | C-TR,CMBT5551 | UBM | AV-D77 |
| | S | POWER AMP | Q 0410 | 87-A30-186-010 | | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0410 | 87-A30-186-010 | 1B | FET,2SK3053 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0410 | 87-A30-186-010 | 1B | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0411 | 87-A30-186-010 | | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0411 | 87-A30-186-010 | 1B | FET,2SK3053 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0411 | 87-A30-186-010 | 1B | FET,2SK3053 | UBM | AV-D77 |
| | S | POWER AMP | Q 0412 | 87-A30-072-080 | | C-TR,RT1P 144C | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | POWER AMP | Q 0412 | 87-A30-072-080 | 0E | C-TR,RT1P 144C | EZBM | AV-D77 |
| | S | POWER AMP | Q 0412 | 87-A30-072-080 | 0E | C-TR,RT1P 144C | UBM | AV-D77 |
| | S | POWER AMP | Q 0413 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0413 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0413 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0414 | 87-A30-074-080 | | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | POWER AMP | Q 0414 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | EZBM | AV-D77 |
| | S | POWER AMP | Q 0414 | 87-A30-074-080 | 0E | C-TR,RT1P 141C | UBM | AV-D77 |
| | S | POWER AMP | Q 0415 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0415 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0415 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0416 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0416 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0416 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0417 | 87-026-236-080 | | C-TR,DTC124EK | UBM | AV-D77 |
| | S | POWER AMP | Q 0417 | 87-026-236-080 | 0E | C-TR,DTC124EK | EZBM | AV-D77 |
| | S | POWER AMP | Q 0417 | 87-026-236-080 | 0E | C-TR,DTC124EK | UBM | AV-D77 |
| | S | POWER AMP | Q 0418 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0418 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0418 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER AMP | Q 0420 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0420 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0420 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0421 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0421 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER AMP | Q 0421 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER AMP | Q 0440 | 87-A30-107-070 | | C-TR,CMBT5401 | UBM | AV-D77 |
| | S | POWER AMP | Q 0440 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | EZBM | AV-D77 |
| | S | POWER AMP | Q 0440 | 87-A30-107-070 | 0E | C-TR,CMBT5401 | UBM | AV-D77 |
| | X | POWER AMP | R 0200 | 88-128-681-080 | | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0200 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0200 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0201 | 88-118-332-080 | | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0201 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0201 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0202 | 88-118-332-080 | | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0202 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0202 | 88-118-332-080 | 0E | C-RES,S 3.3K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0205 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0205 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0205 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0206 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0206 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0206 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0207 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0207 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0207 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0208 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0208 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0208 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0209 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0209 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0209 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0210 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0210 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0210 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | O | POWER AMP | R 0211 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0211 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0211 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0212 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0212 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0212 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | X | POWER AMP | R 0213 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0213 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0213 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0214 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0214 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0214 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0215 | 88-118-821-080 | | C-RES,S 820-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0215 | 88-118-821-080 | 0E | C-RES,S 820-1/10W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | R 0215 | 88-118-821-080 | 0E | C-RES,S 820-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0216 | 88-118-821-080 | | C-RES,S 820-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0216 | 88-118-821-080 | 0E | C-RES,S 820-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0216 | 88-118-821-080 | 0E | C-RES,S 820-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0217 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0217 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0217 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0218 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0218 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0218 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0219 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0219 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0219 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0220 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0220 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0220 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0221 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0221 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0221 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0222 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0222 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0222 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0223 | 88-128-331-080 | | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0223 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0223 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0224 | 88-128-331-080 | | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0224 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0224 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0225 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0225 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0225 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0226 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0226 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0226 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0227 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0227 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0227 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0228 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0228 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0228 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0229 | 88-118-390-080 | | C-RES,S 39-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0229 | 88-118-390-080 | 0E | C-RES,S 39-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0229 | 88-118-390-080 | 0E | C-RES,S 39-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0230 | 88-118-390-080 | | C-RES,S 39-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0230 | 88-118-390-080 | 0E | C-RES,S 39-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0230 | 88-118-390-080 | 0E | C-RES,S 39-1/10W J | UBM | AV-D77 |
| | O | POWER AMP | R 0231 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0231 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0231 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0232 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0232 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0232 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0233 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0233 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0233 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0234 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0234 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0234 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | X | POWER AMP | R 0235 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0235 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0235 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0236 | 88-128-152-080 | | C-RES, 1.5K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0236 | 88-128-152-080 | 0E | C-RES, 1.5K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0236 | 88-128-152-080 | 0E | C-RES, 1.5K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0237 | 88-118-681-080 | | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0237 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0237 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0238 | 88-118-681-080 | | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0238 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0238 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | R 0239 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0239 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0239 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0240 | 88-128-223-080 | | C-RES, 22K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0240 | 88-128-223-080 | 0E | C-RES, 22K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0240 | 88-128-223-080 | 0E | C-RES, 22K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0241 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0241 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0241 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0242 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0242 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0242 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0243 | 88-118-563-080 | | C-RES,S 56K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0243 | 88-118-563-080 | 0E | C-RES,S 56K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0243 | 88-118-563-080 | 0E | C-RES,S 56K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0244 | 88-118-563-080 | | C-RES,S 56K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0244 | 88-118-563-080 | 0E | C-RES,S 56K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0244 | 88-118-563-080 | 0E | C-RES,S 56K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0245 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | R 0245 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | R 0245 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | R 0246 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0246 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0246 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0247 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0247 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | R 0247 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0248 | 88-128-681-080 | | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0248 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0248 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0249 | 88-128-681-080 | | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0249 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0249 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0250 | 88-130-272-080 | | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0250 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0250 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0251 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0251 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0251 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0252 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0252 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0252 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0253 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0253 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0253 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0254 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0254 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0254 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0255 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0255 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0255 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0256 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0256 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0256 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0257 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0257 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0257 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0258 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0258 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0258 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0259 | 88-118-471-080 | | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0259 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0259 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0260 | 88-118-821-080 | | C-RES,S 820-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0260 | 88-118-821-080 | 0E | C-RES,S 820-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0260 | 88-118-821-080 | 0E | C-RES,S 820-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0261 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0261 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0261 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0262 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | R 0262 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0262 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0263 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0263 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0263 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0264 | 88-128-472-080 | | C-RES, 4.7K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0264 | 88-128-472-080 | 0E | C-RES, 4.7K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0264 | 88-128-472-080 | 0E | C-RES, 4.7K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0265 | 88-130-272-080 | | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0265 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0265 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0266 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0266 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0266 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0267 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0267 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0267 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0268 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0268 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0268 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0269 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0269 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0269 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0270 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | POWER AMP | R 0270 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | POWER AMP | R 0270 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | POWER AMP | R 0271 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0271 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0271 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0272 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0272 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0272 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0273 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0273 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0273 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0274 | 88-118-683-080 | | C-RES,S 68K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0274 | 88-118-683-080 | 0E | C-RES,S 68K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0274 | 88-118-683-080 | 0E | C-RES,S 68K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0275 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0275 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0275 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0276 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0276 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | R 0276 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0277 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0277 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | R 0277 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0278 | 88-118-562-080 | | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0278 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0278 | 88-118-562-080 | 0E | C-RES,S 5.6K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0279 | 88-128-391-080 | | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0279 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0279 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0280 | 88-128-391-080 | | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0280 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0280 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | UBM | AV-D77 |
| | O | POWER AMP | R 0281 | 87-A00-126-080 | 0E | RES,M/F 220-1W J VTP | EZBM | AV-D77 |
| | O | POWER AMP | R 0281 | 87-A00-373-050 | | RES,M/F 270-1W J VTP | UBM | AV-D77 |
| | O | POWER AMP | R 0281 | 87-A00-373-050 | 0E | RES,M/F 270-1W J VTP | UBM | AV-D77 |
| | O | POWER AMP | R 0282 | 87-A00-126-080 | 0E | RES,M/F 220-1W J VTP | EZBM | AV-D77 |
| | O | POWER AMP | R 0282 | 87-A00-373-050 | | RES,M/F 270-1W J VTP | UBM | AV-D77 |
| | O | POWER AMP | R 0282 | 87-A00-373-050 | 0E | RES,M/F 270-1W J VTP | UBM | AV-D77 |
| | O | POWER AMP | R 0283 | 87-A00-126-080 | 0E | RES,M/F 220-1W J VTP | EZBM | AV-D77 |
| | O | POWER AMP | R 0283 | 87-A00-373-050 | | RES,M/F 270-1W J VTP | UBM | AV-D77 |
| | O | POWER AMP | R 0283 | 87-A00-373-050 | 0E | RES,M/F 270-1W J VTP | UBM | AV-D77 |
| | O | POWER AMP | R 0284 | 87-A00-126-080 | 0E | RES,M/F 220-1W J VTP | EZBM | AV-D77 |
| | O | POWER AMP | R 0284 | 87-A00-373-050 | | RES,M/F 270-1W J VTP | UBM | AV-D77 |
| | O | POWER AMP | R 0284 | 87-A00-373-050 | 0E | RES,M/F 270-1W J VTP | UBM | AV-D77 |
| | X | POWER AMP | R 0285 | 88-128-220-080 | | C-RES, 22-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0285 | 88-128-220-080 | 0E | C-RES, 22-1/8W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | R 0286 | 88-128-180-080 | | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0286 | 88-128-180-080 | 0E | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0287 | 88-128-180-080 | | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0287 | 88-128-180-080 | 0E | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0288 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0288 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0288 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0289 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0289 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0289 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0290 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0290 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0290 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0291 | 88-121-100-080 | | RES,10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0291 | 88-121-100-080 | 0E | RES,10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0291 | 88-121-100-080 | 0E | RES,10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0292 | 88-121-100-080 | | RES,10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0292 | 88-121-100-080 | 0E | RES,10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0292 | 88-121-100-080 | 0E | RES,10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0293 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0293 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0293 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0294 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0294 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0294 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0295 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0295 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0295 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0296 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0296 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0296 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0297 | 88-121-100-080 | | RES,10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0297 | 88-121-100-080 | 0E | RES,10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0297 | 88-121-100-080 | 0E | RES,10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0298 | 88-121-100-080 | | RES,10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0298 | 88-121-100-080 | 0E | RES,10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0298 | 88-121-100-080 | 0E | RES,10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0299 | 88-128-122-080 | | C-RES, 1.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0299 | 88-128-122-080 | 0E | C-RES, 1.2K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0299 | 88-128-122-080 | 0E | C-RES, 1.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0301 | 88-118-222-080 | | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0301 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0301 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0302 | 88-118-222-080 | | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0302 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0302 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0305 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0305 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0305 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0306 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0306 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0306 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0307 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0307 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0307 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0308 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0308 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0308 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0309 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0309 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0309 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0310 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0310 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0310 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0311 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0311 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | R 0311 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0312 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0312 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | R 0312 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | R 0313 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0313 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0313 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0314 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0314 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0314 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0315 | 88-118-561-080 | | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0315 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0315 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0316 | 88-118-561-080 | | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0316 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0316 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0317 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0317 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0317 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0318 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0318 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0318 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0319 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0319 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0319 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0320 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0320 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0320 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0321 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0321 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0321 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0322 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0322 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0322 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0323 | 88-128-331-080 | | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0323 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0323 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0324 | 88-128-391-080 | | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0324 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0324 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0325 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0325 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0325 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0326 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0326 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0326 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0327 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0327 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0327 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0328 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0328 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0328 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0329 | 88-118-390-080 | | C-RES,S 39-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0329 | 88-118-390-080 | 0E | C-RES,S 39-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0329 | 88-118-390-080 | 0E | C-RES,S 39-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0330 | 88-118-390-080 | | C-RES,S 39-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0330 | 88-118-390-080 | 0E | C-RES,S 39-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0330 | 88-118-390-080 | 0E | C-RES,S 39-1/10W J | UBM | AV-D77 |
| | O | POWER AMP | R 0331 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0331 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0331 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0332 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0332 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0332 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0333 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0333 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0333 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0334 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0334 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0334 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | X | POWER AMP | R 0335 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0335 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0335 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0336 | 88-128-152-080 | | C-RES, 1.5K-1/8W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | R 0336 | 88-128-152-080 | 0E | C-RES, 1.5K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0336 | 88-128-152-080 | 0E | C-RES, 1.5K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0337 | 88-118-681-080 | | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0337 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0337 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0338 | 88-118-681-080 | | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0338 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0338 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0339 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0339 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0339 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0340 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0340 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0340 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0341 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0341 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0341 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0342 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0342 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0342 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0343 | 88-118-563-080 | | C-RES,S 56K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0343 | 88-118-563-080 | 0E | C-RES,S 56K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0343 | 88-118-563-080 | 0E | C-RES,S 56K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0344 | 88-118-563-080 | | C-RES,S 56K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0344 | 88-118-563-080 | 0E | C-RES,S 56K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0344 | 88-118-563-080 | 0E | C-RES,S 56K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0346 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0346 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0346 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0347 | 88-128-681-080 | | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0347 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0347 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0348 | 88-128-681-080 | | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0348 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0348 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0349 | 88-128-681-080 | | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0349 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0349 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0350 | 88-130-272-080 | | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0350 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0350 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0351 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0351 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0351 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0352 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0352 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0352 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0353 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0353 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0353 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0354 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0354 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0354 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0355 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0355 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0355 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0356 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0356 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0356 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0357 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0357 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0357 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0358 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0358 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0358 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0359 | 88-118-471-080 | | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0359 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0359 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0360 | 88-118-821-080 | | C-RES,S 820-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0360 | 88-118-821-080 | 0E | C-RES,S 820-1/10W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | R 0360 | 88-118-821-080 | 0E | C-RES,S 820-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0361 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0361 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0361 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0362 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0362 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0362 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0363 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0363 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0363 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0364 | 88-128-472-080 | | C-RES, 4.7K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0364 | 88-128-472-080 | 0E | C-RES, 4.7K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0364 | 88-128-472-080 | 0E | C-RES, 4.7K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0365 | 88-130-272-080 | | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0365 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0365 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0366 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0366 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0366 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0367 | 88-128-103-080 | | C-RES, 10K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0367 | 88-128-103-080 | 0E | C-RES, 10K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0367 | 88-128-103-080 | 0E | C-RES, 10K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0368 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0368 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0368 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0369 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0369 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0369 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0372 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0372 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0372 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0373 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0373 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0373 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0374 | 88-118-683-080 | | C-RES,S 68K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0374 | 88-118-683-080 | 0E | C-RES,S 68K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0374 | 88-118-683-080 | 0E | C-RES,S 68K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0375 | 88-128-331-080 | | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0375 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0375 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0376 | 88-128-271-080 | | C-RES, 270-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0376 | 88-128-271-080 | 0E | C-RES, 270-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0376 | 88-128-271-080 | 0E | C-RES, 270-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0381 | 88-128-391-080 | | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0381 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0381 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0382 | 88-128-391-080 | | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0382 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0382 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0383 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0383 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | R 0383 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0384 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0384 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER AMP | R 0384 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0387 | 88-118-471-080 | | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0387 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0387 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0388 | 88-121-122-080 | | RES,1.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0388 | 88-121-122-080 | 0E | RES,1.2K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0388 | 88-121-122-080 | 0E | RES,1.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0389 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0389 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0389 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0390 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0390 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0390 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0391 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0391 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0391 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | R 0392 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0392 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0392 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0393 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0393 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0393 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0394 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0394 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0394 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0395 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | POWER AMP | R 0395 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | POWER AMP | R 0395 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | POWER AMP | R 0396 | 88-121-122-080 | | RES,1.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0396 | 88-121-122-080 | 0E | RES,1.2K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0396 | 88-121-122-080 | 0E | RES,1.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0397 | 88-121-222-080 | | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0397 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0397 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0398 | 88-121-222-080 | | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0398 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0398 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0399 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | POWER AMP | R 0399 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | POWER AMP | R 0399 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | POWER AMP | R 0401 | 88-118-222-080 | | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0401 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0401 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0403 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0403 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0403 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0404 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0404 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0404 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0405 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0405 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0405 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0406 | 88-128-331-080 | | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0406 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0406 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0407 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0407 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0407 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0408 | 88-118-561-080 | | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0408 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0408 | 88-118-561-080 | 0E | C-RES,S 560-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0409 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0409 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0409 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0410 | 88-128-101-080 | | C-RES, 100-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0410 | 88-128-101-080 | 0E | C-RES, 100-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0410 | 88-128-101-080 | 0E | C-RES, 100-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0411 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0411 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0411 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0412 | 88-128-331-080 | | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0412 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0412 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0413 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0413 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0413 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0414 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0414 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0414 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0415 | 88-118-390-080 | | C-RES,S 39-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0415 | 88-118-390-080 | 0E | C-RES,S 39-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0415 | 88-118-390-080 | 0E | C-RES,S 39-1/10W J | UBM | AV-D77 |
| | O | POWER AMP | R 0416 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0416 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0416 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0417 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | POWER AMP | R 0417 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0417 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | X | POWER AMP | R 0418 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0418 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0418 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0419 | 88-118-681-080 | | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0419 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0419 | 88-118-681-080 | 0E | C-RES,S 680-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0420 | 88-128-223-080 | | C-RES, 22K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0420 | 88-128-223-080 | 0E | C-RES, 22K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0420 | 88-128-223-080 | 0E | C-RES, 22K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0421 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0421 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0421 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0422 | 88-128-681-080 | | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0422 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0422 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0423 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0423 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0423 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | O | POWER AMP | R 0424 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0424 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0424 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | X | POWER AMP | R 0425 | 88-128-681-080 | | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0425 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0425 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0426 | 88-128-681-080 | | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0426 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0426 | 88-128-681-080 | 0E | C-RES, 680-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0427 | 88-130-272-080 | | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0427 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0427 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0428 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0428 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0428 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0429 | 88-118-563-080 | | C-RES,S 56K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0429 | 88-118-563-080 | 0E | C-RES,S 56K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0429 | 88-118-563-080 | 0E | C-RES,S 56K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0430 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0430 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0430 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0431 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0431 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0431 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0432 | 88-128-222-080 | | C-RES, 2.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0432 | 88-128-222-080 | 0E | C-RES, 2.2K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0432 | 88-128-222-080 | 0E | C-RES, 2.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0433 | 88-121-122-080 | | RES,1.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0433 | 88-121-122-080 | 0E | RES,1.2K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0433 | 88-121-122-080 | 0E | RES,1.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0434 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0434 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0434 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0435 | 88-128-222-080 | | C-RES, 2.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0435 | 88-128-222-080 | 0E | C-RES, 2.2K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0435 | 88-128-222-080 | 0E | C-RES, 2.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0436 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0436 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0436 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0437 | 88-128-471-080 | | C-RES, 470-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0437 | 88-128-471-080 | 0E | C-RES, 470-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0437 | 88-128-471-080 | 0E | C-RES, 470-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0438 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0438 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0438 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0439 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0439 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0439 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0440 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0440 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER AMP | R 0440 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER AMP | R 0441 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0441 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0441 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0442 | 88-128-472-080 | | C-RES, 4.7K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0442 | 88-128-472-080 | 0E | C-RES, 4.7K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0442 | 88-128-472-080 | 0E | C-RES, 4.7K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0443 | 88-130-272-080 | | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0443 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0443 | 88-130-272-080 | 0E | RES,2.7K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0444 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0444 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0444 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0445 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0445 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0445 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0446 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0446 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0446 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0447 | 88-118-683-080 | | C-RES,S 68K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0447 | 88-118-683-080 | 0E | C-RES,S 68K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0447 | 88-118-683-080 | 0E | C-RES,S 68K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0450 | 88-128-391-080 | | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0450 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0450 | 88-128-391-080 | 0E | C-RES, 390-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0467 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0467 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0467 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0469 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0469 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0469 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0471 | 88-138-822-080 | | C-RES, 8.2K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0471 | 88-138-822-080 | 0E | C-RES, 8.2K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0471 | 88-138-822-080 | 0E | C-RES, 8.2K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0472 | 88-138-822-080 | | C-RES, 8.2K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0472 | 88-138-822-080 | 0E | C-RES, 8.2K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0472 | 88-138-822-080 | 0E | C-RES, 8.2K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0473 | 88-130-822-080 | | RES,8.2K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0473 | 88-130-822-080 | 0E | RES,8.2K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0473 | 88-130-822-080 | 0E | RES,8.2K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0481 | 88-128-220-080 | | C-RES, 22-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0481 | 88-128-220-080 | 0E | C-RES, 22-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0482 | 88-128-180-080 | | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0482 | 88-128-180-080 | 0E | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0483 | 88-128-180-080 | | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0483 | 88-128-180-080 | 0E | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0489 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0489 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0489 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0490 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0490 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0490 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0491 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0491 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0491 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0492 | 88-128-100-080 | | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0492 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0492 | 88-128-100-080 | 0E | C-RES, 10-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0493 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | R 0493 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER AMP | R 0493 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER AMP | R 0494 | 88-121-122-080 | | RES,1.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0494 | 88-121-122-080 | 0E | RES,1.2K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0494 | 88-121-122-080 | 0E | RES,1.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0495 | 88-121-222-080 | | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0495 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0495 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | UBM | AV-D77 |
| | O | POWER AMP | R 0590 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0590 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0590 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | POWER AMP | R 0611 | 87-A00-598-010 | | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | O | POWER AMP | R 0611 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | EZBM | AV-D77 |
| | O | POWER AMP | R 0611 | 87-A00-598-010 | 0E | RES,M/F 0.15-3W J-8.5MM | UBM | AV-D77 |
| | X | POWER AMP | R 0745 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0745 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0748 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0748 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0748 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER AMP | R 0801 | 88-128-220-080 | | C-RES, 22-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0801 | 88-128-220-080 | 0E | C-RES, 22-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0802 | 88-128-180-080 | | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0802 | 88-128-180-080 | 0E | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0803 | 88-128-180-080 | | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0803 | 88-128-180-080 | 0E | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0804 | 88-138-822-080 | | C-RES, 8.2K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0804 | 88-138-822-080 | 0E | C-RES, 8.2K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0804 | 88-138-822-080 | 0E | C-RES, 8.2K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0805 | 88-138-822-080 | | C-RES, 8.2K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0805 | 88-138-822-080 | 0E | C-RES, 8.2K-1/4W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0805 | 88-138-822-080 | 0E | C-RES, 8.2K-1/4W J | UBM | AV-D77 |
| | X | POWER AMP | R 0997 | 88-128-331-080 | | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0997 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0997 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0998 | 88-128-331-080 | | C-RES, 330-1/8W J | UBM | AV-D77 |
| | X | POWER AMP | R 0998 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | EZBM | AV-D77 |
| | X | POWER AMP | R 0998 | 88-128-331-080 | 0E | C-RES, 330-1/8W J | UBM | AV-D77 |
| | O | POWER AMP | RY 0281 | 87-A91-686-010 | | RELAY, G5PA-28(OMRON) | UBM | AV-D77 |
| ! | O | POWER AMP | RY 0281 | 87-A91-686-010 | 1B | RELAY, G5PA-28(OMRON) | UBM | AV-D77 |
| | O | POWER AMP | RY 0481 | 87-A91-686-010 | | RELAY, G5PA-28(OMRON) | UBM | AV-D77 |
| ! | O | POWER AMP | RY 0481 | 87-A91-686-010 | 1B | RELAY, G5PA-28(OMRON) | UBM | AV-D77 |
| | O | POWER AMP | RY 0801 | 87-A91-686-010 | | RELAY, G5PA-28(OMRON) | UBM | AV-D77 |
| ! | O | POWER AMP | RY 0801 | 87-A91-686-010 | 1B | RELAY, G5PA-28(OMRON) | UBM | AV-D77 |
| | O | POWER AMP | S 0291 | 87-A90-174-010 | | SW,PUSH 2-2-2 R2121382ES | UBM | AV-D77 |
| ! | O | POWER AMP | S 0291 | 87-A90-174-010 | 1B | SW,PUSH 2-2-2 R2121382ES | EZBM | AV-D77 |
| ! | O | POWER AMP | S 0291 | 87-A90-174-010 | 1B | SW,PUSH 2-2-2 R2121382ES | UBM | AV-D77 |
| | O | POWER AMP | S 0292 | 87-A90-174-010 | | SW,PUSH 2-2-2 R2121382ES | UBM | AV-D77 |
| ! | O | POWER AMP | S 0292 | 87-A90-174-010 | 1B | SW,PUSH 2-2-2 R2121382ES | EZBM | AV-D77 |
| ! | O | POWER AMP | S 0292 | 87-A90-174-010 | 1B | SW,PUSH 2-2-2 R2121382ES | UBM | AV-D77 |
| | O | POWER AMP | TH 0201 | 87-A91-081-080 | | C-THMS,100K-K 20P | UBM | AV-D77 |
| | O | POWER AMP | TH 0201 | 87-A91-081-080 | 0E | C-THMS,100K-K 20P | EZBM | AV-D77 |
| | O | POWER AMP | TH 0201 | 87-A91-081-080 | 0E | C-THMS,100K-K 20P | UBM | AV-D77 |
| | O | POWER AMP | TH 0202 | 87-A91-081-080 | | C-THMS,100K-K 20P | UBM | AV-D77 |
| | O | POWER AMP | TH 0202 | 87-A91-081-080 | 0E | C-THMS,100K-K 20P | EZBM | AV-D77 |
| | O | POWER AMP | TH 0202 | 87-A91-081-080 | 0E | C-THMS,100K-K 20P | UBM | AV-D77 |
| | O | POWER AMP | TH 0301 | 87-A91-081-080 | | C-THMS,100K-K 20P | UBM | AV-D77 |
| | O | POWER AMP | TH 0301 | 87-A91-081-080 | 0E | C-THMS,100K-K 20P | EZBM | AV-D77 |
| | O | POWER AMP | TH 0301 | 87-A91-081-080 | 0E | C-THMS,100K-K 20P | UBM | AV-D77 |
| | O | POWER AMP | TH 0302 | 87-A91-081-080 | | C-THMS,100K-K 20P | UBM | AV-D77 |
| | O | POWER AMP | TH 0302 | 87-A91-081-080 | 0E | C-THMS,100K-K 20P | EZBM | AV-D77 |
| | O | POWER AMP | TH 0302 | 87-A91-081-080 | 0E | C-THMS,100K-K 20P | UBM | AV-D77 |
| | O | POWER AMP | TH 0401 | 87-A91-081-080 | | C-THMS,100K-K 20P | UBM | AV-D77 |
| | O | POWER AMP | TH 0401 | 87-A91-081-080 | 0E | C-THMS,100K-K 20P | EZBM | AV-D77 |
| | O | POWER AMP | TH 0401 | 87-A91-081-080 | 0E | C-THMS,100K-K 20P | UBM | AV-D77 |
| | X | POWER SUPPLY | | 8A-AR3-617-010 | | PWB,VCC1(U) | UBM | AV-D77 |
| | X | POWER SUPPLY | | 8A-AR3-617-110 | -- | PWB,VCC1(U) | UBM | AV-D77 |
| | X | POWER SUPPLY | | 8A-AR3-618-010 | | PWB,VCC2(U) | UBM | AV-D77 |
| | X | POWER SUPPLY | | 8A-AR3-618-110 | -- | PWB,VCC2(U) | UBM | AV-D77 |
| | X | POWER SUPPLY | | 8A-AR3-623-110 | -- | PWB,VCC1 | EZBM | AV-D77 |
| | X | POWER SUPPLY | * | 8A-AR3-615-010 | | PWB,COMB MAIN (U) | UBM | AV-D77 |
| | X | POWER SUPPLY | * | 8A-AR3-615-110 | 1H | PWB,COMB MAIN (U) | UBM | AV-D77 |
| | X | POWER SUPPLY | * | 8A-AR3-616-010 | | PWB,MAIN (U) | UBM | AV-D77 |
| | X | POWER SUPPLY | * | 8A-AR3-616-110 | -- | PWB,MAIN (U) | UBM | AV-D77 |
| | X | POWER SUPPLY | * | 8A-AR3-621-110 | -- | PWB,COMB MAIN (EZ,H) | EZBM | AV-D77 |
| | X | POWER SUPPLY | * | 8A-AR3-622-110 | -- | PWB,MAIN (EZ,H) | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0101 | 87-010-235-080 | | CAP,E 470-16 M SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0101 | 87-010-235-080 | 0E | CAP,E 470-16 M SME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0101 | 87-010-235-080 | 0E | CAP,E 470-16 M SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0102 | 87-010-235-080 | | CAP,E 470-16 M SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0102 | 87-010-235-080 | 0E | CAP,E 470-16 M SME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0102 | 87-010-235-080 | 0E | CAP,E 470-16 M SME | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | POWER SUPPLY | C 0103 | 87-010-384-080 | | CAP,E 100-25 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0103 | 87-010-384-080 | 0E | CAP,E 100-25 M 11L SME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0103 | 87-010-384-080 | 0E | CAP,E 100-25 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0104 | 87-016-128-080 | | CAP,E 22-25 M 105 KME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0104 | 87-016-128-080 | 0E | CAP,E 22-25 M 105 KME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0104 | 87-016-128-080 | 0E | CAP,E 22-25 M 105 KME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0105 | 87-010-247-080 | | CAP,E 100-50 M SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0105 | 87-010-247-080 | 0E | CAP,E 100-50 M SME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0105 | 87-010-247-080 | 0E | CAP,E 100-50 M SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0106 | 87-010-384-080 | | CAP,E 100-25 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0106 | 87-010-384-080 | 0E | CAP,E 100-25 M 11L SME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0106 | 87-010-384-080 | 0E | CAP,E 100-25 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0107 | 87-010-263-080 | | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0107 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0108 | 87-012-140-080 | | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0108 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0108 | 87-012-140-080 | 0E | C-CAP,S 470P-50 J CH | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0109 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0109 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0109 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0110 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0110 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0110 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0111 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0111 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0111 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0112 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0112 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0112 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0113 | 87-A12-300-010 | | CAP,E 3900-35 LXZ | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0113 | 87-A12-300-010 | 1D | CAP,E 3900-35 LXZ | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0113 | 87-A12-300-010 | 1D | CAP,E 3900-35 LXZ | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0114 | 87-A12-300-010 | | CAP,E 3900-35 LXZ | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0114 | 87-A12-300-010 | 1D | CAP,E 3900-35 LXZ | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0114 | 87-A12-300-010 | 1D | CAP,E 3900-35 LXZ | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0115 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0115 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0115 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0116 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0116 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0116 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0117 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0117 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0117 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0118 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0118 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0118 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0119 | 87-A11-316-090 | | CAP,E 8200-85 | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0119 | 87-A11-316-090 | 2M | CAP,E 8200-85 | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0119 | 87-A11-991-090 | 2P | CAP,E 7500-85 105 KMG | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0120 | 87-A11-316-090 | | CAP,E 8200-85 | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0120 | 87-A11-316-090 | 2M | CAP,E 8200-85 | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0120 | 87-A11-991-090 | 2P | CAP,E 7500-85 105 KMG | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0121 | 87-010-260-080 | | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0121 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0121 | 87-010-260-080 | 0E | CAP,E 47-25 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0122 | 87-010-403-080 | | CAP,E 3.3-50 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0122 | 87-010-403-080 | 0E | CAP,E 3.3-50 M 11L SME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0122 | 87-010-403-080 | 0E | CAP,E 3.3-50 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0123 | 87-010-384-080 | | CAP,E 100-25 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0123 | 87-010-384-080 | 0E | CAP,E 100-25 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0123 | 87-010-393-080 | 0E | CAP,E 100-35 M SME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0124 | 87-010-384-080 | | CAP,E 100-25 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0124 | 87-010-384-080 | 0E | CAP,E 100-25 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0124 | 87-010-393-080 | 0E | CAP,E 100-35 M SME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0125 | 87-A10-417-080 | | CAP,E 47-63 SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0125 | 87-A10-417-080 | 0E | CAP,E 47-63 SME | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0125 | 87-A10-417-080 | 0E | CAP,E 47-63 SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0126 | 87-010-263-080 | | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0126 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | POWER SUPPLY | C 0126 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0127 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0127 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0127 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0128 | 87-010-197-080 | | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0128 | 87-010-197-080 | 0E | C-CAP,S 0.01-25 K B C2012 | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0143 | 87-A10-712-080 | | C-CAP,S 0.22-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0143 | 87-A10-712-080 | 0E | C-CAP,S 0.22-50 Z F | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0143 | 87-A10-712-080 | 0E | C-CAP,S 0.22-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0144 | 87-A10-712-080 | | C-CAP,S 0.22-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | C 0144 | 87-A10-712-080 | 0E | C-CAP,S 0.22-50 Z F | EZBM | AV-D77 |
| | O | POWER SUPPLY | C 0144 | 87-A10-712-080 | 0E | C-CAP,S 0.22-50 Z F | UBM | AV-D77 |
| | O | POWER SUPPLY | CN 0110 | 87-A60-621-010 | | CONN,4P V 2MM JMT | UBM | AV-D77 |
| | O | POWER SUPPLY | CN 0110 | 87-A60-621-010 | 0E | CONN,4P V 2MM JMT | EZBM | AV-D77 |
| | O | POWER SUPPLY | CN 0110 | 87-A60-621-010 | 0E | CONN,4P V 2MM JMT | UBM | AV-D77 |
| | O | POWER SUPPLY | CN 0112 | 87-009-031-010 | | CONN,3P V WHT PH | UBM | AV-D77 |
| ! | O | POWER SUPPLY | CN 0112 | 87-009-031-010 | 0E | CONN,3P V WHT PH | UBM | AV-D77 |
| | O | POWER SUPPLY | CN 0997 | 87-049-919-010 | | CONN,3P V WHT EH | UBM | AV-D77 |
| ! | O | POWER SUPPLY | CN 0997 | 87-049-919-010 | 0E | CONN,3P V WHT EH | EZBM | AV-D77 |
| ! | O | POWER SUPPLY | CN 0997 | 87-049-919-010 | 0E | CONN,3P V WHT EH | UBM | AV-D77 |
| | O | POWER SUPPLY | CN 0998 | 87-049-919-010 | | CONN,3P V WHT EH | UBM | AV-D77 |
| ! | O | POWER SUPPLY | CN 0998 | 87-049-919-010 | 0E | CONN,3P V WHT EH | EZBM | AV-D77 |
| ! | O | POWER SUPPLY | CN 0998 | 87-049-919-010 | 0E | CONN,3P V WHT EH | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0101 | 87-A40-345-080 | | ZENER,MTZJ10C | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0101 | 87-A40-345-080 | 0E | ZENER,MTZJ10C | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0101 | 87-A40-345-080 | 0E | ZENER,MTZJ10C | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0102 | 87-A40-269-080 | | C-DIODE,MC2836 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0102 | 87-A40-269-080 | 0E | C-DIODE,MC2836 | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0102 | 87-A40-269-080 | 0E | C-DIODE,MC2836 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0103 | 87-027-686-080 | | ZENER,HZ12A1 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0103 | 87-027-686-080 | 0E | ZENER,HZ12A1 | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0103 | 87-027-686-080 | 0E | ZENER,HZ12A1 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0104 | 87-027-686-080 | | ZENER,HZ12A1 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0104 | 87-027-686-080 | 0E | ZENER,HZ12A1 | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0104 | 87-027-686-080 | 0E | ZENER,HZ12A1 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0105 | 87-027-686-080 | | ZENER,HZ12A1 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0105 | 87-027-686-080 | 0E | ZENER,HZ12A1 | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0105 | 87-027-686-080 | 0E | ZENER,HZ12A1 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0106 | 87-027-686-080 | | ZENER,HZ12A1 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0106 | 87-027-686-080 | 0E | ZENER,HZ12A1 | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0106 | 87-027-686-080 | 0E | ZENER,HZ12A1 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0107 | 87-A40-115-060 | | DIODE,RS603M | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0107 | 87-A40-115-060 | 1C | DIODE,RS603M | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0107 | 87-A40-115-060 | 1C | DIODE,RS603M | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0108 | 87-A40-269-080 | | C-DIODE,MC2836 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0108 | 87-A40-269-080 | 0E | C-DIODE,MC2836 | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0108 | 87-A40-269-080 | 0E | C-DIODE,MC2836 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0109 | 87-A40-270-080 | | C-DIODE,MC2838 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0109 | 87-A40-270-080 | 0E | C-DIODE,MC2838 | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0109 | 87-A40-270-080 | 0E | C-DIODE,MC2838 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0110 | 87-A40-004-080 | | ZENER,MTZJ16A | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0110 | 87-A40-004-080 | 0E | ZENER,MTZJ16A | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0110 | 87-A40-004-080 | 0E | ZENER,MTZJ16A | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0112 | 87-A40-335-080 | | ZENER,MTZJ11C T-72 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0112 | 87-A40-335-080 | 0E | ZENER,MTZJ11C T-72 | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0112 | 87-A40-335-080 | 0E | ZENER,MTZJ11C T-72 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0113 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0113 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0121 | 87-A40-224-010 | | DIODE,GBU8DL | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0121 | 87-A40-224-010 | 1E | DIODE,GBU8DL | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0121 | 87-A40-224-010 | 1E | DIODE,GBU8DL | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0122 | 87-070-274-080 | | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0122 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0122 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0123 | 87-070-274-080 | | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0123 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0123 | 87-070-274-080 | 0E | DIODE,1N4003 SEM | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0124 | 87-A40-435-080 | | ZENER,MTZJ30D | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0124 | 87-A40-435-080 | 0E | ZENER,MTZJ30D | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0124 | 87-A40-435-080 | 0E | ZENER,MTZJ30D | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | POWER SUPPLY | D 0125 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0125 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0125 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0126 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0126 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0126 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0199 | 87-A40-341-080 | | ZENER,MTZJ36A | UBM | AV-D77 |
| | S | POWER SUPPLY | D 0199 | 87-A40-341-080 | 0E | ZENER,MTZJ36A | EZBM | AV-D77 |
| | S | POWER SUPPLY | D 0199 | 87-A40-341-080 | 0E | ZENER,MTZJ36A | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0102 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0102 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0102 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0111 | 88-148-000-080 | | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0111 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0111 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0112 | 88-148-000-080 | | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0112 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0112 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0113 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0113 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0113 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0114 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0114 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0114 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0118 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0118 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0118 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0119 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0119 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0119 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0121 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0121 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0121 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0123 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0123 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0123 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0124 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0124 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0124 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0127 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0127 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0127 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0128 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0128 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0128 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0131 | 88-148-000-080 | | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0131 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0131 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0132 | 88-148-000-080 | | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0132 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0132 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0133 | 88-148-000-080 | | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0133 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0133 | 88-148-000-080 | 0E | C-JUMPER, 1/2W J | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0134 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0134 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0134 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0137 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0137 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0137 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0153 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0153 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0153 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0154 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0154 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0154 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0155 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0155 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0155 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0157 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER SUPPLY | JR 0157 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0157 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0482 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0482 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0482 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0492 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0492 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0492 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0587 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0587 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0587 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0896 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | POWER SUPPLY | JR 0896 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | POWER SUPPLY | JR 0896 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | S | POWER SUPPLY | PR 0101 | 87-026-682-080 | 0E | PROTECTOR,10A 491SERIES 60V | EZBM | AV-D77 |
| | S | POWER SUPPLY | PR 0101 | 87-026-691-080 | | FUSE,10A 125V 251 | UBM | AV-D77 |
| ! | S | POWER SUPPLY | PR 0101 | 87-026-691-080 | 1A | FUSE,10A 125V 251 | UBM | AV-D77 |
| | S | POWER SUPPLY | PR 0104 | 87-026-682-080 | 0E | PROTECTOR,10A 491SERIES 60V | EZBM | AV-D77 |
| | S | POWER SUPPLY | PR 0104 | 87-026-691-080 | | FUSE,10A 125V 251 | UBM | AV-D77 |
| ! | S | POWER SUPPLY | PR 0104 | 87-026-691-080 | 1A | FUSE,10A 125V 251 | UBM | AV-D77 |
| | S | POWER SUPPLY | PR 0107 | 87-026-682-080 | 0E | PROTECTOR,10A 491SERIES 60V | EZBM | AV-D77 |
| | S | POWER SUPPLY | PR 0107 | 87-026-691-080 | | FUSE,10A 125V 251 | UBM | AV-D77 |
| ! | S | POWER SUPPLY | PR 0107 | 87-026-691-080 | 1A | FUSE,10A 125V 251 | UBM | AV-D77 |
| | S | POWER SUPPLY | PR 0108 | 87-026-682-080 | 0E | PROTECTOR,10A 491SERIES 60V | EZBM | AV-D77 |
| | S | POWER SUPPLY | PR 0108 | 87-026-691-080 | | FUSE,10A 125V 251 | UBM | AV-D77 |
| ! | S | POWER SUPPLY | PR 0108 | 87-026-691-080 | 1A | FUSE,10A 125V 251 | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0101 | 89-110-372-080 | | C-TR,2SA1037K(R) | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0101 | 89-110-372-080 | 0E | C-TR,2SA1037K(R) | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0101 | 89-110-372-080 | 0E | C-TR,2SA1037K(R) | UBM | AV-D77 |
| | O | POWER SUPPLY | Q 0102 | 8Z-NFT-604-110 | | CONN ASSY,3P SURR | UBM | AV-D77 |
| | O | POWER SUPPLY | Q 0102 | 8Z-NFT-604-110 | 1A | CONN ASSY,3P SURR | EZBM | AV-D77 |
| | O | POWER SUPPLY | Q 0102 | 8Z-NFT-604-110 | 1A | CONN ASSY,3P SURR | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0103 | 87-A30-083-080 | | TR,CSD1489B | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0103 | 87-A30-083-080 | 0E | TR,CSD1489B | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0103 | 87-A30-083-080 | 0E | TR,CSD1489B | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0104 | 87-A30-085-040 | | C-TR,CSA1362GR | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0104 | 87-A30-085-040 | 0E | C-TR,CSA1362GR | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0105 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0105 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0106 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0106 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0106 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0107 | 87-026-610-080 | | TR,KTC3198GR | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0107 | 87-026-610-080 | 0E | TR,KTC3198GR | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0107 | 87-026-610-080 | 0E | TR,KTC3198GR | UBM | AV-D77 |
| | O | POWER SUPPLY | Q 0108 | 8Z-AR1-670-010 | | CONN ASSY,3P VM | UBM | AV-D77 |
| | O | POWER SUPPLY | Q 0108 | 8Z-AR1-670-010 | 1A | CONN ASSY,3P VM | EZBM | AV-D77 |
| | O | POWER SUPPLY | Q 0108 | 8Z-AR1-670-010 | 1A | CONN ASSY,3P VM | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0109 | 89-213-702-010 | | TR,2SB1370E | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0109 | 89-213-702-010 | 1A | TR,2SB1370E | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0109 | 89-213-702-010 | 1A | TR,2SB1370E | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0110 | 87-A30-072-080 | | C-TR,RT1P 144C | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0110 | 87-A30-072-080 | 0E | C-TR,RT1P 144C | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0110 | 87-A30-072-080 | 0E | C-TR,RT1P 144C | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0111 | 87-A30-072-080 | | C-TR,RT1P 144C | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0111 | 87-A30-072-080 | 0E | C-TR,RT1P 144C | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0111 | 87-A30-072-080 | 0E | C-TR,RT1P 144C | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0112 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0112 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0112 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0113 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0113 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0113 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0114 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0114 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0114 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0115 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0115 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0115 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0116 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | POWER SUPPLY | Q 0116 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0116 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0117 | 87-026-609-080 | | TR,KTA1266GR | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0117 | 87-026-609-080 | 0E | TR,KTA1266GR | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0117 | 87-026-609-080 | 0E | TR,KTA1266GR | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0118 | 87-026-609-080 | | TR,KTA1266GR | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0118 | 87-026-609-080 | 0E | TR,KTA1266GR | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0118 | 87-026-609-080 | 0E | TR,KTA1266GR | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0997 | 89-213-702-010 | | TR,2SB1370E | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0997 | 89-213-702-010 | 1A | TR,2SB1370E | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0997 | 89-213-702-010 | 1A | TR,2SB1370E | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0998 | 89-213-702-010 | | TR,2SB1370E | UBM | AV-D77 |
| | S | POWER SUPPLY | Q 0998 | 89-213-702-010 | 1A | TR,2SB1370E | EZBM | AV-D77 |
| | S | POWER SUPPLY | Q 0998 | 89-213-702-010 | 1A | TR,2SB1370E | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0101 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0101 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0101 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0102 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0102 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0102 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0103 | 88-118-471-080 | | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0103 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0103 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0104 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0104 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0104 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0105 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0105 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0105 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0106 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0106 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0106 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0107 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0107 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0107 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0108 | 88-118-682-080 | | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0108 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0108 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | O | POWER SUPPLY | R 0109 | 87-029-060-080 | | RES,FUSE 33-1/4W J | UBM | AV-D77 |
| ! | O | POWER SUPPLY | R 0109 | 87-029-060-080 | 0E | RES,FUSE 33-1/4W J | EZBM | AV-D77 |
| ! | O | POWER SUPPLY | R 0109 | 87-029-060-080 | 0E | RES,FUSE 33-1/4W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0110 | 88-138-393-080 | | C-RES, 39K-1/4W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0110 | 88-138-393-080 | 0E | C-RES, 39K-1/4W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0110 | 88-138-393-080 | 0E | C-RES, 39K-1/4W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0112 | 88-118-333-080 | | C-RES,S 33K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0112 | 88-118-333-080 | 0E | C-RES,S 33K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0112 | 88-118-333-080 | 0E | C-RES,S 33K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0113 | 88-118-471-080 | | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0113 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0113 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0114 | 88-118-221-080 | | C-RES,S 220-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0114 | 88-118-221-080 | 0E | C-RES,S 220-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0114 | 88-118-221-080 | 0E | C-RES,S 220-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0115 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0115 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0116 | 88-128-103-080 | | C-RES, 10K-1/8W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0116 | 88-128-103-080 | 0E | C-RES, 10K-1/8W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0116 | 88-128-103-080 | 0E | C-RES, 10K-1/8W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0117 | 88-118-334-080 | | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0117 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0117 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0118 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0118 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0118 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0120 | 88-118-471-080 | | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0120 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0120 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0121 | 88-118-680-080 | | C-RES,S 68-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0121 | 88-118-680-080 | 0E | C-RES,S 68-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0121 | 88-118-680-080 | 0E | C-RES,S 68-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER SUPPLY | R 0122 | 88-118-471-080 | | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0122 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0122 | 88-118-471-080 | 0E | C-RES,S 470-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0123 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0123 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0123 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0124 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0124 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0124 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0125 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0125 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0125 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0126 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0126 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0126 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0127 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0127 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0127 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0128 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0128 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0128 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0129 | 88-121-183-080 | | RES,18K-1/8W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0129 | 88-121-183-080 | 0E | RES,18K-1/8W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0129 | 88-121-183-080 | 0E | RES,18K-1/8W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0130 | 88-121-183-080 | | RES,18K-1/8W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0130 | 88-121-183-080 | 0E | RES,18K-1/8W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0130 | 88-121-183-080 | 0E | RES,18K-1/8W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0131 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0131 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0131 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0132 | 88-118-123-080 | | C-RES,S 12K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0132 | 88-118-123-080 | 0E | C-RES,S 12K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0132 | 88-118-123-080 | 0E | C-RES,S 12K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0133 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0133 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0133 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0134 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0134 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0134 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0135 | 88-118-100-080 | | C-RES,S 10-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0135 | 88-118-100-080 | 0E | C-RES,S 10-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0135 | 88-118-100-080 | 0E | C-RES,S 10-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0136 | 88-128-472-080 | | C-RES, 4.7K-1/8W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0136 | 88-128-472-080 | 0E | C-RES, 4.7K-1/8W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0136 | 88-128-472-080 | 0E | C-RES, 4.7K-1/8W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0137 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0137 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0137 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0138 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0138 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0138 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0139 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0139 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0139 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0140 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0140 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0140 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0141 | 88-118-333-080 | | C-RES,S 33K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0141 | 88-118-333-080 | 0E | C-RES,S 33K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0141 | 88-118-333-080 | 0E | C-RES,S 33K-1/10W J | UBM | AV-D77 |
| | O | POWER SUPPLY | R 0143 | 87-A00-259-080 | | RES,M/F 0.33-1W J | UBM | AV-D77 |
| | O | POWER SUPPLY | R 0143 | 87-A00-259-080 | 0E | RES,M/F 0.33-1W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0161 | 88-118-222-080 | | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0161 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0162 | 88-118-222-080 | | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0162 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0170 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0170 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0170 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0185 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | POWER SUPPLY | R 0185 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0185 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0186 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0186 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0186 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0187 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0187 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0187 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0188 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0188 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0188 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0198 | 88-138-393-080 | | C-RES, 39K-1/4W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0198 | 88-138-393-080 | 0E | C-RES, 39K-1/4W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0198 | 88-138-393-080 | 0E | C-RES, 39K-1/4W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0199 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0199 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0199 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0589 | 88-121-102-080 | | RES,1K-1/8W J | UBM | AV-D77 |
| | X | POWER SUPPLY | R 0589 | 88-121-102-080 | 0E | RES,1K-1/8W J | EZBM | AV-D77 |
| | X | POWER SUPPLY | R 0589 | 88-121-102-080 | 0E | RES,1K-1/8W J | UBM | AV-D77 |
| | O | POWER SUPPLY | RY 0101 | 87-A90-454-010 | | RELAY,12V DJ12D2-O(M) | UBM | AV-D77 |
| ! | O | POWER SUPPLY | RY 0101 | 87-A90-454-010 | 1E | RELAY,12V DJ12D2-O(M) | EZBM | AV-D77 |
| ! | O | POWER SUPPLY | RY 0101 | 87-A90-454-010 | 1E | RELAY,12V DJ12D2-O(M) | UBM | AV-D77 |
| | O | POWER SUPPLY | RY 0102 | 87-A90-454-010 | | RELAY,12V DJ12D2-O(M) | UBM | AV-D77 |
| ! | O | POWER SUPPLY | RY 0102 | 87-A90-454-010 | 1E | RELAY,12V DJ12D2-O(M) | EZBM | AV-D77 |
| ! | O | POWER SUPPLY | RY 0102 | 87-A90-454-010 | 1E | RELAY,12V DJ12D2-O(M) | UBM | AV-D77 |
| | O | POWER SUPPLY | S 0101 | 86-SP8-611-010 | | SW,SL 1-1-2 | UBM | AV-D77 |
| | O | POWER SUPPLY | S 0101 | 86-SP8-611-010 | 1A | SW,SL 1-1-2 | EZBM | AV-D77 |
| | O | POWER SUPPLY | S 0101 | 86-SP8-611-010 | 1A | SW,SL 1-1-2 | UBM | AV-D77 |
| | O | POWER SUPPLY | W 0003 | 8A-AR3-654-010 | | CONN ASSY,9P VH | UBM | AV-D77 |
| | O | POWER SUPPLY | W 0003 | 8A-AR3-654-010 | 1B | CONN ASSY,9P VH | EZBM | AV-D77 |
| | O | POWER SUPPLY | W 0003 | 8A-AR3-654-010 | 1B | CONN ASSY,9P VH | UBM | AV-D77 |
| | | POWER SUPPLY | W 0101 | 89-955-123-410 | | WIRE,U24H5-12-5 F | UBM | AV-D77 |
| | X | POWER SUPPLY | W 0101 | 89-955-123-410 | 0E | WIRE,U24H5-12-5 F | EZBM | AV-D77 |
| | X | POWER SUPPLY | W 0101 | 89-955-123-410 | 0E | WIRE,U24H5-12-5 F | UBM | AV-D77 |
| | X | POWER SUPPLY | W 0104 | 89-959-203-410 | | WIRE,U24 H0-20-5/5F | UBM | AV-D77 |
| | X | POWER SUPPLY | W 0104 | 89-959-203-410 | 0E | WIRE,U24 H0-20-5/5F | EZBM | AV-D77 |
| | X | POWER SUPPLY | W 0104 | 89-959-203-410 | 0E | WIRE,U24 H0-20-5/5F | UBM | AV-D77 |
| | X | POWER SUPPLY | W 0198 | 89-995-183-410 | | WIRE,U24X5-18-5 F | UBM | AV-D77 |
| | X | POWER SUPPLY | W 0198 | 89-995-183-410 | 0E | WIRE,U24X5-18-5 F | EZBM | AV-D77 |
| | X | POWER SUPPLY | W 0198 | 89-995-183-410 | 0E | WIRE,U24X5-18-5 F | UBM | AV-D77 |
| | | POWER SUPPLY | W 0199 | 89-951-123-410 | | WIRE,U24H1-12-5 F | UBM | AV-D77 |
| | X | POWER SUPPLY | W 0199 | 89-951-123-410 | 0E | WIRE,U24H1-12-5 F | EZBM | AV-D77 |
| | X | POWER SUPPLY | W 0199 | 89-951-123-410 | 0E | WIRE,U24H1-12-5 F | UBM | AV-D77 |
| | X | POWER SUPPLY | W 0302 | 89-953-083-410 | | WIRE,U24H3-8-5 | UBM | AV-D77 |
| | X | POWER SUPPLY | W 0302 | 89-953-083-410 | 0E | WIRE,U24H3-8-5 | EZBM | AV-D77 |
| | X | POWER SUPPLY | W 0302 | 89-953-083-410 | 0E | WIRE,U24H3-8-5 | UBM | AV-D77 |
| | O | POWER SUPPLY | WH 0101 | 87-A90-510-010 | | HLDR,WIRE 2.5-9P | UBM | AV-D77 |
| ! | O | POWER SUPPLY | WH 0101 | 87-A90-510-010 | 0E | HLDR,WIRE 2.5-9P | EZBM | AV-D77 |
| ! | O | POWER SUPPLY | WH 0101 | 87-A90-510-010 | 0E | HLDR,WIRE 2.5-9P | UBM | AV-D77 |
| | X | PRINTED DU | | 87-056-168-010 | 0E | SH,CAUTION INF-WARR(EC) | EZBM | AV-D77 |
| | X | PRINTED DU | | 87-B40-086-010 | | BAG,PV 0.04-230-400 PL | UBM | AV-D77 |
| | X | PRINTED DU | | 87-B40-086-010 | 0E | BAG,PV 0.04-230-400 PL | EZBM | AV-D77 |
| | X | PRINTED DU | | 87-B40-086-010 | 0E | BAG,PV 0.04-230-400 PL | UBM | AV-D77 |
| | X | PRINTED DU | | 87-B50-053-010 | | WARR-CARD,USA CUST/AV,VISUAL | UBM | AV-D77 |
| | X | PRINTED DU | | 87-B50-053-010 | 0E | WARR-CARD,USA CUST/AV,VISUAL | UBM | AV-D77 |
| | X | PRINTED DU | | 87-B50-066-010 | 0E | LIST,FACILITY(B)-TOKYO | EZBM | AV-D77 |
| | O | PRINTED DU | | 8A-AR2-906-010 | 1D | IB,EZ(9L)M | EZBM | AV-D77 |
| | O | PRINTED DU | | 8A-AR2-913-010 | | IB,U(ESF)M AV-D77 | UBM | AV-D77 |
| | O | PRINTED DU | | 8A-AR2-913-010 | 1B | IB,U(ESF)M AV-D77 | UBM | AV-D77 |
| | X | PRINTED DU | | 8A-AR2-920-010 | 0E | SH,ADDITIONAL C-SP MODE | EZBM | AV-D77 |
| | X | PRINTED DU | | 8A-AR4-920-010 | 0E | SH,ADDITIONAL REMOTE | EZBM | AV-D77 |
| | X | PT(EZ/U) | | 8A-AR2-657-110 | 1C | PWB,PT U 2M | EZBM | AV-D77 |
| | X | PT(EZ/U) | | 8A-AR3-657-010 | | PWB,PT (U,EZ) 2M | UBM | AV-D77 |
| | X | PT(EZ/U) | | 8A-AR3-657-010 | 1C | PWB,PT (U,EZ) 2M | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0001 | 87-010-237-080 | | CAP,E 1000-16 M SME | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0001 | 87-010-237-080 | 1A | CAP,E 1000-16 M SME | EZBM | AV-D77 |
| | O | PT(EZ/U) | C 0001 | 87-010-237-080 | 1A | CAP,E 1000-16 M SME | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0002 | 87-010-403-080 | | CAP,E 3.3-50 M 11L SME | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0002 | 87-010-403-080 | 0E | CAP,E 3.3-50 M 11L SME | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | PT(EZ/U) | C 0002 | 87-010-403-080 | 0E | CAP,E 3.3-50 M 11L SME | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0003 | 87-A11-148-080 | | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0003 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | EZBM | AV-D77 |
| | O | PT(EZ/U) | C 0003 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0004 | 87-A11-148-080 | | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0004 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | EZBM | AV-D77 |
| | O | PT(EZ/U) | C 0004 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0005 | 87-A11-148-080 | | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0005 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | EZBM | AV-D77 |
| | O | PT(EZ/U) | C 0005 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0007 | 87-A10-922-090 | | CAP,CER 0.01-250 M F KH | UBM | AV-D77 |
| ! | O | PT(EZ/U) | C 0007 | 87-A10-922-090 | 1A | CAP,CER 0.01-250 M F KH | EZBM | AV-D77 |
| ! | O | PT(EZ/U) | C 0007 | 87-A10-922-090 | 1A | CAP,CER 0.01-250 M F KH | UBM | AV-D77 |
| | O | PT(EZ/U) | C 0141 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | EZBM | AV-D77 |
| | O | PT(EZ/U) | CN 0101 | 88-805-042-690 | | CONN ASSY,4P | UBM | AV-D77 |
| | O | PT(EZ/U) | CN 0101 | 88-805-042-690 | 0E | CONN ASSY,4P | EZBM | AV-D77 |
| | O | PT(EZ/U) | CN 0101 | 88-805-042-690 | 0E | CONN ASSY,4P | UBM | AV-D77 |
| | O | PT(EZ/U) | CN 0103 | 87-A61-057-010 | | CONN,9P V THL-P09P-A1 | UBM | AV-D77 |
| | O | PT(EZ/U) | CN 0103 | 87-A61-057-010 | 0E | CONN,9P V THL-P09P-A1 | EZBM | AV-D77 |
| | O | PT(EZ/U) | CN 0103 | 87-A61-057-010 | 0E | CONN,9P V THL-P09P-A1 | UBM | AV-D77 |
| | O | PT(EZ/U) | CNA0001 | 8A-AR3-651-010 | | CONN ASSY,2P AC-OUTLET | UBM | AV-D77 |
| | O | PT(EZ/U) | CNA0001 | 8A-AR3-651-110 | 1B | CONN ASSY,2P AC-OUTLET | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0001 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0001 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | PT(EZ/U) | D 0001 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0002 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0002 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | PT(EZ/U) | D 0002 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0003 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0003 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | PT(EZ/U) | D 0003 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0004 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0004 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | PT(EZ/U) | D 0004 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0005 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0005 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | PT(EZ/U) | D 0005 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0006 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0006 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | PT(EZ/U) | D 0006 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0007 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | PT(EZ/U) | D 0007 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | PT(EZ/U) | D 0007 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | O | PT(EZ/U) | FC 0101 | 87-A90-160-080 | | FUSE CLAMP,FC 51F | UBM | AV-D77 |
| | O | PT(EZ/U) | FC 0101 | 87-A90-160-080 | 0E | FUSE CLAMP,FC 51F | EZBM | AV-D77 |
| | O | PT(EZ/U) | FC 0101 | 87-A90-160-080 | 0E | FUSE CLAMP,FC 51F | UBM | AV-D77 |
| | O | PT(EZ/U) | FC 0102 | 87-A90-160-080 | | FUSE CLAMP,FC 51F | UBM | AV-D77 |
| | O | PT(EZ/U) | FC 0102 | 87-A90-160-080 | 0E | FUSE CLAMP,FC 51F | EZBM | AV-D77 |
| | O | PT(EZ/U) | FC 0102 | 87-A90-160-080 | 0E | FUSE CLAMP,FC 51F | UBM | AV-D77 |
| | S | PT(EZ/U) | PR 0001 | 87-A91-276-080 | | FUSE,125MA 125V F 251 | UBM | AV-D77 |
| ! | S | PT(EZ/U) | PR 0001 | 87-A91-276-080 | 1B | FUSE,125MA 125V F 251 | UBM | AV-D77 |
| | X | PT(EZ/U) | PR 0001 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| ! | S | PT(EZ/U) | PR 0105 | 87-A90-195-080 | 1A | PROTECTOR,7A 491SERIES 60V | EZBM | AV-D77 |
| | S | PT(EZ/U) | PR 0105 | 87-A90-210-080 | | FUSE,7A 125V 251 | UBM | AV-D77 |
| ! | S | PT(EZ/U) | PR 0105 | 87-A90-210-080 | 1A | FUSE,7A 125V 251 | UBM | AV-D77 |
| ! | S | PT(EZ/U) | PR 0106 | 87-A90-195-080 | 1A | PROTECTOR,7A 491SERIES 60V | EZBM | AV-D77 |
| | S | PT(EZ/U) | PR 0106 | 87-A90-210-080 | | FUSE,7A 125V 251 | UBM | AV-D77 |
| ! | S | PT(EZ/U) | PR 0106 | 87-A90-210-080 | 1A | FUSE,7A 125V 251 | UBM | AV-D77 |
| ! | S | PT(EZ/U) | PR 0115 | 87-A90-195-080 | 1A | PROTECTOR,7A 491SERIES 60V | EZBM | AV-D77 |
| | S | PT(EZ/U) | PR 0115 | 87-A90-210-080 | | FUSE,7A 125V 251 | UBM | AV-D77 |
| ! | S | PT(EZ/U) | PR 0115 | 87-A90-210-080 | 1A | FUSE,7A 125V 251 | UBM | AV-D77 |
| ! | S | PT(EZ/U) | PR 0116 | 87-A90-195-080 | 1A | PROTECTOR,7A 491SERIES 60V | EZBM | AV-D77 |
| | S | PT(EZ/U) | PR 0116 | 87-A90-210-080 | | FUSE,7A 125V 251 | UBM | AV-D77 |
| ! | S | PT(EZ/U) | PR 0116 | 87-A90-210-080 | 1A | FUSE,7A 125V 251 | UBM | AV-D77 |
| ! | O | PT(EZ/U) | PT 0002 | 8Z-NF8-659-010 | 1C | PT,SUB ZNF-8(E)TAM | EZBM | AV-D77 |
| | S | PT(EZ/U) | Q 0001 | 87-A30-197-080 | | TR,KTA1267GR | UBM | AV-D77 |
| | S | PT(EZ/U) | Q 0001 | 87-A30-197-080 | 0E | TR,KTA1267GR | EZBM | AV-D77 |
| | S | PT(EZ/U) | Q 0001 | 87-A30-197-080 | 0E | TR,KTA1267GR | UBM | AV-D77 |
| | S | PT(EZ/U) | Q 0002 | 87-026-245-080 | | TR,DTC114ES | UBM | AV-D77 |
| | S | PT(EZ/U) | Q 0002 | 87-026-245-080 | 0E | TR,DTC114ES | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | PT(EZ/U) | Q 0002 | 87-026-245-080 | 0E | TR,DTC114ES | UBM | AV-D77 |
| | S | PT(EZ/U) | Q 0003 | 87-A30-198-080 | | TR,KTC3199GR | UBM | AV-D77 |
| | S | PT(EZ/U) | Q 0003 | 87-A30-198-080 | 0E | TR,KTC3199GR | EZBM | AV-D77 |
| | S | PT(EZ/U) | Q 0003 | 87-A30-198-080 | 0E | TR,KTC3199GR | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0001 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0001 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | PT(EZ/U) | R 0001 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0002 | 88-121-222-080 | | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0002 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | EZBM | AV-D77 |
| | X | PT(EZ/U) | R 0002 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0003 | 88-121-222-080 | | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0003 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | EZBM | AV-D77 |
| | X | PT(EZ/U) | R 0003 | 88-121-222-080 | 0E | RES,2.2K-1/8W J | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0005 | 88-121-333-080 | | RES,33K-1/8W J | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0005 | 88-121-333-080 | 0E | RES,33K-1/8W J | EZBM | AV-D77 |
| | X | PT(EZ/U) | R 0005 | 88-121-333-080 | 0E | RES,33K-1/8W J | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0006 | 88-121-101-080 | | RES,100-1/8W J | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0006 | 88-121-101-080 | 0E | RES,100-1/8W J | EZBM | AV-D77 |
| | X | PT(EZ/U) | R 0006 | 88-121-101-080 | 0E | RES,100-1/8W J | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0007 | 88-140-225-080 | | RES,2.2M-1/2W J | UBM | AV-D77 |
| | X | PT(EZ/U) | R 0007 | 88-140-225-080 | 0E | RES,2.2M-1/2W J | UBM | AV-D77 |
| | O | PT(EZ/U) | RY 0001 | 87-A91-368-010 | | RELAY,ACDC12V DG12D-O(M)-2 | UBM | AV-D77 |
| ! | O | PT(EZ/U) | RY 0001 | 87-A91-368-010 | 1C | RELAY,ACDC12V DG12D-O(M)-2 | EZBM | AV-D77 |
| ! | O | PT(EZ/U) | RY 0001 | 87-A91-368-010 | 1C | RELAY,ACDC12V DG12D-O(M)-2 | UBM | AV-D77 |
| | O | PT(EZ/U) | T 0001 | 87-A60-317-010 | | TERMINAL, 1P MSC | UBM | AV-D77 |
| | O | PT(EZ/U) | T 0001 | 87-A60-317-010 | 0E | TERMINAL, 1P MSC | EZBM | AV-D77 |
| | O | PT(EZ/U) | T 0001 | 87-A60-317-010 | 0E | TERMINAL, 1P MSC | UBM | AV-D77 |
| | O | PT(EZ/U) | T 0002 | 87-A60-317-010 | | TERMINAL, 1P MSC | UBM | AV-D77 |
| | O | PT(EZ/U) | T 0002 | 87-A60-317-010 | 0E | TERMINAL, 1P MSC | EZBM | AV-D77 |
| | O | PT(EZ/U) | T 0002 | 87-A60-317-010 | 0E | TERMINAL, 1P MSC | UBM | AV-D77 |
| ! | X | PT(EZ/U) | W 0004 | 81-653-659-010 | 0E | WIRE ASSY | EZBM | AV-D77 |
| | X | PT(EZ/U)CB MECHA | | 8Z-AR1-218-010 | 1C | PLATE,SUB PT B | EZBM | AV-D77 |
| | X | S-VIDEO | | 81-653-659-010 | | WIRE ASSY | UBM | AV-D77 |
| ! | X | S-VIDEO | | 81-653-659-010 | 0E | WIRE ASSY | UBM | AV-D77 |
| | X | S-VIDEO | * | 8A-AR1-618-110 | | PWB,S-VIDEO 3M | UBM | AV-D77 |
| | X | S-VIDEO | * | 8A-AR1-618-110 | 1D | PWB,S-VIDEO 3M | UBM | AV-D77 |
| | O | S-VIDEO | C 0601 | 87-010-382-080 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0601 | 87-010-382-080 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0602 | 87-010-382-080 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0602 | 87-010-382-080 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0603 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0603 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0604 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0604 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0605 | 87-010-371-080 | | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0605 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0606 | 87-010-371-080 | | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0606 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0607 | 87-010-382-080 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0607 | 87-010-382-080 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0608 | 87-010-382-080 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0608 | 87-010-382-080 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0609 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0609 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0610 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0610 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0611 | 87-010-371-080 | | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0611 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0612 | 87-010-371-080 | | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0612 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0613 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0613 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0614 | 87-010-322-080 | | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0614 | 87-010-322-080 | 0E | C-CAP,S 100P-50 J CH GRM | UBM | AV-D77 |
| | O | S-VIDEO | C 0615 | 87-010-371-080 | | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0615 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0616 | 87-010-371-080 | | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0616 | 87-010-371-080 | 0E | CAP,E 470-6.3 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0617 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | S-VIDEO | C 0617 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | S-VIDEO | C 0618 | 87-010-387-080 | | CAP,E 470-25 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0618 | 87-010-387-080 | 1A | CAP,E 470-25 M SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0619 | 87-010-382-080 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0619 | 87-010-382-080 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0620 | 87-010-382-080 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0620 | 87-010-382-080 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0621 | 87-010-382-080 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0621 | 87-010-382-080 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0622 | 87-010-382-080 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0622 | 87-010-382-080 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0623 | 87-010-263-080 | | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0623 | 87-010-263-080 | 0E | CAP,E 100-10 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0624 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | S-VIDEO | C 0624 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | S-VIDEO | C 0639 | 87-010-382-080 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0639 | 87-010-382-080 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0640 | 87-010-382-080 | | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | C 0640 | 87-010-382-080 | 0E | CAP,E 22-25 M 11L SME | UBM | AV-D77 |
| | O | S-VIDEO | CN 0601 | 87-A60-063-010 | | CONN,04P V 9604S-04C | UBM | AV-D77 |
| | O | S-VIDEO | CN 0601 | 87-A60-063-010 | 0E | CONN,04P V 9604S-04C | UBM | AV-D77 |
| | S | S-VIDEO | D 0621 | 87-070-136-080 | | ZENER,MTZJ5.1B | UBM | AV-D77 |
| | S | S-VIDEO | D 0621 | 87-070-136-080 | 0E | ZENER,MTZJ5.1B | UBM | AV-D77 |
| | S | S-VIDEO | IC 0601 | 87-A20-820-010 | | IC,BA7625 | UBM | AV-D77 |
| | S | S-VIDEO | IC 0601 | 87-A20-820-010 | 1C | IC,BA7625 | UBM | AV-D77 |
| | S | S-VIDEO | IC 0602 | 87-A20-820-010 | | IC,BA7625 | UBM | AV-D77 |
| | S | S-VIDEO | IC 0602 | 87-A20-820-010 | 1C | IC,BA7625 | UBM | AV-D77 |
| | O | S-VIDEO | J 0801 | 87-A61-213-010 | | JACK,Y/C YKF51-5501 | UBM | AV-D77 |
| | O | S-VIDEO | J 0801 | 87-A61-213-010 | 1E | JACK,Y/C YKF51-5501 | UBM | AV-D77 |
| | O | S-VIDEO | J 0802 | 87-A61-213-010 | | JACK,Y/C YKF51-5501 | UBM | AV-D77 |
| | O | S-VIDEO | J 0802 | 87-A61-213-010 | 1E | JACK,Y/C YKF51-5501 | UBM | AV-D77 |
| | O | S-VIDEO | J 0803 | 87-A61-213-010 | | JACK,Y/C YKF51-5501 | UBM | AV-D77 |
| | O | S-VIDEO | J 0803 | 87-A61-213-010 | 1E | JACK,Y/C YKF51-5501 | UBM | AV-D77 |
| | O | S-VIDEO | J 0804 | 87-A61-213-010 | | JACK,Y/C YKF51-5501 | UBM | AV-D77 |
| | O | S-VIDEO | J 0804 | 87-A61-213-010 | 1E | JACK,Y/C YKF51-5501 | UBM | AV-D77 |
| | O | S-VIDEO | J 0805 | 87-A60-127-010 | | JACK,Y/CYKF51-5503 | UBM | AV-D77 |
| ! | O | S-VIDEO | J 0805 | 87-A60-127-010 | 1B | JACK,Y/CYKF51-5503 | UBM | AV-D77 |
| | X | S-VIDEO | JR 0600 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | S-VIDEO | JR 0600 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | S-VIDEO | JR 0611 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | S-VIDEO | JR 0611 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | S-VIDEO | JR 0612 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | S-VIDEO | JR 0612 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | S-VIDEO | JR 0613 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | S-VIDEO | JR 0613 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | S-VIDEO | JR 0614 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | S-VIDEO | JR 0614 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | S-VIDEO | JR 0615 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | S-VIDEO | JR 0615 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | S-VIDEO | L 0601 | 87-003-136-080 | | COIL,100UH K LAL04 | UBM | AV-D77 |
| | O | S-VIDEO | L 0601 | 87-003-136-080 | 0E | COIL,100UH K LAL04 | UBM | AV-D77 |
| | S | S-VIDEO | Q 0614 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0614 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0615 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0615 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0616 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0616 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0617 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0617 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0618 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0618 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0619 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | S-VIDEO | Q 0619 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | X | S-VIDEO | R 0601 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0601 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0602 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0602 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0603 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0603 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0604 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0604 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | S-VIDEO | R 0605 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0605 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0606 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0606 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0607 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0607 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0608 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0608 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0609 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0609 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0610 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0610 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0611 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0611 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0612 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0612 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0613 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0613 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0614 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0614 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0615 | 88-121-101-080 | | RES,100-1/8W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0615 | 88-121-101-080 | 0E | RES,100-1/8W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0616 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0616 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0617 | 88-121-101-080 | | RES,100-1/8W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0617 | 88-121-101-080 | 0E | RES,100-1/8W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0618 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0618 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0619 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0619 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0620 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0620 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0621 | 88-130-471-080 | | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0621 | 88-130-471-080 | 0E | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0622 | 88-130-471-080 | | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0622 | 88-130-471-080 | 0E | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0623 | 88-130-471-080 | | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0623 | 88-130-471-080 | 0E | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0624 | 88-130-471-080 | | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0624 | 88-130-471-080 | 0E | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0625 | 88-130-471-080 | | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0625 | 88-130-471-080 | 0E | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0626 | 88-130-471-080 | | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0626 | 88-130-471-080 | 0E | RES,470-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0630 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0630 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0631 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0631 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0634 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0634 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0635 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0635 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0659 | 88-130-820-080 | | RES,82-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0659 | 88-130-820-080 | 0E | RES,82-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0660 | 88-130-820-080 | | RES,82-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0660 | 88-130-820-080 | 0E | RES,82-1/4W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0669 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0669 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0670 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0670 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0671 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0671 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0672 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0672 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0673 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0673 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0674 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0674 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0680 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0680 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | S-VIDEO | R 0681 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0681 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | S-VIDEO | R 0684 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | S-VIDEO | R 0684 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | SCREW | | 87-067-579-010 | | BVT2+3-8 W/O SL0T | UBM | AV-D77 |
| | O | SCREW | | 87-067-579-010 | 0E | BVT2+3-8 W/O SL0T | UBM | AV-D77 |
| | O | SCREW | | 87-067-581-010 | | BVT2+3-15 W/O SL0T | UBM | AV-D77 |
| | O | SCREW | | 87-067-581-010 | 0E | BVT2+3-15 W/O SL0T | EZBM | AV-D77 |
| | O | SCREW | | 87-067-581-010 | 0E | BVT2+3-15 W/O SL0T | UBM | AV-D77 |
| | O | SCREW | | 87-067-584-010 | | BVT2+3-6 W/O SL0T | UBM | AV-D77 |
| | O | SCREW | | 87-067-584-010 | 0E | BVT2+3-6 W/O SL0T | EZBM | AV-D77 |
| | O | SCREW | | 87-067-584-010 | 0E | BVT2+3-6 W/O SL0T | UBM | AV-D77 |
| | O | SCREW | | 87-067-585-010 | | BVTT+4-6 | UBM | AV-D77 |
| | O | SCREW | | 87-067-585-010 | 0E | BVTT+4-6 | EZBM | AV-D77 |
| | O | SCREW | | 87-067-585-010 | 0E | BVTT+4-6 | UBM | AV-D77 |
| | O | SCREW | | 87-067-632-010 | | BVT2+3-15 W/O SLOT W/CONVEX | UBM | AV-D77 |
| | O | SCREW | | 87-067-632-010 | 0E | BVT2+3-15 W/O SLOT W/CONVEX | EZBM | AV-D77 |
| | O | SCREW | | 87-067-632-010 | 0E | BVT2+3-15 W/O SLOT W/CONVEX | UBM | AV-D77 |
| | O | SCREW | | 87-067-633-010 | | BVT2+3-8 W/O SLOT W/CONVEX | UBM | AV-D77 |
| | O | SCREW | | 87-067-633-010 | 0E | BVT2+3-8 W/O SLOT W/CONVEX | EZBM | AV-D77 |
| | O | SCREW | | 87-067-633-010 | 0E | BVT2+3-8 W/O SLOT W/CONVEX | UBM | AV-D77 |
| | O | SCREW | | 87-067-641-010 | | UTT2+3-8 W/O SLOT BLK | UBM | AV-D77 |
| | O | SCREW | | 87-067-641-010 | 0E | UTT2+3-8 W/O SLOT BLK | EZBM | AV-D77 |
| | O | SCREW | | 87-067-641-010 | 0E | UTT2+3-8 W/O SLOT BLK | UBM | AV-D77 |
| | O | SCREW | | 87-067-689-010 | | BVTT+3-8 | UBM | AV-D77 |
| | O | SCREW | | 87-067-689-010 | 0E | BVTT+3-8 | EZBM | AV-D77 |
| | O | SCREW | | 87-067-689-010 | 0E | BVTT+3-8 | UBM | AV-D77 |
| | O | SCREW | | 87-067-703-010 | | BVT2+3-10 W/O SL0T | UBM | AV-D77 |
| | O | SCREW | | 87-067-703-010 | 0E | BVT2+3-10 W/O SL0T | EZBM | AV-D77 |
| | O | SCREW | | 87-067-703-010 | 0E | BVT2+3-10 W/O SL0T | UBM | AV-D77 |
| | O | SCREW | | 87-078-191-010 | | S-SCREW,IT+4-10 SWCH12A | UBM | AV-D77 |
| | O | SCREW | | 87-078-191-010 | 0E | S-SCREW,IT+4-10 SWCH12A | EZBM | AV-D77 |
| | O | SCREW | | 87-078-191-010 | 0E | S-SCREW,IT+4-10 SWCH12A | UBM | AV-D77 |
| | O | SCREW | | 87-591-095-410 | | QIT+3-8 | UBM | AV-D77 |
| | O | SCREW | | 87-591-095-410 | 0E | QIT+3-8 | EZBM | AV-D77 |
| | O | SCREW | | 87-591-095-410 | 0E | QIT+3-8 | UBM | AV-D77 |
| | O | SCREW | | 87-721-095-410 | | QT2+3-8 W/O SL0T | UBM | AV-D77 |
| | O | SCREW | | 87-721-095-410 | 0E | QT2+3-8 W/O SL0T | EZBM | AV-D77 |
| | O | SCREW | | 87-721-095-410 | 0E | QT2+3-8 W/O SL0T | UBM | AV-D77 |
| | O | SCREW | | 87-B10-091-010 | | UTT2+3-10 W/O SLOT BLK | UBM | AV-D77 |
| | O | SCREW | | 87-B10-091-010 | 0E | UTT2+3-10 W/O SLOT BLK | UBM | AV-D77 |
| | X | SPKR | | 8A-AR3-628-010 | | PWB,SPKR 3M | UBM | AV-D77 |
| | X | SPKR | | 8A-AR3-628-110 | 1B | PWB,SPKR 3M | EZBM | AV-D77 |
| | X | SPKR | | 8A-AR3-628-110 | 1B | PWB,SPKR 3M | UBM | AV-D77 |
| | O | SPKR | C 0001 | 87-010-191-080 | 0E | C-CAP,S 0.015-50 Z F GRM | EZBM | AV-D77 |
| | O | SPKR | C 0002 | 87-010-190-080 | 0E | C-CAP,S 0.01-50 Z F C2012 | EZBM | AV-D77 |
| | O | SPKR | C 0004 | 87-010-191-080 | 0E | C-CAP,S 0.015-50 Z F GRM | EZBM | AV-D77 |
| | O | SPKR | C 0005 | 87-010-191-080 | 0E | C-CAP,S 0.015-50 Z F GRM | EZBM | AV-D77 |
| | O | SPKR | C 0008 | 87-010-191-080 | 0E | C-CAP,S 0.015-50 Z F GRM | EZBM | AV-D77 |
| | O | SPKR | C 0009 | 87-010-191-080 | 0E | C-CAP,S 0.015-50 Z F GRM | EZBM | AV-D77 |
| | O | SPKR | C 0012 | 87-010-191-080 | 0E | C-CAP,S 0.015-50 Z F GRM | EZBM | AV-D77 |
| | O | SPKR | C 0013 | 87-010-191-080 | 0E | C-CAP,S 0.015-50 Z F GRM | EZBM | AV-D77 |
| | O | SPKR | C 0016 | 87-010-190-080 | 0E | C-CAP,S 0.01-50 Z F C2012 | EZBM | AV-D77 |
| | O | SPKR | CN 0201 | 87-099-799-010 | | CONN,8P V B8P-VH | UBM | AV-D77 |
| | O | SPKR | CN 0201 | 87-099-799-010 | 1A | CONN,8P V B8P-VH | EZBM | AV-D77 |
| | O | SPKR | CN 0201 | 87-099-799-010 | 1A | CONN,8P V B8P-VH | UBM | AV-D77 |
| | O | SPKR | CN 0202 | 87-009-663-010 | | CONN,6P V VH | UBM | AV-D77 |
| | O | SPKR | CN 0202 | 87-009-663-010 | 1A | CONN,6P V VH | EZBM | AV-D77 |
| | O | SPKR | CN 0202 | 87-009-663-010 | 1A | CONN,6P V VH | UBM | AV-D77 |
| | O | SPKR | J 0901 | 87-033-210-010 | | TERMINAL,SPKR 8P LTS0810-1002 | UBM | AV-D77 |
| | O | SPKR | J 0901 | 87-033-210-010 | 1H | TERMINAL,SPKR 8P LTS0810-1002 | UBM | AV-D77 |
| | O | SPKR | J 0901 | 87-A61-051-010 | 1F | TERMINAL,SPKR LTS0820-1003 | EZBM | AV-D77 |
| | O | SPKR | J 0902 | 87-A60-965-010 | 1E | TERMINAL,SP 6P LTS0620-2002 | EZBM | AV-D77 |
| | O | SPKR | J 0902 | 87-A61-172-010 | | TERMINAL,SPKR 6P LTS0610-1002 | UBM | AV-D77 |
| | O | SPKR | J 0902 | 87-A61-172-010 | 1E | TERMINAL,SPKR 6P LTS0610-1002 | UBM | AV-D77 |
| | O | SUBW | C 0131 | 87-010-404-080 | | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | SUBW | C 0131 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | EZBM | AV-D77 |
| | O | SUBW | C 0131 | 87-010-404-080 | 0E | CAP,E 4.7-50 M 11L SME | UBM | AV-D77 |
| | O | SUBW | C 0133 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | SUBW | C 0133 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | SUBW | C 0133 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | SUBW | C 0135 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | SUBW | C 0135 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | SUBW | C 0135 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | SUBW | C 0136 | 87-012-368-080 | | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | O | SUBW | C 0136 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | EZBM | AV-D77 |
| | O | SUBW | C 0136 | 87-012-368-080 | 0E | C-CAP,S 0.1-50 Z F | UBM | AV-D77 |
| | S | SUBW | IC 0101 | 87-A21-419-040 | 0E | C-IC,NJM14558MD-TE2 | EZBM | AV-D77 |
| | S | SUBW | IC 0101 | 87-A21-419-040 | 0E | C-IC,NJM14558MD-TE2 | UBM | AV-D77 |
| O | S | SUBW | IC 0101 | 87-A21-419-040 | | C-IC,NJM14558MD-TE2 | UBM | AV-D77 |
| | X | SUBW | R 0111 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0111 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | SUBW | R 0111 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0151 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0151 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | SUBW | R 0151 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0155 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0155 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | SUBW | R 0155 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0175 | 88-118-222-080 | | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0175 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | EZBM | AV-D77 |
| | X | SUBW | R 0175 | 88-118-222-080 | 0E | C-RES,S 2.2K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0177 | 88-128-102-080 | | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | SUBW | R 0177 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | EZBM | AV-D77 |
| | X | SUBW | R 0177 | 88-128-102-080 | 0E | C-RES, 1K-1/8W J | UBM | AV-D77 |
| | X | SUBW | R 0178 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0178 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | SUBW | R 0178 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0181 | 88-118-104-080 | | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | X | SUBW | R 0181 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | EZBM | AV-D77 |
| | X | SUBW | R 0181 | 88-118-104-080 | 0E | C-RES,S 100K-1/10W J | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0149 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0149 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0149 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0150 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0150 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0150 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0151 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0151 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0151 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0152 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0152 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0152 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0153 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0153 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0153 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0154 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0154 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0154 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0155 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0155 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0155 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0156 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0156 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0156 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0157 | 87-010-408-080 | | CAP,E 47-50 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0157 | 87-010-408-080 | 0E | CAP,E 47-50 M 11L SME | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0157 | 87-010-408-080 | 0E | CAP,E 47-50 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0158 | 87-010-248-080 | | CAP,E 220-10 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0158 | 87-010-248-080 | 0E | CAP,E 220-10 M 11L SME | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0158 | 87-010-248-080 | 0E | CAP,E 220-10 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0159 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0159 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0159 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0167 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0167 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0167 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0168 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0168 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | C 0168 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | SURR/CENTER VOL | C 0169 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0169 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0169 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0170 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0170 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0170 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0171 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0171 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0171 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0172 | 87-010-154-080 | | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0172 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0172 | 87-010-154-080 | 0E | C-CAP,S 10P-50 D CH GRM | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0173 | 87-010-405-080 | | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0173 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0173 | 87-010-405-080 | 0E | CAP,E 10-50 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0174 | 87-010-401-080 | | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0174 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0174 | 87-010-401-080 | 0E | CAP,E 1-50 M 11L SME | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0175 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0175 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | C 0175 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | S | SURR/CENTER VOL | D 0145 | 87-A40-347-080 | | ZENER,MTZJ2.2B | UBM | AV-D77 |
| | S | SURR/CENTER VOL | D 0145 | 87-A40-347-080 | 0E | ZENER,MTZJ2.2B | EZBM | AV-D77 |
| | S | SURR/CENTER VOL | D 0145 | 87-A40-347-080 | 0E | ZENER,MTZJ2.2B | UBM | AV-D77 |
| | S | SURR/CENTER VOL | D 0146 | 87-A40-347-080 | | ZENER,MTZJ2.2B | UBM | AV-D77 |
| | S | SURR/CENTER VOL | D 0146 | 87-A40-347-080 | 0E | ZENER,MTZJ2.2B | EZBM | AV-D77 |
| | S | SURR/CENTER VOL | D 0146 | 87-A40-347-080 | 0E | ZENER,MTZJ2.2B | UBM | AV-D77 |
| | S | SURR/CENTER VOL | IC 0145 | 87-A20-715-010 | | IC,M62439SP | UBM | AV-D77 |
| | S | SURR/CENTER VOL | IC 0145 | 87-A20-715-010 | 1C | IC,M62439SP | EZBM | AV-D77 |
| | S | SURR/CENTER VOL | IC 0145 | 87-A20-715-010 | 1C | IC,M62439SP | UBM | AV-D77 |
| | S | SURR/CENTER VOL | IC 0146 | 87-A20-715-010 | | IC,M62439SP | UBM | AV-D77 |
| | S | SURR/CENTER VOL | IC 0146 | 87-A20-715-010 | 1C | IC,M62439SP | EZBM | AV-D77 |
| | S | SURR/CENTER VOL | IC 0146 | 87-A20-715-010 | 1C | IC,M62439SP | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0158 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0158 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0158 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0180 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0180 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0180 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0181 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0181 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0181 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0182 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0182 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0182 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0185 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0185 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0185 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0186 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0186 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0186 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0566 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0566 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0566 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0705 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0705 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0705 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0710 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0710 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0710 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0722 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0722 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0722 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0723 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0723 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0723 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0731 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0731 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0731 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0761 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | SURR/CENTER VOL | JR 0761 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | JR 0761 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0142 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0142 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0145 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0145 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0145 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0146 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0146 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0146 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0147 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0147 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0147 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0148 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0148 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0148 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0152 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0152 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0152 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0153 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0153 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0153 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0154 | 88-118-123-080 | | C-RES,S 12K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0154 | 88-118-123-080 | 0E | C-RES,S 12K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0154 | 88-118-123-080 | 0E | C-RES,S 12K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0156 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0156 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0156 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0157 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0157 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0157 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0158 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0158 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0158 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0159 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0159 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0159 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0160 | 88-118-223-080 | | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0160 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0160 | 88-118-223-080 | 0E | C-RES,S 22K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0169 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0169 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0169 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0172 | 88-118-473-080 | | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0172 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0172 | 88-118-473-080 | 0E | C-RES,S 47K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0173 | 88-118-123-080 | | C-RES,S 12K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0173 | 88-118-123-080 | 0E | C-RES,S 12K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0173 | 88-118-123-080 | 0E | C-RES,S 12K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0174 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0174 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0174 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | O | SURR/CENTER VOL | R 0176 | 87-A00-401-050 | | RES,M/F 390-1W J VTP | UBM | AV-D77 |
| | O | SURR/CENTER VOL | R 0176 | 87-A00-401-050 | 1B | RES,M/F 390-1W J VTP | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | R 0176 | 87-A00-401-050 | 1B | RES,M/F 390-1W J VTP | UBM | AV-D77 |
| | O | SURR/CENTER VOL | R 0179 | 87-A00-373-050 | 0E | RES,M/F 270-1W J VTP | EZBM | AV-D77 |
| | O | SURR/CENTER VOL | R 0179 | 87-A00-402-050 | | RES,M/F 560-1W J VTP | UBM | AV-D77 |
| | O | SURR/CENTER VOL | R 0179 | 87-A00-402-050 | 1B | RES,M/F 560-1W J VTP | UBM | AV-D77 |
| | O | SURR/CENTER VOL | R 0180 | 87-A00-403-080 | 1B | RES,M/F 560-1W J T52L25.5 | EZBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0180 | 88-130-101-080 | | RES,100-1/4W J | UBM | AV-D77 |
| | X | SURR/CENTER VOL | R 0180 | 88-130-101-080 | 0E | RES,100-1/4W J | UBM | AV-D77 |
| | O | TAPE MONITOR | C 0701 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | TAPE MONITOR | C 0701 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | TAPE MONITOR | C 0701 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | TAPE MONITOR | C 0702 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | TAPE MONITOR | C 0702 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | TAPE MONITOR | C 0702 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | S | TAPE MONITOR | IC 0701 | 87-020-784-080 | 1B | C-IC,TC4053BF | EZBM | AV-D77 |
| | S | TAPE MONITOR | IC 0701 | 87-020-784-080 | 1B | C-IC,TC4053BF | UBM | AV-D77 |
| O | S | TAPE MONITOR | IC 0701 | 87-020-784-080 | | C-IC,TC4053BF | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | TAPE MONITOR | JR 0551 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | TAPE MONITOR | JR 0551 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | TAPE MONITOR | JR 0551 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | TAPE MONITOR | JR 0762 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | TAPE MONITOR | JR 0762 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | TAPE MONITOR | JR 0762 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | TAPE MONITOR | JR 0763 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | TAPE MONITOR | JR 0763 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | TAPE MONITOR | JR 0763 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | TAPE MONITOR | JR 0919 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | TAPE MONITOR | JR 0919 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | TAPE MONITOR | JR 0919 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0701 | 88-128-562-080 | | C-RES, 5.6K-1/8W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0701 | 88-128-562-080 | 0E | C-RES, 5.6K-1/8W J | EZBM | AV-D77 |
| | X | TAPE MONITOR | R 0701 | 88-128-562-080 | 0E | C-RES, 5.6K-1/8W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0702 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0702 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | TAPE MONITOR | R 0702 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0704 | 88-118-183-080 | | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0704 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | EZBM | AV-D77 |
| | X | TAPE MONITOR | R 0704 | 88-118-183-080 | 0E | C-RES,S 18K-1/10W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0705 | 88-118-103-080 | | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0705 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | EZBM | AV-D77 |
| | X | TAPE MONITOR | R 0705 | 88-118-103-080 | 0E | C-RES,S 10K-1/10W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0706 | 88-118-392-080 | | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0706 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | EZBM | AV-D77 |
| | X | TAPE MONITOR | R 0706 | 88-118-392-080 | 0E | C-RES,S 3.9K-1/10W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0707 | 88-118-153-080 | | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | TAPE MONITOR | R 0707 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | EZBM | AV-D77 |
| | X | TAPE MONITOR | R 0707 | 88-118-153-080 | 0E | C-RES,S 15K-1/10W J | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-626-110 | | PWB,HP/VIDEO3/ VOLUME/GEQ | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-626-310 | 1D | PWB,HP/VIDEO3/ VOLUME/GEQ | EZBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-626-310 | 1D | PWB,HP/VIDEO3/ VOLUME/GEQ | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-627-110 | | PWB,VIDEO3 | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-627-310 | -- | PWB,VIDEO3 | EZBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-627-310 | -- | PWB,VIDEO3 | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-628-110 | | PWB,VOLUME | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-628-310 | -- | PWB,VOLUME | EZBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-628-310 | -- | PWB,VOLUME | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-629-110 | | PWB,GEQ | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-629-310 | -- | PWB,GEQ | EZBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-629-310 | -- | PWB,GEQ | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-630-110 | | PWB,FFC1 | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-630-310 | -- | PWB,FFC1 | EZBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-630-310 | -- | PWB,FFC1 | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-631-110 | | PWB,FFC2 | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-632-110 | | PWB,FFC3 | UBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-632-310 | -- | PWB,FFC3 | EZBM | AV-D77 |
| | X | VIDEO3 | | 8A-AR1-632-310 | -- | PWB,FFC3 | UBM | AV-D77 |
| | O | VIDEO3 | C 0501 | 87-A11-148-080 | | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | VIDEO3 | C 0501 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | EZBM | AV-D77 |
| | O | VIDEO3 | C 0501 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | VIDEO3 | C 0502 | 87-A11-148-080 | | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | VIDEO3 | C 0502 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | EZBM | AV-D77 |
| | O | VIDEO3 | C 0502 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | VIDEO3 | C 0503 | 87-010-188-080 | | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | VIDEO3 | C 0503 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | EZBM | AV-D77 |
| | O | VIDEO3 | C 0503 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | VIDEO3 | C 0504 | 87-010-188-080 | | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | VIDEO3 | C 0504 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | EZBM | AV-D77 |
| | O | VIDEO3 | C 0504 | 87-010-188-080 | 0E | C-CAP,S 6800P-50 K B C2012 | UBM | AV-D77 |
| | O | VIDEO3 | C 0507 | 87-A11-148-080 | | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | VIDEO3 | C 0507 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | EZBM | AV-D77 |
| | O | VIDEO3 | C 0507 | 87-A11-148-080 | 0E | CAP,TC U 0.1-50 Z F | UBM | AV-D77 |
| | O | VIDEO3 | C 0651 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | VIDEO3 | C 0652 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | VIDEO3 | CN 0604 | 87-099-201-010 | | CONN,8P H BLK 6216 | UBM | AV-D77 |
| ! | O | VIDEO3 | CN 0604 | 87-099-201-010 | 0E | CONN,8P H BLK 6216 | EZBM | AV-D77 |
| ! | O | VIDEO3 | CN 0604 | 87-099-201-010 | 0E | CONN,8P H BLK 6216 | UBM | AV-D77 |
| | O | VIDEO3 | CN 0605 | 8A-AR3-652-010 | | CONN ASSY,2P -VIDEO 3 | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | VIDEO3 | CN 0605 | 8A-AR3-652-110 | 0E | CONN ASSY,2P -VIDEO 3 | EZBM | AV-D77 |
| | O | VIDEO3 | CN 0605 | 8A-AR3-652-110 | 0E | CONN ASSY,2P -VIDEO 3 | UBM | AV-D77 |
| | S | VIDEO3 | D 0501 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0501 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | VIDEO3 | D 0501 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0502 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0502 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | VIDEO3 | D 0502 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0503 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0503 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | VIDEO3 | D 0503 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0504 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0504 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | VIDEO3 | D 0504 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0505 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0505 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | VIDEO3 | D 0505 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0506 | 87-020-465-080 | | DIODE,1SS133 | UBM | AV-D77 |
| | S | VIDEO3 | D 0506 | 87-020-465-080 | 0E | DIODE,1SS133 | EZBM | AV-D77 |
| | S | VIDEO3 | D 0506 | 87-020-465-080 | 0E | DIODE,1SS133 | UBM | AV-D77 |
| | X | VIDEO3 | EP 0501 | 81-689-212-010 | | PLATE,EARTH | UBM | AV-D77 |
| | X | VIDEO3 | EP 0501 | 81-689-212-010 | 0E | PLATE,EARTH | EZBM | AV-D77 |
| | X | VIDEO3 | EP 0501 | 81-689-212-010 | 0E | PLATE,EARTH | UBM | AV-D77 |
| | O | VIDEO3 | FB 0501 | 87-008-372-080 | | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | VIDEO3 | FB 0501 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | EZBM | AV-D77 |
| | O | VIDEO3 | FB 0501 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | VIDEO3 | FB 0602 | 87-008-372-080 | | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | VIDEO3 | FB 0602 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | EZBM | AV-D77 |
| | O | VIDEO3 | FB 0602 | 87-008-372-080 | 0E | FLTR,EMI BL01 RN1 | UBM | AV-D77 |
| | O | VIDEO3 | J 0501 | 87-A60-948-010 | | JACK,PIN 3P R/W/Y GLD | UBM | AV-D77 |
| | O | VIDEO3 | J 0501 | 87-A60-948-010 | 1B | JACK,PIN 3P R/W/Y GLD | EZBM | AV-D77 |
| | O | VIDEO3 | J 0501 | 87-A60-948-010 | 1B | JACK,PIN 3P R/W/Y GLD | UBM | AV-D77 |
| | O | VIDEO3 | J 0603 | 87-A60-550-010 | | JACK,DIA6.3 BLK ST W/SW KM | UBM | AV-D77 |
| | O | VIDEO3 | J 0603 | 87-A60-550-010 | 1A | JACK,DIA6.3 BLK ST W/SW KM | EZBM | AV-D77 |
| | O | VIDEO3 | J 0603 | 87-A60-550-010 | 1A | JACK,DIA6.3 BLK ST W/SW KM | UBM | AV-D77 |
| | X | VIDEO3 | JR 0501 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | VIDEO3 | JR 0501 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | VIDEO3 | JR 0501 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | VIDEO3 | JR 0502 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | VIDEO3 | JR 0502 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | VIDEO3 | JR 0502 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | VIDEO3 | JR 0503 | 88-118-000-080 | | C-JUMPER,S | UBM | AV-D77 |
| | X | VIDEO3 | JR 0503 | 88-118-000-080 | 0E | C-JUMPER,S | EZBM | AV-D77 |
| | X | VIDEO3 | JR 0503 | 88-118-000-080 | 0E | C-JUMPER,S | UBM | AV-D77 |
| | X | VIDEO3 | JR 0504 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VIDEO3 | JR 0504 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | VIDEO3 | JR 0504 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VIDEO3 | R 0503 | 88-118-334-080 | | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | VIDEO3 | R 0503 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | EZBM | AV-D77 |
| | X | VIDEO3 | R 0503 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | VIDEO3 | R 0506 | 88-118-334-080 | | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | VIDEO3 | R 0506 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | EZBM | AV-D77 |
| | X | VIDEO3 | R 0506 | 88-118-334-080 | 0E | C-RES,S 330K-1/10W J | UBM | AV-D77 |
| | X | VIDEO3 | R 0507 | 88-118-750-080 | | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | VIDEO3 | R 0507 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | EZBM | AV-D77 |
| | X | VIDEO3 | R 0507 | 88-118-750-080 | 0E | C-RES,S 75-1/10W J | UBM | AV-D77 |
| | X | VIDEO3 | R 0508 | 88-118-109-080 | | C-RES,S 1-1/10W J | UBM | AV-D77 |
| | X | VIDEO3 | R 0508 | 88-118-109-080 | 0E | C-RES,S 1-1/10W J | EZBM | AV-D77 |
| | X | VIDEO3 | R 0508 | 88-118-109-080 | 0E | C-RES,S 1-1/10W J | UBM | AV-D77 |
| | O | VOLUME | C 0601 | 87-010-195-080 | | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0601 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0601 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0602 | 87-010-195-080 | | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0602 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0602 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0603 | 87-010-195-080 | | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0603 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0603 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0604 | 87-010-195-080 | | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0604 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | O | VOLUME | C 0604 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0605 | 87-010-195-080 | | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0605 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0605 | 87-010-195-080 | 0E | C-CAP,S 0.068-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0606 | 87-010-805-080 | | C-CAP,S 1-16 Z F | UBM | AV-D77 |
| | O | VOLUME | C 0606 | 87-010-805-080 | 0E | C-CAP,S 1-16 Z F | EZBM | AV-D77 |
| | O | VOLUME | C 0606 | 87-010-805-080 | 0E | C-CAP,S 1-16 Z F | UBM | AV-D77 |
| | O | VOLUME | C 0607 | 87-010-178-080 | | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0607 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0607 | 87-010-178-080 | 0E | C-CAP,S 1000P-50 K B C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0608 | 87-010-186-080 | | C-CAP,S 4700P-50 K B C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0608 | 87-010-186-080 | 0E | C-CAP,S 4700P-50 K B C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0608 | 87-010-186-080 | 0E | C-CAP,S 4700P-50 K B C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0610 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0610 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0610 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0611 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0611 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0611 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0612 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0612 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0612 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0613 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0613 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0613 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0614 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0614 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0614 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0615 | 87-010-196-080 | | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0615 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | EZBM | AV-D77 |
| | O | VOLUME | C 0615 | 87-010-196-080 | 0E | C-CAP,S 0.1-25 Z F C2012 | UBM | AV-D77 |
| | O | VOLUME | C 0634 | 87-010-374-080 | | CAP,E 47-10 M 11L SME | UBM | AV-D77 |
| | O | VOLUME | C 0634 | 87-010-374-080 | 0E | CAP,E 47-10 M 11L SME | EZBM | AV-D77 |
| | O | VOLUME | C 0634 | 87-010-374-080 | 0E | CAP,E 47-10 M 11L SME | UBM | AV-D77 |
| | X | VOLUME | C 0635 | 88-100-000-010 | | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | X | VOLUME | C 0635 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | EZBM | AV-D77 |
| | X | VOLUME | C 0635 | 88-100-000-010 | 0E | PLATING-JW, 0.58 SN95 | UBM | AV-D77 |
| | O | VOLUME | CN 0601 | 87-A60-076-010 | | CONN,12P H 9604S-12F | UBM | AV-D77 |
| | O | VOLUME | CN 0601 | 87-A60-076-010 | 0E | CONN,12P H 9604S-12F | EZBM | AV-D77 |
| | O | VOLUME | CN 0601 | 87-A60-076-010 | 0E | CONN,12P H 9604S-12F | UBM | AV-D77 |
| | O | VOLUME | CN 0603 | 87-A60-080-010 | | CONN,07P H 9604S-07F | UBM | AV-D77 |
| ! | O | VOLUME | CN 0603 | 87-A60-080-010 | 0E | CONN,07P H 9604S-07F | EZBM | AV-D77 |
| ! | O | VOLUME | CN 0603 | 87-A60-080-010 | 0E | CONN,07P H 9604S-07F | UBM | AV-D77 |
| | S | VOLUME | D 0602 | 87-017-931-080 | | ZENER,MTZJ5.6B | UBM | AV-D77 |
| | S | VOLUME | D 0602 | 87-017-931-080 | 0E | ZENER,MTZJ5.6B | EZBM | AV-D77 |
| | S | VOLUME | D 0602 | 87-017-931-080 | 0E | ZENER,MTZJ5.6B | UBM | AV-D77 |
| | X | VOLUME | JR 0602 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0602 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | VOLUME | JR 0602 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0603 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0603 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | VOLUME | JR 0603 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0604 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0604 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | VOLUME | JR 0604 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0611 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0611 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | VOLUME | JR 0611 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0612 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0612 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | VOLUME | JR 0612 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0613 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0613 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | VOLUME | JR 0613 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0614 | 88-129-000-080 | | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0614 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | VOLUME | JR 0614 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | X | VOLUME | JR 0627 | 88-129-000-080 | 0E | C-JUMPER,3216 | EZBM | AV-D77 |
| | X | VOLUME | JR 0627 | 88-129-000-080 | 0E | C-JUMPER,3216 | UBM | AV-D77 |
| | S | VOLUME | Q 0601 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | S | VOLUME | Q 0601 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | VOLUME | Q 0601 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0602 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0602 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0602 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0603 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0603 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | VOLUME | Q 0603 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0604 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0604 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0604 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0605 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0605 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0605 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0606 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0606 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0606 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0607 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0607 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | VOLUME | Q 0607 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0608 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0608 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0608 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0609 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0609 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | VOLUME | Q 0609 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0610 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0610 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0610 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0611 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0611 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0611 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0612 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0612 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0612 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0613 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0613 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | VOLUME | Q 0613 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0614 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0614 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0614 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0615 | 87-A30-076-080 | | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0615 | 87-A30-076-080 | 0E | C-TR,2SC3052F | EZBM | AV-D77 |
| | S | VOLUME | Q 0615 | 87-A30-076-080 | 0E | C-TR,2SC3052F | UBM | AV-D77 |
| | S | VOLUME | Q 0616 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0616 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0616 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0617 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0617 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0617 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0618 | 87-A30-075-080 | | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0618 | 87-A30-075-080 | 0E | C-TR,2SA1235F | EZBM | AV-D77 |
| | S | VOLUME | Q 0618 | 87-A30-075-080 | 0E | C-TR,2SA1235F | UBM | AV-D77 |
| | S | VOLUME | Q 0619 | 87-026-610-080 | | TR,KTC3198GR | UBM | AV-D77 |
| | S | VOLUME | Q 0619 | 87-026-610-080 | 0E | TR,KTC3198GR | EZBM | AV-D77 |
| | S | VOLUME | Q 0619 | 87-026-610-080 | 0E | TR,KTC3198GR | UBM | AV-D77 |
| | X | VOLUME | R 0601 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0601 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0601 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0602 | 88-118-474-080 | | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0602 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0602 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0603 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0603 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0603 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0604 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0604 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0604 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0605 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0605 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | VOLUME | R 0605 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0606 | 88-118-474-080 | | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0606 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0606 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0607 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0607 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0607 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0608 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0608 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0608 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0609 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0609 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0609 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0610 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0610 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0610 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0611 | 88-118-474-080 | | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0611 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0611 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0612 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0612 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0612 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0613 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0613 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0613 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0614 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0614 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0614 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0615 | 88-118-474-080 | | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0615 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0615 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0616 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0616 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0616 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0617 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0617 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0617 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0618 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0618 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0618 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0619 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0619 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0619 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0620 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0620 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0620 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0621 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0621 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0621 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0622 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0622 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0622 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0623 | 88-118-224-080 | | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0623 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0623 | 88-118-224-080 | 0E | C-RES,S 220K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0624 | 88-118-474-080 | | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0624 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0624 | 88-118-474-080 | 0E | C-RES,S 470K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0625 | 88-118-472-080 | | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0625 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0625 | 88-118-472-080 | 0E | C-RES,S 4.7K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0626 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0626 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0626 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0627 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0627 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0627 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0628 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0628 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0628 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | VOLUME | R 0629 | 88-118-682-080 | | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0629 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0629 | 88-118-682-080 | 0E | C-RES,S 6.8K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0630 | 88-118-273-080 | | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0630 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0630 | 88-118-273-080 | 0E | C-RES,S 27K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0631 | 88-118-102-080 | | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0631 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0631 | 88-118-102-080 | 0E | C-RES,S 1K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0632 | 88-118-152-080 | | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0632 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0632 | 88-118-152-080 | 0E | C-RES,S 1.5K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0633 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0633 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0633 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0634 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0634 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0634 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0635 | 88-118-101-080 | | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0635 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0635 | 88-118-101-080 | 0E | C-RES,S 100-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0636 | 88-118-331-080 | | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0636 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0636 | 88-118-331-080 | 0E | C-RES,S 330-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0637 | 88-128-180-080 | | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | VOLUME | R 0637 | 88-128-180-080 | 0E | C-RES, 18-1/8W J | EZBM | AV-D77 |
| | X | VOLUME | R 0637 | 88-128-180-080 | 0E | C-RES, 18-1/8W J | UBM | AV-D77 |
| | X | VOLUME | R 0638 | 88-118-470-080 | | C-RES,S 47-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0638 | 88-118-470-080 | 0E | C-RES,S 47-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0638 | 88-118-470-080 | 0E | C-RES,S 47-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0640 | 88-118-823-080 | | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0640 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0640 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0641 | 88-118-823-080 | | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0641 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0641 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0642 | 88-118-823-080 | | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0642 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0642 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0643 | 88-118-823-080 | | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0643 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0643 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0644 | 88-118-823-080 | | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0644 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0644 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0645 | 88-118-823-080 | | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0645 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0645 | 88-118-823-080 | 0E | C-RES,S 82K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0646 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0646 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0646 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0647 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0647 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0647 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0648 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0648 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0648 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0649 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0649 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0649 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0650 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0650 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0650 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0651 | 88-118-105-080 | | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0651 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0651 | 88-118-105-080 | 0E | C-RES,S 1M-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0661 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0661 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0661 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0662 | 88-118-822-080 | | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |

# PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.
K NO. = Only use japanese.

| ! | C | UNIT NAME | REF NO. | PARTS CODE | K NO. | DESCRIPTION | SUFFIX | MODEL NAME |
|---|---|---|---|---|---|---|---|---|
| | X | VOLUME | R 0662 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0662 | 88-118-822-080 | 0E | C-RES,S 8.2K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0665 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0665 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0665 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0671 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0671 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0671 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0672 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0672 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0672 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0673 | 88-118-154-080 | | C-RES,S 150K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0673 | 88-118-154-080 | 0E | C-RES,S 150K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0673 | 88-118-154-080 | 0E | C-RES,S 150K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0674 | 88-118-154-080 | | C-RES,S 150K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0674 | 88-118-154-080 | 0E | C-RES,S 150K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0674 | 88-118-154-080 | 0E | C-RES,S 150K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0675 | 88-118-154-080 | | C-RES,S 150K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0675 | 88-118-154-080 | 0E | C-RES,S 150K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0675 | 88-118-154-080 | 0E | C-RES,S 150K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0676 | 88-118-124-080 | | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | X | VOLUME | R 0676 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | EZBM | AV-D77 |
| | X | VOLUME | R 0676 | 88-118-124-080 | 0E | C-RES,S 120K-1/10W J | UBM | AV-D77 |
| | O | VOLUME | S 0601 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | VOLUME | S 0601 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | VOLUME | S 0601 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | VOLUME | S 0602 | 87-A90-095-080 | | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | VOLUME | S 0602 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | EZBM | AV-D77 |
| | O | VOLUME | S 0602 | 87-A90-095-080 | 0E | SW,TACT EVQ11G04M | UBM | AV-D77 |
| | O | VOLUME | SW 0601 | 87-A91-645-010 | | SW,RTRY EC12E24304NON-CLICK | UBM | AV-D77 |
| | O | VOLUME | SW 0601 | 87-A91-645-010 | 1A | SW,RTRY EC12E24304NON-CLICK | EZBM | AV-D77 |
| | O | VOLUME | SW 0601 | 87-A91-645-010 | 1A | SW,RTRY EC12E24304NON-CLICK | UBM | AV-D77 |
| | X | VOLUME | W 0101 | 89-750-164-610 | | WIRE ASSY, LUG | UBM | AV-D77 |
| | X | VOLUME | W 0101 | 89-750-164-610 | 0E | WIRE ASSY, LUG | EZBM | AV-D77 |
| | X | VOLUME | W 0101 | 89-750-164-610 | 0E | WIRE ASSY, LUG | UBM | AV-D77 |

# ELECTRICAL MAIN PARTS LIST - 1/2 (TUNER : AZA-8)

NOTE: The characters in the suffix column indicate the part usage.

| | | |
|---|---|---|
| ULHM | XX | A |
| EZM | XX | B |

| REF.NO | PARTS NO. | KANRI NO. | DESCRIPTION | SUFFIX |
|---|---|---|---|---|
| C 701 | 87-010-260-080 | | CAP, ELECT 47-25V | ABC |
| C 702 | 87-010-404-080 | | CAP, ELECT 4.7-50V | ABC |
| C 709 | 87-012-195-080 | | C-CAP,U 100P-50CH | ABC |
| C 703 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 704 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 712 | 87-010-196-080 | | CHIP CAPACITOR,0.1-25 | ABC |
| C 711 | 87-010-263-080 | | CAP, ELECT 100-10V | ABC |
| C 715 | 87-012-195-080 | | C-CAP,U 100P-50CH | .B |
| C 717 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 714 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 713 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 719 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 727 | 87-010-196-080 | | CHIP CAPACITOR,0.1-25 | ABC |
| C 728 | 87-010-248-080 | | CAP, ELECT 220-10V | ABC |
| C 721 | 87-012-176-080 | | CAP 15P | ABC |
| C 722 | 87-012-176-080 | | CAP 15P | ABC |
| C 720 | 87-012-195-080 | | C-CAP,U 100P-50CH | .B |
| C 725 | 87-012-274-080 | | CHIP CAP,U 1000P-50B | ABC |
| C 723 | 87-012-274-080 | | CHIP CAP,U 1000P-50B | ABC |
| D 721 | 87-017-148-080 | | ZENER,HZS6A1L | ABC |
| D 774 | 87-A40-269-080 | | C-DIODE,MC2836 | .B |
| D 774 | 87-A40-270-080 | | C-DIODE,MC2838 | A.C |
| IC 721 | 87-070-127-110 | | IC,LC72131 D | ABC |
| Q 711 | 87-A30-196-080 | | TR,2SC4115SRS | ABC |
| X 721 | 87-A70-061-010 | | VIB,XTAL 4.500MHZ CSA-309 | ABC |
| C 758 | 87-012-167-080 | | C-CAP,U 5P-50 CH | ABC |
| C 757 | 87-012-188-080 | | C-CAP,U 47P-50 CH | ABC |
| C 753 | 87-012-195-080 | | C-CAP,U 100P-50CH | .B |
| C 756 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 755 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 761 | 87-010-196-080 | | CHIP CAPACITOR,0.1-25 | ABC |
| C 769 | 87-010-260-080 | | CAP, ELECT 47-25V | ABC |
| C 763 | 87-010-829-080 | | CAP, U 0.047-16 | ABC |
| C 766 | 87-012-286-080 | | CAP, U 0.01-25 | .B |
| C 765 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 762 | 87-012-286-080 | | CAP, U 0.01-25 | .B |
| C 768 | 87-012-286-080 | | CAP, U 0.01-25 | .B |
| C 764 | 87-012-337-080 | | C-CAP,U 56P-50 CH | A.C |
| C 773 | 87-010-196-080 | | CHIP CAPACITOR,0.1-25 | A.C |
| C 774 | 87-010-263-080 | | CAP, ELECT 100-10V | ABC |
| C 771 | 87-010-383-080 | | CAP, ELECT 33-25V | ABC |
| C 777 | 87-010-400-080 | | CAP, ELECT 0.47-50V | ABC |
| C 779 | 87-010-401-080 | | CAP, ELECT 1-50V | ABC |
| C 778 | 87-010-401-080 | | CAP, ELECT 1-50V | ABC |
| C 775 | 87-010-404-080 | | CAP, ELECT 4.7-50V | ABC |
| C 772 | 87-010-829-080 | | CAP, U 0.047-16 | ABC |
| C 770 | 87-010-829-080 | | CAP, U 0.047-16 | ABC |
| C 776 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 773 | 87-015-785-080 | | CHIP CAPACITOR, 0.1FZ-25Z | .B |
| C 780 | 87-010-196-080 | | CHIP CAPACITOR,0.1-25 | ABC |
| C 781 | 87-010-405-080 | | CAP, ELECT 10-50V | ABC |
| C 782 | 87-010-405-080 | | CAP, ELECT 10-50V | ABC |
| C 785 | 87-010-805-080 | | CAP, S 1-16 | ABC |
| C 786 | 87-010-805-080 | | CAP, S 1-16 | ABC |
| C 789 | 87-012-275-080 | | C-CAP,U 1200P-50 B | ABC |
| C 788 | 87-012-280-080 | | CAP, U 3300P-50 | ABC |
| C 787 | 87-012-280-080 | | CAP, U 3300P-50 | ABC |
| C 784 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 783 | 87-012-286-080 | | CAP, U 0.01-25 | ABC |
| C 795 | 87-010-194-080 | | CAP, CHIP 0.047 | A.C |
| C 796 | 87-010-403-080 | | CAP, ELECT 3.3-50V | ABC |
| C 791 | 87-010-405-080 | | CAP, ELECT 10-50V | ABC |
| C 794 | 87-010-406-080 | | CAP, ELECT 22-50 | ABC |
| C 795 | 87-010-829-080 | | CAP, U 0.047-16 | .B |
| C 799 | 87-010-829-080 | | CAP, U 0.047-16 | ABC |
| C 793 | 87-012-273-080 | | C-CAP,U 820P-50 B | A.C |
| C 793 | 87-012-274-080 | | CHIP CAP,U 1000P-50B | .B |
| C 790 | 87-012-275-080 | | C-CAP,U 1200P-50 B | ABC |
| C 797 | 87-012-276-080 | | CAP, CHIP SS 1500 PBK | .BC |
| C 798 | 87-012-276-080 | | CAP, CHIP SS 1500 PBK | .BC |
| C 797 | 87-012-278-080 | | C-CAP,U 2200P-50 B | A |
| C 798 | 87-012-278-080 | | C-CAP,U 2200P-50 B | A |
| CN 601 | 87-099-029-010 | | CONN,12P 6216H | ABC |
| D 771 | 87-020-465-080 | | DIODE,1SS133 (110MA) | .B |
| D 773 | 87-020-465-080 | | DIODE,1SS133 (110MA) | ABC |
| IC 771 | 87-A20-913-010 | | IC,LA1837NL | ABC |
| L 771 | 87-A50-266-010 | | COIL,FM DET-2N(TOK) | ABC |
| L 772 | 87-A90-733-010 | | FLTR,PCFAZH-450 (TOK) | ABC |
| L 781 | 87-005-847-080 | | COIL,2.2UH(CECS) | ABC |
| L 792 | 87-A50-027-010 | | COIL,1 POLE MPX(TOK) | .BC |

# ELECTRICAL MAIN PARTS LIST - 2/2 (TUNER : AZA-8)

| | | | | |
|---|---|---|---|---|
| L | 791 | 87-A50-027-010 | COIL,1 POLE MPX(TOK) | .BC..... |
| L | 792 | 87-A50-209-010 | COIL,1POLE MPX(MIT) | A..... |
| L | 791 | 87-A50-209-010 | COIL,1POLE MPX(MIT) | A..... |
| C | 859 | 87-012-286-080 | CAP, U 0.01-25 | .B..... |
| C | 865 | 87-010-196-080 | CHIP CAPACITOR,0.1-25 | .B..... |
| C | 864 | 87-010-405-080 | CAP, ELECT 10-50V | .B..... |
| C | 866 | 87-010-405-080 | CAP, ELECT 10-50V | .B..... |
| C | 869 | 87-012-180-080 | C-CAP,U 22P-50 CH | .B..... |
| C | 868 | 87-012-184-080 | C-CAP,U 33P-50 CH | .B..... |
| C | 862 | 87-012-199-080 | CAP  220P | .B..... |
| C | 861 | 87-012-199-080 | CAP  220P | .B..... |
| C | 863 | 87-012-270-080 | CAP, U 470P-50 | .B..... |
| C | 867 | 87-012-286-080 | CAP, U 0.01-25 | .B..... |
| CN | 602 | 87-099-211-010 | CONN,4P 6216V | .B..... |
| IC | 851 | 87-A20-440-040 | C-IC,BU1920FS | .B..... |
| Q | 853 | 87-A30-076-080 | C-TR,2SC3052F | .B..... |
| X | 851 | 87-A70-091-010 | VIB,XTAL 4.332MHZ CSA-309 | .B..... |
| C | 818 | 87-010-196-080 | CHIP CAPACITOR,0.1-25 | .B..... |
| C | 819 | 87-010-197-080 | CAP, CHIP 0.01 DM | A.C..... |
| C | 813 | 87-010-197-080 | CAP, CHIP 0.01 DM | A.C..... |
| C | 814 | 87-012-286-080 | CAP, U 0.01-25 | ABC..... |
| C | 812 | 87-012-286-080 | CAP, U 0.01-25 | ABC..... |
| C | 828 | 87-010-196-080 | CHIP CAPACITOR,0.1-25 | ABC..... |
| C | 829 | 87-010-196-080 | CHIP CAPACITOR,0.1-25 | ABC..... |
| C | 820 | 87-010-260-080 | CAP, ELECT 47-25V | ABC..... |
| C | 822 | 87-012-286-080 | CAP, U 0.01-25 | ABC..... |
| C | 823 | 87-012-286-080 | CAP, U 0.01-25 | ABC..... |
| C | 821 | 87-012-286-080 | CAP, U 0.01-25 | ABC..... |
| C | 942 | 87-012-172-080 | CAPACITOR CHIP U 10P CH | .B..... |
| C | 940 | 87-012-286-080 | CAP, U 0.01-25 | .B..... |
| C | 947 | 87-012-286-080 | CAP, U 0.01-25 | .B..... |
| C | 949 | 87-A10-039-080 | C-CAP,U 470P-50 J CH | .B..... |
| C | 959 | 87-010-196-080 | CHIP CAPACITOR,0.1-25 | ABC..... |
| C | 958 | 87-012-286-080 | CAP, U 0.01-25 | .B..... |
| C | 952 | 87-012-286-080 | CAP, U 0.01-25 | .B..... |
| C | 960 | 87-010-196-080 | CHIP CAPACITOR,0.1-25 | ABC..... |
| C | 962 | 87-010-401-080 | CAP, ELECT 1-50V | .B..... |
| C | 961 | 87-012-170-080 | C-CAP,U 8P-50 CH | A.C..... |
| CF | 802 | 82-785-747-010 | CF MS2 GHY R | .B..... |
| CF | 801 | 87-008-261-010 | FILTER, SFE10.7MA5-A | A.C..... |
| CF | 802 | 87-008-261-010 | FILTER, SFE10.7MA5-A | A.C..... |
| CF | 801 | 87-008-423-010 | CERAMIC FILTER, SFE10.7 | .B..... |
| D | 944 | 87-020-465-080 | DIODE,1SS133 (110MA) | .B..... |
| D | 942 | 87-A40-270-080 | C-DIODE,MC2838 | .B..... |
| FFE | 801 | A8-6ZA-191-130 | 6ZA-1 FEENM | .B..... |
| FFE | 801 | A8-8ZA-190-030 | 8ZA-1 FEUNM | A.C..... |
| J | 802 | 87-033-241-010 | TERMINAL,ANT AJ-2039 | .B..... |
| J | 801 | 87-A60-657-010 | TERMINAL,4P HSP-154V5-02 | A.C..... |
| L | 832 | 87-005-847-080 | COIL,2.2UH(CECS) | ABC..... |
| L | 942 | 87-A50-019-010 | COIL,OSC LW(COI) | .B..... |
| L | 941 | 87-A50-020-010 | COIL,ANT LW(COI) | .B..... |
| L | 981 | 87-NF4-650-010 | COIL,AM PACK 4N(TOK) | A.C..... |
| L | 981 | 87-NF4-651-110 | COIL,AM PACK2N(TOM) | .B..... |
| Q | 806 | 87-A30-072-080 | C-TR,RT1P 144C | ABC..... |
| Q | 805 | 89-327-143-080 | TR,2SC2714 (0.1W) | ABC..... |
| Q | 948 | 87-A30-086-070 | C-TR,CSD1306E | .B..... |
| Q | 947 | 89-503-602-080 | C-FET,2SK360E | .B..... |
| Q | 951 | 87-A30-074-080 | C-TR,RT1P 141C | .B..... |
| Q | 952 | 87-A30-086-070 | C-TR,CSD1306E | .B..... |
| TC | 942 | 87-A91-658-010 | TRIMMER,30P 4.0X4.5 ECRL | .B..... |

# SCHEMATIC DIAGRAM – 1 ( MAIN 1/2)



# SCHEMATIC DIAGRAM – 2 ( MAIN 2/2)




| PROTECT | R335, R336 |
|---|---|
| AAR-1, 2 | 1.2K |
| AAR-3, 2ULO | 1K |
| AAR-4 | 1K |

| PROTECT | R235, R236 |
|---|---|
| AAR-1, 2 | 1.5K |
| AAR-3, 2ULO | 1K |
| AAR-4 | 1K |

| PROTECT | R418 |
|---|---|
| AAR-1/2 | 1.5K |
| AAR-3U, 2ULO | 1K |
| AAR-3, 4 LH | 1.5K |
| AAR-4 | |

| PROTECT | R366 |
|---|---|
| AAR-1, 2 | 1K |
| AAR-3H, EZ | 1.5K |
| AAR-4/3U | 2.7K |

| PROTECT | R444 |
|---|---|
| AAR-1, 2 | 1K |
| AAR-3H, EZ | 1.5K |
| AAR-4/3U | 2.7K |

| PR101 | PR104 | PR107 | PR108 |
|---|---|---|---|
| PROTEC 10K | PROTEC 10K | PROTEC 10K | PROTEC 10K |
| PROTEC 10K | PROTEC 10K | PROTEC 10K | PROTEC 10K |
| FUSE 10A | FUSE 10A | FUSE 10A | PROTEC 10K |
| PROTEC 10K | PROTEC 10K | PROTEC 10K | PROTEC 10K |
| PROTEC 10K | PROTEC 10K | PROTEC 10K | PROTEC 10K |
| FUSE 10A | FUSE 10A | FUSE 10A | PROTEC 10K |
| PROTEC 10K | PROTEC 10K | PROTEC 10K | PROTEC 10K |
| PROTEC 10K | PROTEC 10K | PROTEC 10K | PROTEC 10K |
| Nothing | FUSE 10A | FUSE 10A | Nothing |
| Nothing | FUSE 10A | FUSE 10A | Nothing |
| Nothing | FUSE 10A | FUSE 10A | Nothing |
| Nothing | FUSE 10A | FUSE 10A | Nothing |

| R139, R140 (RESISTORS ARE 1/8W) | U | HR/HC | EZ | LH | Ø |
|---|---|---|---|---|---|
| AAR-1 | JR | JR | JR | JR | JR |
| AAR-2 | JR | 1.8 | JR | JR | JR |
| AAR-3 | 1.5 | JR | 1.8 | JR | 1.8 |
| AAR-4 | 1.5 | JR | 1.5 | JR | 1.5 |
| AAR-2ULO | 1.5 | | | | |

# SCHEMATIC DIAGRAM – 3 ( FRONT)


TO VOL PWB
AAR-1 U/EZ
AAR-1 H
12P
18P
12P
AAR-2 U/EZ
AAR-3 U/EZ/LH
AAR-4 U/EZ
AAR-2ULO
16P
AAR-3/4 H
18P
AAR-2 H
CN805
96045/H 18P
EQ LEVEL.M: AAR-1 ONLY
FR-L
FR-R
SR-L
SR-R
CENTER
SUB-W
VDD
D-GND
MUTE/BALA
VOL-IN
VCC
CHGND
DSP-CE
MICGND
MIC-OUT
DELAY-OUT
CLK M
DATA M
AAR-1/2H: ONLY
R982 1k *
R983 1k *
R977 1k *
C865 1000p *
HR/HC: ONLY
CN802
96045/H 35P
U/HR/HC/LH: 32P
EZ: 35P
EZ ONLY
R933 220
R934 220
R935 1k *
R936 1k
RDS-CLK
RDS-DATA
RDS-SIG/SYNC-DET
D-STB-31
STB-31
VCC
+10.6V
+10.2V
CH-GND
VID3-L
AGND
VID3-R
N.C
I/E
A-GND (HP)
HP-R
HP-L
VM
+11.8V
HOLD
CONT2
CONT1
MUTE
POWER
N.C
SW-RELAY
N.C
CLK M
STB M
DATA M
PLL-CE
STEREO
TUNE/TFC
TM-BASE
D-GND
-VFL
FIL2
FIL1
-28.5
~ 5.3V
1U: ONLY
R919 1k *
R937 1k
R938 1k
R939 100
R940 100
R941 1k *
R943 1k
R944 1k
R945 1k
R946 1k
R947 1k
R948 1k
R949 1k
R950 JR *
R951 JR *
CONT2
CONT1
MUTE
SW-RELAY
STB (M)
CLK (M)
DATA (M)
PLLCE
STEREO
TUNE/TFC
TM-BASE
1H/2H: USE
R952 47 *
MIC-OUT
JR826 JR * MICGND
R953 1k *
R954 1k *
R955 1k *
R956 1k *
RDS-SIG/SYNC-DET
OSD-CE
OSD-CLK
OSD-DATA
CH-GND
CHGND
R959 1k *
R960 100
R961 100
R962
R963
R964
R965
R966
R967
R968
R969
R970
R971
R972 22k 1/8W
TAPE-ATT
CN803
96045/H 18P
AAR-2 H 18P
N.C.
MIC-OUT
N.C.
MICGND
CH-GND
DSP-SW
TAPE-ATT
AK45-PDN
Y912-CSB
Y912-CS
Y912-SO
Y912-SI
Y912-SCK
Y917-CS
Y917-RST
AK45-CLK
AK45-DATA
AK45-CS
TO MAIN PWB
AAR-2U/ULO
AAR-3U
AAR-2
U/EZ
14P
AAR-3
LH
Nothing
AAR-3/4
U/EZ
Nothing
AAR-3/4
H
6P
DELAY-OUT
MIC-OUT
MIC-IN
MICGND
CH-GND
N.C.
AAR-1
U
18P
SYNC-DET
OSD-CE
OSD-CLK
OSD-DATA
CH-GND
DSP-SW
TO MAIN PWB
CN801
96045/H 8P
HP MUTE
VID3-L
HP-GND
VID3-R
CH GND
HP-R
A-GND
HP-L
I/E
HPGND
VID3-R
CH-GND
MIC-OUT
HP-R
AGND
HP-L
TO H/P PWB
D827
D811
OPTICAL -3PCS
OPTICAL -2PCS
OPTICAL -1PCS
DIODE MATRIX AAR-1/2
D808 96KHZ (96) - / - (96) (96) | ○ / - (48) | - / - (96) (96) | - / - (96) (96) | – (5)
D826 DTS - | ○ / ○ | - | ○ / - | ○ / - | ○
D828 96KHZ (96) - / - (96) (96) | ○ (48) | - / - (96) (96) | - / - (96) (96) | ○ (48)
D827 DIGITAL-IN1 - | ○ / - | - | ○ / - | ○ / - | -
D818 AC3 - | ○ / ○ | ○ | ○ / ○ | ○ / ○ | ○
D817 OSD - | ○ / - | - | - / - | - / - | -
D816 KARAOKE - | - / - | - | ○ / ○ | - / - | -
D815 AM 10K STEP - | ○ / ○ | ○ | - / - | - / - | ○
D814 AMST/WIDE - | - / - | - | - / - | - / - | -
D813 BBE - | - / - | ○ | - / - | - / - | ○
D812 RDS - | - / - | - | - / - | ○ / ○ | -
D811 DIGITAL-IN2 - | - / - | - | - / - | - / - | ○
D810 LW - | - / - | - | - / - | ○ / ○ | -
D809 GEQ - | - / - | ○ | - / - | - / - | ○
FL801
BJ759GK
IC801
μPD780228GF
:Non-O
PLLCE
DATA (M)
TUNE/TFC
STB (M)
MUTE
CLK (M)
DSP-CE
DSP-CE
D-STB-31
TM-BASE
D-TC4094-CE
AK45-CS
AK45-DATA
AK45-CLK
IC
VSS
VDD +5.5V
Y917-RST
Y917-CS
Y912-SCK
Y912-SI
Y912-SO
Y912-CS
Y912-CSB
AK45-PDN
RDS-CLK
RDS-DATA
RESET
D-K-SCAN
D-PLL-CE
D-DATA (M)
I-TUNE/TFC
D-STB (M)
D-MUTE
D-CLK (M)
D-DSP-CE
D-POWER
D-DSP-CE
D-STB-31
D-TM-BASE
D-TC4094-CE
D-AK45-CS
D-45-DATA
D-AK45-CLK
D-Y917-RST
D-Y917-CS
D-Y912-SCK
D-Y912-SI
D-Y912-SO
D-Y912-CS
D-Y912-CSB
D-AK45-PDN
I-RDS-DATA
I-RDS-CLK
CONT1
CONT2
OSD-CLK
OSD-DATA
I-RMC
C-SHIFT
VDD1
X2
X1
VSS1
AVDD
HOLD
I-PE-VOL
I-RDS-SIG/SYNC-DET
I-JOG2
I-JOG1
I-FU-JOG1
I-KEY2
I-KEY1
I-MULTI-LEVEL
AVSS
-VFL
VDD2
I-MIC
HP-MUTE
STEREO
DSP
DTS
96KHZ
DIGITAL-IN1
AC-3
OSD
KARAOKE
AMIOK
AMST/WIDE
BBE
RDS
DIGITAL-IN2
LW
GEQ
MICON VER IC801
AAR-1U -068
AAR-1EZ, H -069
AAR-2 (-01) -066
AAR-3U (-11) -070
ALL: USE
FR-L
FR-R
SR-L
SR-R
SUB-W
CENTER
C775 NM
R737 47k 1/8W
R738 47k 1/8W
R739 47k 1/8W
R742 4.7k
R740 4.7k
R741 4.7k
C724 NM
C714 10 50 5L
IC701
HD74HC4051FP
X4CEN
F-L X2
F-R X3
SW-R
SUB-W
INH
BIT
EE
VSS
R747 100
R744 100
R745 100
R746 100
R743 100
R748 100
R829
Q719
RT1N144C
R819 100k
R827 2.7k 1/8W
R823 470
R825 JR
R826 4.7k 1/8W
R821 4.7k
R822 470
C804 0.47/50
C807 0.1
C808 0.1
C809 0.1
C810 0.1
C811 220/10 SL
C812 220/10 SL
C805 0.1
C828 0.01
C802 100p
C803 0.1
R802 10k
R803 1.5k
C801 100p
R804 10k
R805 100k
R806 5k
R807 0k
R808 4.7k
R809 10k
R810 #
R811 0k
R701 0k
R702 0k
R703 0k
R812 #
R813 #
R701 10k
R814 100k 1/8W
R815 100k 1/8W
R816 220k
C814 1000p
C813 1/50 *
H VERSION: ONLY
C815 0.1 *
C816 15p CH
C817 180p CH
C818 1000p
C819 220p
C820 1000p
C821 1000p
C822 2200p
C823 2200p
C824 2200p
C825 2200p
C826 3300p
C827 0.022
C829 220p
C830 0.1
C831 0.1
C832 0.1
C833 0.1
C834 0.1 50V
C835 0.1 50V
C836 3300p
C837 3300p
C838 3300p
C839 3300p
C840 3300p
C841 3300p
C842 3300p
C843 3300p
C844 3300p
C845 3300p
C846 3300p
C847 10/50 7L
C848 0.1 **
C849 47/50 7L
C850 0.1
C851 220/10 SL
C852 0.1
C853 0.1
C854 0.1 50V
C855 0.1 50V
R924 JW *
R925 10 1/8W
R926 6.8k 1/8W
R927 47k
R928 47k
R929 47k
R930 JW *
R931 22k 1/8W
R932 10 1/8W
R933 100k
R934 100k
R935 100k
R936 100k
R937 100k
R938 100k
R939 100k
R940 100k
R941 100k
R942 100k
R943 100k
R944 100k
R945 100k
R946 100k
R947 100k
R948 100k
R949 100k
R950 100k
R951 100k
R952 100k
R953 100k
R954 100k
R955 100k
R956 100k
R957 100k
R958 100k
R959 100k
R960 100k
R961 100k
R962 100k
R963 100k
R964 100k
R965 100k
R966 100k
R967 100k
R968 100k
R969 100k
R970 100k
R971 100k
R972 100k
R973 100k
R974 100k
R975 100k
R976 100k
R977 100k
R978 47k
R979 47k
R980 10k
R981 10k
R982 10k
R983 10k
R984 10k
R985 10k
R986 10k
R987 10k
R988 10k
R989 10k
R990 10k
R991 10k
R992 10k
R993 10k
R994 10k
R995 10k
R996 10k
R997 10k
R998 10k
R999 10k

# SCHEMATIC DIAGRAM – 4 (DIGITAL)



SCHEMATIC DIAGRAM – 5 (SVIDEO)




Y.G.KIM Y.G.KIM

SHEMATIC ÐIAGRAM (SVIÐEO)

AAR-1/AAR-2U

25 JAN 2000

SCHEMATIC DIAGRAM – 6 (MIC / OSD/KEY CON / OSD)




ONLY HR/HC USE




ONLY HR/HC USE




ONLY 1U USE

Y.G.KIM Y.G.KIM

SHEMATIC DIAGRAM (OSDKEYMIC)

AAR-1/2/3/4

25 JAN 2000

-AAR-OSDKEYMIC

TMP 13001 25.04.2000 17:17:55 T-AAR-OSDKEYMIC P1

SCHEMATIC DIAGRAM – 7 (HP VIDEO / GEQ / VOL)



# SCHEMATIC DIAGRAM – 8 (U : TUNER)



# SCHEMATIC DIAGRAM – 9 (EZ : TUNER)




T-AAR-TUNER-EZ

SM-TMP 13001 25.04.2000 17:20:13 T-AAR-TUNER-EZ P1

SCHEMATIC DIAGRAM TUNNER (EZ)

8A ZAB 602 01

COD00104

AAR-1/2/3/4

26 MAR 2000

SCHEMATIC DIAGRAM – 10 (SPKR)




| | | | | |
|---|---|---|---|---|
| SPKR TERMINAL: | AAR-1 | BANANA: U/HC<br>SCREW: EZ | AAR-3 | PUSH: U<br>SCREW: LH<br>BANANA: HC |
| | AAR-2 | PUSH: ULO<br>BANANA: U/HC<br>SCREW: EZ/HR | AAR-4 | PUSH: U<br>SCREW: EZ<br>BANANA: HC |

Y.G.KIM Y.G.KIM

SHEMATIC DIAGRAM (SPKR)

AAR-1/2/3/4

29 OCT 1999

SCHEMATIC DIAGRAM – 11 (AC OUTLET)




AC OUTLET PWB
AAR-1U/2UHI: USE

| F102 | |
|---|---|
| 1U | 1A/125V |
| 2UHI | 1A/125V |

| F103 | |
|---|---|
| 1U | 1A/125V |
| 2UHI | 1A/125V |

Y.G.KIM Y.G.KIM

SHEMATIC DIAGRAM (SPKR)

AAR-1U/2UHI

08 JAN 2000

SCHEMATIC DIAGRAM – 12 (PT)

| VERSION | PWR TRANS | | |
|---|---|---|---|
| 1EZ | 8A-AR1-607-01 | 100WX5 | 8 OHM |
| | | 100WX3, 60WX2 | 4 OHM |
| 1U | 8A-AR1-605-01 | 120WX5 | 8 OHM |
| | | 120WX3, 60WX2 | 4 OHM |
| 2EZ | 8A-AR1-607-01 | 100WX5 | 8 OHM |
| | | 100WX3, 60WX2 | 4 OHM |
| 2UHI | 8A-AR1-605-01 | 120WX5 | 8 OHM |
| | | 120WX3, 60WX2 | 4 OHM |
| 2ULO | 8Z-AR3-601-01 | 100WX5 | 8 OHM |

| VERSION | PWR TRANS | | |
|---|---|---|---|
| 3U | 8A-AR3-605-01 | 70WX5 | 8 OHM |
| 4EZ | 8A-AR4-607-01 | 60WX5 | 8 OHM |




| | PR105, PR106 | PR115, PR116 | F101 |
|---|---|---|---|
| 1EZ | PROTEC 7K | PROTEC 7K | T6.3AL/250V |
| 1U | FUSE 7A | FUSE 7A | 10A/125V |
| 2EZ | PROTEC 7K | PROTEC 7K | T6.3AL/250V |
| 2UHI | FUSE 7A | FUSE 7A | 10A/125V |
| 2ULO | FUSE 10A | Nothing | 10A/125V |
| 3EZ | PROTEC 10K | Nothing | T5AL/250V |
| 3U | FUSE 10A | Nothing | 10A/125V |
| 4EZ | PROTEC 10K | Nothing | T4AL/250V |
| 4U | FUSE 10A | Nothing | 8A/125V |

| SUB TRANS | |
|---|---|
| U | 661-01 |
| EZ | 662-01 |

Y.G.KIM Y.G.KIM

SHEMATIC ĐIAGRAM (AC1UEZ)

AAR-1/2/3/4

23 JAN 2000

アイワ株式会社 〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 (代表)
AIWA CO.,LTD. 2–11, IKENOHATA 1–CHOME, TAITO-KU, TOKYO 110, JAPAN TEL:03 (3827) 3111

9301978 Printed in Singapore